Aoxun TM-TSF213

Aoxun 70-inch Fireplace TV Stand Entertainment Center Instruction Manual

Model: TM-TSF213 | **Brand:** Aoxun

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Aoxun 70-inch Fireplace TV Stand Entertainment Center. Please read all instructions carefully before assembly and use to ensure safe and proper operation.
Important Note: This product is shipped in two separate packages, which may arrive at different times. Please ensure all packages have been received before beginning assembly.

Package Contents

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.



Image Description: This image illustrates the product dimensions and indicates that the product comes in two packages: one for the TV stand and one for the fireplace insert. The total weight is approximately 130 lbs. Dimensions shown are 79 inches (length), 13.94 inches (depth), and 22.24 inches (height) for the TV stand, and 36 inches (width), 18.5 inches (height), and 4.7 inches (depth) for the fireplace insert.

- TV Stand Components (various panels, hardware, shelves)
- 36-inch Electric Fireplace Insert
- Remote Control for Electric Fireplace
- Assembly Hardware Kit
- Instruction Manual

Setup and Assembly

Assembly typically requires one to two people and can be completed in approximately one hour. Follow the detailed instructions provided in the separate assembly guide included with your product. Ensure you have adequate space and the necessary tools (e.g., screwdriver) before starting.

Key Assembly Steps:

1. Unpack all components and verify against the parts list.

2. Assemble the main frame of the TV stand according to the diagrams.
3. Install the shelves and cabinet doors. The cabinet doors feature a high-gloss finish.
4. Integrate the 36-inch electric fireplace insert into the designated opening.
5. Connect any internal wiring for LED lighting, if applicable.
6. Place the TV stand in its desired location. Ensure it is on a stable, level surface.




Image Description: This image highlights key features of the TV stand. It shows a close-up of the fireplace insert, a high-gloss cabinet door, a circular cutout for cable management, and an interior view of a storage shelf.

Operating Instructions

Electric Fireplace Operation:

The electric fireplace can be operated using the control panel on the unit or the included remote control.



Image Description: This image displays the control panel buttons for the electric fireplace. Buttons include Timer (0h to 8h), Temperature (62°F to 82°F), Heat (750W/1500W), Dimmer (12 flame colors and 5 brightness adjustments), and Power (on/off).

- **Power:** Press the power button to turn the fireplace on or off.
- **Heat Settings:** Select between 750W (low heat) and 1500W (high heat) modes.
- **Temperature Control:** Adjust the desired room temperature between 62°F and 82°F.
- **Flame Colors:** The fireplace features 12 distinct flame colors. Cycle through them using the appropriate button on the control panel or remote.
- **Flame Brightness:** There are 5 levels of flame brightness adjustment.
- **Timer:** Set the operational timer for 0 to 8 hours.




Image Description: This graphic illustrates the 12 available flame colors and 5 brightness levels (100%, 75%, 50%, 25%, 0%) for the electric fireplace, controlled by the remote.

LED Light System Operation:

The TV stand includes an integrated LED light system with 12 color options, controllable via a remote.



Image Description: This image shows the TV stand's LED lighting in various colors within the open compartments, along with a remote control for adjusting the 12 available colors.

- Use the dedicated remote control to turn the LED lights on/off and cycle through the 12 color options.

Storage Cabinets:

The TV stand features high-gloss storage cabinets for organizing media devices, accessories, and other items.



Image Description: This image shows the TV stand with its storage compartments open, demonstrating the ample space available for various items. The compartments are illuminated by the internal LED lighting.

- Open the cabinet doors to access the internal shelves.
- Utilize the cable management cutouts to route wires neatly and prevent tangles.

Maintenance

Cleaning:

- For general cleaning, wipe the surfaces of the TV stand with a dry, soft cloth.
- Avoid using abrasive cleaners, harsh chemicals, or excessive moisture, as these can damage the engineered wood and high-gloss finish.
- For the electric fireplace glass, use a glass cleaner sparingly on a cloth, then wipe dry. Do not spray directly onto the unit.

General Care:

- Ensure the TV stand is not exposed to direct sunlight or extreme temperature changes, which can cause warping or fading.

- Periodically check all assembly hardware to ensure it remains tight. Retighten as necessary.
- Keep liquids away from the electric fireplace and electronic components.

Troubleshooting

- **Fireplace not turning on:**
  - Ensure the power cord is securely plugged into a functional electrical outlet.
  - Check if the main power switch on the fireplace unit is in the 'ON' position.
  - Verify the remote control batteries are functional and correctly inserted.
- **No heat output from fireplace:**
  - Confirm that the heat setting (750W or 1500W) is selected.
  - Check the temperature setting; ensure it is set higher than the current room temperature.
- **LED lights not working:**
  - Ensure the LED light system is properly connected during assembly.
  - Check the remote control batteries.
- **TV stand unstable:**
  - Verify that all assembly hardware is tightened securely.
  - Ensure the TV stand is placed on a flat, level surface.

Specifications

Brand	Aoxun
Model Number	TM-TSF213
Product Type	Fireplace TV Stand Entertainment Center
Overall Dimensions (Approx.)	79" L x 13.94" D x 22.24" H (for 70-inch TV stand variant)
TV Compatibility	Up to 80 inches (desktop supports up to 130 lbs)
Material	Engineered Wood
Color	White TV Stand with Black Fireplace
Item Weight	Approximately 130 pounds
Fireplace Insert Size	36 inches
Fireplace Heat Settings	750W / 1500W
Fireplace Flame Options	12 colors, 5 brightness levels
LED Light System	12 colors, remote controlled
Product Care	Wipe with Dry Cloth

Warranty and Support

Specific warranty information for the Aoxun Fireplace TV Stand is typically provided with the product packaging or can be obtained directly from the manufacturer. Please refer to the documentation included in your product box for details regarding warranty coverage and terms. For technical assistance, missing parts, or any other inquiries, please contact Aoxun customer support through their official website or the contact information provided in your product documentation. When contacting support, please have your model number (TM-TSF213) and purchase details readily available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question