Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Soundcore A3874

Soundcore AeroFit 2 Open-Ear Headphones User Manual

Brand: Soundcore | Model: A3874

1. Setup Guide

1.1 What's in the Box

- soundcore AeroFit 2 Open-Ear Headphones
- Charging Case
- USB-C Cable

1.2 First Time Connection

To connect your Soundcore AeroFit 2 headphones for the first time, open the charging case. The earbuds will automatically power on and enter Bluetooth pairing mode, indicated by a flashing LED bar on the case. On your device, go to Bluetooth settings and select "soundcore AeroFit 2" from the list. Once connected, the LED bar will stay on for one second before turning off.

Video: How to Reset Your AeroFit 2 (This video also demonstrates the LED bar behavior during pairing).

2. Operating Instructions

2.1 How to Wear

Adjust the ear hooks between four levels to find the most comfortable and secure fit. Gently hook the earbuds onto the upper edge of your ear. LV1 and LV2 are best suited for smaller to medium-sized ears, while LV2 to LV4 are typically more comfortable for medium to larger ears. Try shaking your head or nodding to ensure the earbuds are securely in place. The position that best suits the size of your ears and your preferences offers the best comfort, stability, and sound quality.

Video: How to use soundcore AeroFit 2



Image: Adjustable Ear Hooks to Fit Different Ears. Soundcore's innovative 4-level adjustable ear hooks ensure a comfortable fit tailored to over 99% of ear shapes and sizes.

2.2 Touch Controls

The earbuds feature touch controls for managing music and calls. When wearing both earbuds, double-tap the right earbud to play or pause audio and double-tap the left one to skip to the next song. Double-tap on either earbud to answer calls. Tap and hold either earbud for 2 seconds to reject or end calls. These controls can be customized in the soundcore app.

Video: Soundcore AeroFit 2 by Anker, over ear ear pods COMFY (Demonstrates touch controls)

2.3 Soundcore App Controls

Personalize your listening experience with the soundcore app. You can customize touch controls, enable 3D Sound or Gaming Mode, and more. To set your preferred sound effects, go to Home Page > Sound Effects. To adjust the left and right sound balance, go to Settings > Volume Balance and drag the slider left or right. To set the automatic shutdown time, go to Settings > Auto Power Off. This feature only works when the earbuds are out of the case and not connected to any device. To look for your earbuds, enable "Find Device" in "Settings." Within a certain range, the earbuds will play a sound to help you locate them.



Image: All-Day Comfort, Open-Ear Listening. AeroFit 2 open-ear headphones offer all-day comfort with soft materials and a non-invasive, double-curved design, keeping you attuned to the world while enjoying music.

2.4 AI Translation

The AeroFit 2 supports AI Translation for 100 languages with real-time response and high accuracy. First, download the latest version of the soundcore app from the App Store. Once the download is complete, open the app, connect your earbuds and enable the AI translation feature. Please keep your earbuds on at all times while using AI Translation. In face-to-face translation mode, start by selecting the languages you need to translate. Tap the bottom right button or gently tap the touch-control area on your earbuds to speak. The translated speech will play through your phone. When the other person needs to speak, tap the bottom left button. Once they're done, the translated speech will automatically play through your earbuds. If you don't want to hear the translation, go to "More Settings" in the top right corner and turn it off. To use real-time translation, tap the "Real-Time Translation" button at the bottom left. Once you're in, select the languages you need to translate. Then, tap the microphone icon below to start translating. You'll hear the translated speech through your earbuds.

Video: How to Use AI Translation on the soundcore App

2.5 Sound Quality and Features

Enjoy deep bass, clear mids, and vivid treble, fueled by 20mm × 11.5mm racetrack drivers and BassTurbo acoustics. Adjustable ear hooks bring the sound closer, doubling the bass output of non-adjustable buds. A maximum boost of 7.5dB delivers richer, more powerful beats. It also supports Bluetooth 5.4 and the LDAC codec for stable, Hi-Res audio transmission. Equipped with 4 beam-forming mics and an AI algorithm, these earbuds pick up your voice while filtering out noise, so you're heard in calls even in a busy street.



Image: Vibrant Bass. Features 20mm x 11.5mm Racetrack Diaphragm and BassTurbo Acoustic Structure.

3. Maintenance

3.1 How to Clean Your AeroFit 2

Use a soft, dry cloth to wipe the earbuds clean, and use a cotton swab to clean the charging port. Then, gently clean

the audio output ports with a small brush. Next, moisten a lint-free cloth with a small amount of alcohol and carefully wipe the charging contacts in the charging case.

Video: How to Clean Your AeroFit 2

4. Troubleshooting

4.1 Resetting AeroFit 2

If you encounter connection or functionality issues, try resetting AeroFit 2. Please note that this will erase all pairing records. To reset, return the earbuds to the case and leave the case open. Press the button next to the charging port for 3 seconds. When the LED bar starts flashing, they are ready to pair. Press the button on the case for 10 seconds. By the third second, the LED bar will start flashing. By the tenth second, the LED bar will flash three times rapidly, indicating a successful reset.

Video: How to Reset Your AeroFit 2

4.2 Charging and Connectivity Issues

If one earbud fails to connect or charge, follow these steps: Place each earbud back into the charging case, one at a time. The case light will turn on when the earbud is correctly positioned. If the light doesn't turn on, gently clean the charging contacts on the earbuds and the case with a dust-free cloth dampened with a small amount of alcohol. Then, return the earbuds to the case, close the lid, and reopen it to reconnect. If the light turns on, open the case to check the battery level. A solid white light indicates a full charge. A red light means the case needs charging—charge it for 10 minutes, then try reconnecting. If the issue persists, reset the earbuds as described above.

Video: How to Fix AeroFit 2 Charging and Connectivity Issues

4.3 Battery Indicators

When you open the charging case, the LED bar will indicate the remaining battery level. If the battery is below 20%, the middle of the LED bar will be solid red for 5 seconds before turning off. If the battery is above 20%, the LED bar will display the battery level: a longer bar indicates a higher battery level. When you connect the charging case to a power source, the LED bar will indicate the charging status. If the battery is below 20%, the LED bar will remain solid red. If the battery is above 20%, the LED bar will flash continuously with a longer bar indicating more charge. Once the case is fully charged, the LED bar will stay on for 10 seconds before turning off.



Image: Wireless Charging for Endless Play. Shows the charging case on a wireless charger with battery life indicators.

5. Specifications

Feature	Specification
Model Name	soundcore AeroFit 2

Connectivity Technology	Wireless (Bluetooth 5.4)
Audio Driver Type	Dynamic Driver (20mm × 11.5mm Racetrack)
Playtime (Single Charge)	10 Hours
Playtime (with Charging Case)	42 Hours
Charging Time	1 Hour (Earbuds) / 2 Hours (Case)
Water Resistance Level	IP55 (Sweat, Dust, and Splash-Proof)
Control Type	Touch Control
Weight	3 ounces (85 Grams)
Dimensions	2.24 x 1.54 x 0.56 inches

6. Warranty & Support

For detailed warranty information and further support, please refer to the official documentation provided with your product or visit the Soundcore website.

- User Manual (PDF): Download Here
- Troubleshooting Guide (PDF): Download Here
- Visit the Soundcore Store: Soundcore Official Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DCZB9S97

More documents and user manuals: **https://manuals.plus/**