Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Slevoo SW-01

Slevoo 2-in-1 Baby Jumper Swing and Toddler Swing Instruction Manual

Model: SW-01

Introduction

Thank you for choosing the Slevoo 2-in-1 Baby Jumper Swing and Toddler Swing. This versatile product is designed to provide engaging activity and entertainment for children from 6 months to 6 years old, functioning as both a baby jumper and a toddler swing. It features a portable, quick-fold stand suitable for both indoor and outdoor use. Please read this manual thoroughly before assembly and use to ensure safe operation and proper maintenance.



Image: Slevoo 2-in-1 Baby Jumper Swing banner, highlighting its dual functionality for infants and toddlers.

Safety Information

Your child's safety is paramount. Always adhere to the following safety guidelines:

- **Age and Weight Limits:** Suitable for children aged 6 months to 6 years, with a maximum weight recommendation of 50 pounds. Do not exceed these limits.
- **Adult Supervision:** Never leave a child unattended in the jumper or swing. Constant adult supervision is required.
- **Secure Setup:** Ensure the stand is fully assembled and all connections are secure before placing a child in the jumper

or swing. For outdoor use, utilize the provided ground stakes for enhanced stability.

- **Harness Use:** Always secure your child with the safety harness and buckle. Ensure straps are snug but not too tight.
- **Inspection:** Regularly inspect the product for any signs of wear, damage, or loose parts. Discontinue use immediately if any damage is found.
- **Clear Area:** Ensure there is ample clear space around the jumper/swing to prevent collisions with furniture, walls, or other objects.
- **Proper Use:** Use the product only for its intended purpose as a baby jumper or toddler swing.



Image: Detailed view of the swing seat, highlighting the safety belt, detachable handrail, and height adjustment feature for secure and adaptable use.

Package Contents

Verify that all components are present before beginning assembly:

- Baby Jumper x 1

- Foldable Stand x 1
- Baby Swing x 1
- Ground Nails x 4



Image: Visual representation of all items included in the package: the baby jumper, foldable stand, baby swing, and four ground nails.

Setup and Assembly

The Slevoo 2-in-1 Jumper Swing features a tool-free, quick-fold stand for easy setup. Follow these steps for assembly:

1. **Unfold the Stand:** Carefully unfold the metal stand until it locks into its open position. Ensure all joints are securely engaged.
2. **Attach Jumper or Swing:** Depending on the desired mode, attach either the baby jumper or the baby swing to the hooks on the top bar of the stand. Ensure the carabiners are fully closed and secure.
3. **Adjust Height:** Adjust the strap length to the appropriate height for your child. For the jumper, ensure your child's feet can touch the ground comfortably. For the swing, ensure adequate clearance from the ground.
4. **Outdoor Stability (Optional):** If using outdoors, insert the four ground nails through the designated holes in the stand's base into the ground for added stability.

Your browser does not support the video tag.

Video: Demonstrates the installation process for the adjustable strap on the baby jumper. This video is provided by the seller, Topire.



Image: Diagram illustrating key features of the stand, including heavy-duty metal pipes, the foldable design, adjustable seat height mechanism, and ground nails for outdoor stability.

Operating Instructions

Jumper Mode (6-12 months)

For infants learning to stand and bounce, the jumper mode provides a safe and stimulating environment. Ensure the jumper harness is securely fastened around your baby, and their feet can comfortably touch the ground to allow for bouncing motion.

Swing Mode (6-36 months for bucket seat, 4-6 years for flat seat)

The swing mode offers gentle swaying motion for relaxation and play. The product includes a bucket-style swing seat for younger toddlers (6-36 months) and can be adapted for older children (4-6 years) with a flat seat configuration (if applicable, or by adjusting the bucket seat for older children as shown in images). Always ensure the safety belt is fastened and the child is seated properly.



Image: Illustration of the two primary modes: a baby enjoying the jumper mode indoors and a toddler using the swing mode outdoors.



Image: Visual guide demonstrating the product's adaptability for three age ranges: 6-12 months in jumper mode, 6-36 months in bucket swing mode, and 4-6 years in a more open swing configuration.



Image: A child enjoying the swing outdoors, emphasizing the product's suitability for outdoor use and the inclusion of ground nails for stability.

Maintenance

- **Cleaning:** The fabric components can be spot cleaned with mild soap and water. Allow to air dry completely. The metal frame can be wiped clean with a damp cloth.
- **Storage:** When not in use, the stand can be quickly folded for compact storage. Store in a dry place away from direct sunlight.
- **Regular Checks:** Periodically check all bolts, screws, and connections to ensure they are tight and secure. Inspect ropes and fabric for any signs of fraying or damage.



Image: The Slevoo swing stand in its folded state, demonstrating its space-saving design for easy storage.

Troubleshooting

Problem	Solution
Stand feels unstable.	Ensure all frame connections are fully engaged and tightened. For outdoor use, deploy the ground nails. Verify the stand is on a flat, level surface.
Child's feet not touching ground in jumper mode.	Adjust the jumper's strap length to lower the child. Ensure the child meets the minimum height/age requirements for jumper use.
Difficulty folding the stand.	Ensure no components are obstructing the folding mechanism. Apply gentle, even pressure. Refer to assembly instructions for folding points.

Specifications

- **Brand:** Slevoo
- **Model Number:** SW-01
- **Color:** Blue
- **Material:** Metal (frame), Cotton (seat)
- **Product Dimensions (D x W x H):** 35" x 52" x 56"
- **Item Weight:** 22 pounds
- **Recommended Age:** 0 - 6 years (with appropriate mode and supervision)
- **Maximum Weight Recommendation:** 50 pounds
- **Finish Type:** Powder Coated



Image: Diagram detailing the package contents and the overall dimensions of the assembled Slevoo swing stand.

Warranty and Support

For warranty information, product support, or to purchase replacement parts, please contact Slevoo customer service through the retailer where the product was purchased or visit the official Slevoo website. Please have your model number (SW-01) and purchase date available when contacting support.

Manufacturer: Slevoo

© 2026 Slevoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DCZCD3LP

More documents and user manuals: **https://manuals.plus/**