Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ETTFGUH B0DD6SZNLP

ETTFGUH Electric Space Heater User Manual

Brand: ETTFGUH | Model: B0DD6SZNLP

Introduction

Thank you for choosing the ETTFGUH Electric Space Heater. This ceramic tower heater is designed to provide efficient and comfortable heating for your indoor spaces, featuring advanced safety mechanisms and convenient controls. Please read this manual thoroughly before operation to ensure safe and optimal performance.

Important Safety Information

To reduce the risk of fire, electric shock, or injury, always follow these basic precautions:

- Read all instructions before using this heater.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and keep them away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Always unplug heater when not in use.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not use outdoors.
- This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to off, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable

vapors or liquids are used or stored.

- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This heater includes an overheat protection system and a tip-over switch for enhanced safety.

Product Features

- **Efficient PTC Ceramic Heating:** 1500W high-efficiency PTC heating element for rapid and even heat distribution.
- **Wide Oscillation:** 60° wide oscillation ensures warmth spreads across the room.
- **3D Flame Effect:** Simulated flame on the bottom for a cozy ambiance, can be operated independently.
- **Multiple Heating Modes:** 1500W (High), 1000W (Low), Thermostat Mode (50-95°F), and Fan Mode.
- **Convenient Controls:** Top touch panel and full-function remote control for easy operation.
- **Digital Display:** Front display shows current settings and temperature.
- **Safety Features:** Built-in overheat protection and 45° tip-over protection with automatic shut-off. ETL certified.
- **Timer Function:** 12-hour timer for scheduled operation.



Image: A visual comparison illustrating the wider heating range of the ETTFGUH 27-inch heater.

Package Contents

- Electric Space Heater (1 unit)
- Remote Control (1 unit)
- User Manual (This document)

Setup

1. **Unpacking:** Carefully remove the heater from its packaging. Retain packaging for future storage if needed.
2. **Placement:** Place the heater on a firm, level surface. Ensure it is at least 3 feet (0.9 m) away from walls, furniture, and other combustible materials. Do not place on soft surfaces like carpets with deep pile, as this may block air intake.
3. **Power Connection:** Plug the heater directly into a 120V AC, 60Hz wall outlet. Do not use extension cords or power

strips.



Image: The ETTFGUH Electric Space Heater with its remote control, showing the heat output and 3D flame effect.

Operating Instructions

Control Panel & Remote Control

The heater can be operated using the touch control panel on top or the included remote control. The functions are identical.



Image: Close-up of the heater's top control panel with various function buttons and a digital display.

Power On/Off

- Press the **Power Button** to turn the heater ON or OFF. The digital display will show the current room temperature when on.

Mode Selection

Press the **Mode Button** to cycle through the following modes:

- **High Heat (1500W):** Provides maximum heating power.
- **Low Heat (1000W):** Provides moderate heating power.
- **Thermostat Mode:** Allows you to set a desired temperature between 50-95°F. The heater will automatically adjust between high/low heat or turn off to maintain the set temperature.
- **Fan Mode:** Operates as a fan without heat, circulating air.

Temperature Adjustment (Thermostat Mode)

- In Thermostat Mode, use the **Temperature Up** and **Temperature Down** buttons to set your desired temperature.

Oscillation Function

- Press the **Oscillation Button** to activate or deactivate the 60° oscillation feature.

3D Flame Effect

- Press the **Flame Button** to turn the simulated 3D flame effect ON or OFF. This can be used independently of the heating function.

Timer Function

- Press the **Timer Button** to set the auto-off timer from 1 to 12 hours. Each press increases the timer by one hour.

Your browser does not support the video tag.

Video: An official product video demonstrating the ETTFGUH Tower Space Heater with its 3D Flame effect and various operating modes.

Maintenance

Cleaning

- Always unplug the heater from the power outlet and allow it to cool completely before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces of the heater. Do not use harsh cleaners or abrasive materials.
- Gently vacuum the air intake and exhaust grilles to remove dust and lint.
- Never immerse the heater in water or allow water to drip into the interior of the heater.

Storage

- Store the heater in a cool, dry location when not in use.
- It is recommended to store the heater in its original packaging to protect it from dust and damage.

Troubleshooting

Problem	Possible Cause	Solution
Heater does not turn on.	Not plugged in; Power outlet not working; Tip-over switch activated; Overheat protection activated.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker. Place the heater on a firm, level surface. Allow the heater to cool down for 30 minutes, then restart.
No heat output.	Heater is in Fan Mode; Thermostat set too low.	Switch to High Heat, Low Heat, or Thermostat Mode. Increase the set temperature in Thermostat Mode.
Oscillation not working.	Oscillation function is off.	Press the Oscillation Button to activate.
Flame effect not working.	Flame effect is off.	Press the Flame Button to activate.

Specifications

Feature	Detail
Brand	ETTFGUH
Model	B0DD6SZNLP
Power Output	1500W / 1000W
Voltage	120V AC, 60Hz
Heating Element	PTC Ceramic
Oscillation Angle	60°
Thermostat Range	50-95°F
Dimensions (D x W x H)	7"D x 7"W x 26"H
Weight	4.9 pounds
Safety Features	Overheat Protection, Tip-over Protection, ETL Certified
Indoor/Outdoor Usage	Indoor Use Only

Warranty & Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official ETTFGUH website. Keep your purchase receipt for warranty claims.

© 2025 ETTFGUH. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DCZD4T6J

More documents and user manuals: **https://manuals.plus/**