

[Manuals.plus](#) /

› [GlasFlength](#) /

› GlasFlength Computer Desk Instruction Manual

GlasFlength DDP-HX-D-F01V3-31IN-BK

GlasFlength Computer Desk Instruction Manual

Model: DDP-HX-D-F01V3-31IN-BK

Brand: GlasFlength

1. INTRODUCTION

Thank you for choosing the GlasFlength Computer Desk. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new desk. Please read this manual thoroughly before assembly and use.

Important Safety Information

WARNING: Always assemble the desk according to the provided instructions. Be cautious when placing heavy items on the desk to avoid exceeding its weight limit of 176 lbs. Ensure the desk is properly secured to the floor to prevent tipping or movement, especially when in use. Keep the area around the desk clear of obstacles to prevent tripping hazards.



Figure 1.1: Overview of the GlasFlength Computer Desk, showcasing its compact design and integrated storage solutions.

2. PACKAGE CONTENTS

Before beginning assembly, please verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Desktop Panel (1)
- Desk Legs/Frame Components (2 main frames, crossbars)
- Storage Bag (1)
- Headphone Hook (1)
- Assembly Hardware (Screws, bolts, Allen wrench)
- Instruction Manual (This document)

3. ASSEMBLY INSTRUCTIONS

Assembly of the GlasFlength Computer Desk is designed to be straightforward and typically takes about 15 minutes. No additional tools are required beyond what is provided.

1. **Step 1: Assemble the Desk Frame.**

Begin by connecting the main desk leg frames using the provided crossbars and hardware. Ensure all connections are secure but do not fully tighten screws until all parts are aligned.



Figure 3.1: Illustration of the robust frame construction, highlighting the reinforced X-bar for stability.

2. **Step 2: Attach the Desktop Panel.**

Carefully place the desktop panel onto the assembled frame. Align the pre-drilled holes on the desktop with the holes on the frame. Secure the desktop using the remaining hardware. Once all screws are in place, fully tighten all connections.

3. **Step 3: Install the Storage Bag.**

Locate the attachment points on the side of the desk frame for the storage bag. Hook or slide the storage bag into position as indicated in the diagram. This bag is designed to hold books, notebooks, or other office essentials.



Figure 3.2: The convenient side-mounted storage bag, providing additional space for organization.

4. **Step 4: Attach the Headphone Hook.**

Attach the detachable headphone hook to the designated slot on the opposite side of the desk frame. This hook provides a convenient spot for hanging headphones, bags, or other items.



STURDY IRON HOOK

Extra storage space for hanging headphone or bag

Figure 3.3: The detachable headphone hook, offering extra storage space.

Your GlasFlength Computer Desk is now assembled and ready for use.

4. OPERATING AND FEATURES

The GlasFlength Computer Desk is designed for versatility and functionality in various settings, including home offices, studies, and writing areas.

Durable & Functional Desktop

The desk features a premium particle board surface that is scratch-resistant, anti-collision, and waterproof, safeguarding it against daily wear and tear. Its spacious design accommodates a range of items including computers, notebooks, files, pens, and office supplies, offering a versatile and practical work area.

SPACIOUS & WATERPROOF DESKTOP



Eco-friendly



Waterproof



Anti-scratch



Figure 4.1: The desktop surface is designed to be waterproof and scratch-resistant for long-lasting use.

Convenient Storage Options

Enhancing organization, a side-mounted storage bag offers space for books or office essentials, streamlining desktop clutter. Additionally, a detachable hook on the opposite side provides a handy spot to hang headphones or bags, catering to the needs of students, professionals, and individuals engaged in various work activities.

Reliable Construction

This workstation boasts a robust 1.18-inch tube frame with a diagonal brace, providing exceptional strength and stability that surpasses standard office desks. The solid metal build ensures durability, while floor-protecting leg pads reduce noise and prevent scratches, creating a steadfast and enduring workspace.



Figure 4.2: The desk provides a comfortable and functional workspace for various activities.

5. CARE AND MAINTENANCE

To ensure the longevity and appearance of your GlasFlength Computer Desk, please follow these simple care instructions:

- **Cleaning:** Wipe the desk surface and frame with a dry cloth. Avoid using harsh chemicals or abrasive cleaners, which may damage the finish.
- **Spills:** Although the desktop is waterproof, it is recommended to wipe up any spills immediately to prevent potential damage or staining.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 176 lbs (80 kg) on the desktop.
- **Stability:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary to maintain stability.
- **Environment:** Avoid exposing the desk to extreme temperatures or direct sunlight for prolonged periods, as this may cause warping or discoloration.

6. TROUBLESHOOTING

If you encounter any issues with your GlasFlength Computer Desk, please refer to the common solutions below. If the problem persists, contact customer support.

Problem	Possible Cause	Solution
Desk is wobbly or unstable.	Loose screws or uneven floor.	Ensure all assembly screws are fully tightened. Adjust the floor-protecting leg pads if your floor is uneven.
Missing parts during assembly.	Packaging error.	Double-check all packaging materials. If parts are still missing, contact GlasFlength customer support with your purchase details.
Desktop surface appears scratched or damaged.	Improper handling or sharp objects.	While the surface is scratch-resistant, extreme force or sharp objects can cause damage. For minor scratches, consider furniture repair kits. For significant damage, contact support.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	GlasFlength
Model Number	DDP-HX-D-F01V3-31IN-BK
Product Dimensions (D x W x H)	34"D x 23"W x 3"H
Color	30 Inches Black
Base Material	Metal (Frame), Wood (Leg pads)
Top Material Type	Wood (Particle Board)
Finish Type	Polished
Special Features	Ergonomic, Lightweight, Compact, Side-mounted storage bag, Detachable headphone hook
Recommended Uses	Drafting, Working, Study, Writing, Gaming
Mounting Type	Tabletop
Included Components	Headphone Hook, Storage Bag
Required Assembly	Yes
Weight Capacity	176 lbs (80 kg)
Item Weight	20 Pounds (9.07 kg)

Note: Product dimensions (D x W x H) 34"D x 23"W x 3"H typically refer to packaging dimensions. The assembled desk is approximately 31 inches wide as per the product title.

8. WARRANTY AND CUSTOMER SUPPORT

GlasFlength is committed to providing high-quality products and excellent customer service. While specific warranty details may vary by region and retailer, we stand behind the quality of our computer desks.

If you have any questions, require assistance with assembly, or encounter any issues not covered in this manual, please do not hesitate to contact our customer support team. Please have your model number (DDP-HX-D-F01V3-31IN-BK) and purchase information ready when contacting support.

For the most up-to-date contact information and support resources, please visit the official GlasFlength store or website:

[Visit the GlasFlength Store on Amazon](#)

© 2025 GlasFlength. All rights reserved.
This manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question