

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [KRPTQJoo](#) /

› [Replacement Remote Control for Noma CL Midea RG15A\(B\)/E Windows Air Conditioner User Manual](#)

KRPTQJoo RG15A(B)/E Replacement Remote Control

User Manual

REPLACEMENT REMOTE CONTROL FOR NOMA CL MIDEA RG15A(B)/E WINDOWS AIR CONDITIONER

Model: RG15A(B)/E Replacement Remote Control | Brand: KRPTQJoo

Introduction

This manual provides essential information for the proper use and maintenance of your new replacement remote control. This remote is designed as a spare or backup unit for specific Noma CL Midea RG15A(B)/E Windows Air Conditioner models. Please read this manual thoroughly before use.

Important Note: This remote control is a replacement unit and is only guaranteed to work with the models specified in the product listing. If your original remote control differs in appearance or model number, this replacement may not be compatible or some functions may not operate as expected. Always refer to your air conditioner's original manual for specific feature support.

Package Contents

- 1 x IR Remote Control

Note: Batteries and a detailed user manual for the air conditioner are not included.

Setup

Battery Installation

The remote control requires two (2) AAA batteries for operation. Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Rear view of the remote control, highlighting the circular battery compartment cover.

Initial Use

This replacement remote control is designed for immediate use with compatible air conditioner models. No pairing or programming is required. Once batteries are installed, point the remote towards your air conditioner and begin operation.

Operating Instructions

The remote control features an ergonomic design for comfortable handling. Below is a general guide to the buttons and their typical functions. Please note that specific functions depend on your air conditioner model's capabilities.



Image: Front view of the remote control, displaying its buttons.

- **Power Button (Orange Circle with Line):** Turns the air conditioner ON or OFF.
- **MODE Button:** Cycles through various operating modes (e.g., Cool, Fan, Dry, Heat, Auto).
- **Temperature Up/Down Arrows (Triangles):** Adjusts the desired temperature setting.

- **Fan Speed Button (Fan Icon):** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **Timer Button (Clock Icon):** Sets a timer for the air conditioner to turn ON or OFF.
- **Sleep/Night Mode Button (Moon/Star Icon):** Activates a quiet, energy-saving mode for nighttime operation.
- **Swing Button (Waves Icon):** Controls the louver swing function for air direction.

If your air conditioner does not support a particular feature, the corresponding button on the remote will have no function. Always consult your air conditioner's original user manual for detailed information on its features and how they interact with a remote control.

Maintenance

Battery Replacement

Replace batteries when the remote control's range decreases or it stops responding. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these can damage the remote's surface or internal components.

Troubleshooting

If you experience issues with your remote control, please refer to the following common problems and solutions:

- **Remote Control Not Responding:**

- Check if the batteries are installed correctly with the correct polarity.
- Replace old batteries with new ones.
- Ensure there are no obstructions between the remote control and the air conditioner's infrared receiver.
- Make sure you are within the effective operating range of the air conditioner.

- **Some Buttons Have No Function:**

This is normal if your specific air conditioner model does not support the feature associated with that button. For example, if your AC unit does not have a "Swing" function, pressing the Swing button on the remote will have no effect. Refer to your air conditioner's original manual to confirm supported features.

- **Remote Control Not Compatible with My Air Conditioner:**

This remote is designed for specific models. If your air conditioner's model number is not listed as compatible, or if your original remote looks significantly different, this replacement may not work. The internal codes can vary even if remotes appear similar. Please refer to the compatibility guide below:

How to buy a remote control	
The original/old remote control is still exists but it's broken and doesn't work	If you don't have the model number or don't know the model number, send the front and back picture of the remote control to us, there will be a professional technician to match the right remote control for you!
The old remote control is missing, only the brand of the unit	Provide a clear picture of the brand and model of the machine or the old remote control in the manual and the model & manufacturer of the machine, send it to us.
Still have the original remote, but would like to get a spare one	Send us a Clear picture of the old remote control, front & back, as well as the complete brand and model number of the machine.
<p>Important Note : Our remote is Replacement, Only fits the models we list.</p> <p>In some cases, even though the remotes look the same, the codes inside are different. The model number suffixes are not the same, and the suitable remote control is also different.</p> <p>If you're not sure or our remote doesn't work ,Please provide us with as much information as possible in order to find the right product for you or to identify and solve a problem.</p>	

Image: A guide table titled "How to buy a remote control," detailing scenarios for purchasing a replacement based on the status of the original remote.

If you are unsure about compatibility or if the remote does not work after troubleshooting, please contact the seller for assistance.

Specifications

Product Type	Replacement IR Remote Control
Compatible Devices	Noma CL Midea RG15A(B)/E Windows Air Conditioner (specific models)
Power Source	2 x AAA Batteries (not included)
Color	White
Special Features	Ergonomic design, No pairing/programming required
Manufacturer	HKDRJoo
Country of Origin	China

Support

For any questions, concerns, or issues regarding your replacement remote control, please contact the seller directly through the platform where you made your purchase. The seller aims to respond to inquiries within 12 hours and is committed to assisting you.

Please provide as much detail as possible, including your air conditioner's model number and pictures of your original remote (if available), to help facilitate a quick and accurate resolution.



© 2024 KRPTQJoo. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.