



[Manuals.plus](#) /

- › [DELSEY PARIS](#) /
- › DELSEY PARIS Chatelet Air 2.0 Hardside Luggage Trunk User Manual

DELSEY PARIS 40167681819

DELSEY PARIS Chatelet Air 2.0 Hardside Luggage Trunk User Manual

Model: 40167681819

INTRODUCTION

Welcome to the user manual for your DELSEY PARIS Chatelet Air 2.0 Hardside Luggage Trunk. Named after the famous central district of Paris, this timeless and elegant spinner luggage offers leather-like accents and a deluxe interior. It is crafted from virgin polycarbonate, engineered to meet the highest standards for extreme temperature and impact resistance. This manual provides essential information for the setup, operation, maintenance, and troubleshooting of your luggage, ensuring a seamless travel experience.



Figure 1: Front view of the Chatelet Air 2.0 Hardside Luggage Trunk.

SETUP

1. Initial Inspection

Upon receiving your luggage, carefully inspect it for any signs of damage during transit. Ensure all zippers, handles, and wheels are functioning correctly.

2. Setting the TSA Combination Lock

Your Chatelet Air 2.0 luggage is equipped with a recessed 3-dial TSA-approved combination lock for enhanced security. To set your personal combination:

1. The lock is preset to 0-0-0. Locate the small reset button (usually a tiny hole) next to the dials.

2. Use a pen or a pointed object to press and hold the reset button.
3. While holding the reset button, set your desired 3-digit combination by turning the dials.
4. Release the reset button. Your new combination is now set. Remember your combination as DELSEY PARIS cannot open your luggage if you forget it.



Figure 2: Detail of the TSA combination lock and SECURITECH zip.

OPERATING

1. Packing Your Luggage

The deluxe interior of your Chatelet Air 2.0 offers ample space and organization. Utilize the mesh zippered pockets for smaller items and the included laundry and shoe bags to keep your belongings tidy and separate. The internal compression straps help secure your packed items, preventing shifting during transit.



Figure 3: Interior organization with mesh pockets and straps.

2. Using the Spinner Wheels

Your luggage features dual-density, double-spinner wheels designed for multi-directional rolling with zero weight on your hand. This allows for effortless maneuverability through airports and other travel environments. Ensure the wheels are free of debris for optimal performance.



Figure 4: Detail of the smooth-rolling spinner wheels.

3. Retractable Handle and Carrying Handles

The ergonomical handle extends and retracts smoothly for easy maneuverability. Additionally, soft-grip top and side carrying handles are provided for convenient lifting and carrying, especially when placing the luggage in overhead compartments or on baggage carousels.



Figure 5: Ergonomical retractable handle.

MAINTENANCE

1. Cleaning Instructions

- **Exterior:** Wipe the polycarbonate shell with a soft, damp cloth and mild soap. Avoid abrasive cleaners that may scratch the surface.
- **Interior:** The lining is coated with SILVADUR technology for effective odor control. For cleaning, wipe with a damp cloth. Do not machine wash.
- **Faux Leather Accents:** Clean gently with a soft, dry cloth. Avoid excessive moisture.

2. Storage

Store your luggage in a cool, dry place away from direct sunlight when not in use. Ensure it is empty and clean before storing to prevent odors or mildew.

TROUBLESHOOTING

- **Stuck Retractable Handle:** Ensure no items inside the luggage are obstructing the handle mechanism. Gently pull and push the handle to dislodge any obstructions.
- **Stiff Wheels:** Check for any debris (hair, lint, dirt) caught in the wheel axles. Clean the wheels thoroughly. If the issue persists, a small amount of silicone-based lubricant can be applied to the axles.
- **Lock Not Opening:** Double-check your combination. If you have forgotten it, contact DELSEY PARIS customer support for assistance. Do not attempt to force the lock, as this may damage it.
- **Zipper Issues:** The patented SECURITECH zip is designed to be highly resistant. If a zipper becomes stiff, apply a small amount of zipper lubricant or wax. Avoid overpacking, which can strain the zippers.

SPECIFICATIONS

Feature	Detail
Model Number	40167681819
Product Dimensions	28.75 x 16.5 x 14 inches (includes handles & wheels)
Item Weight	10.9 pounds
Capacity	91 Liters
Shell Material	100% Virgin Polycarbonate (textured basketweave)
Wheels	Dual Density, Double-Spinner Wheels
Lock Type	Recessed 3-dial TSA Approved Combination Lock
Zipper System	Patented SECURITECH zip
Interior Lining	SILVADUR Technology coated for odor control
Included Accessories	Laundry bag, shoe bag

WARRANTY & SUPPORT

DELSEY PARIS products are designed for durability and come with a global warranty. For specific warranty details and to register your product, please visit the official DELSEY PARIS website or contact their customer support. Keep your purchase receipt as proof of purchase for warranty claims.

For further assistance or inquiries, please refer to the contact information provided on the DELSEY PARIS official website.