

## BoxWave ClearTouch Crystal Privacy

# BoxWave ClearTouch Crystal Privacy Screen Protector for Energizer E288s User Manual

Model: ClearTouch Crystal Privacy

## INTRODUCTION

This manual provides instructions for the installation, operation, and maintenance of your BoxWave ClearTouch Crystal Privacy screen protector, designed specifically for the Energizer E288s. This screen protector offers privacy protection and safeguards your device's screen from scratches and cracks.

## PRODUCT FEATURES

- **Privacy Protection:**  
The screen protector changes its properties based on the viewing angle. When viewed straight on, the screen remains clear. From angles of 25 degrees or more, the view is obstructed to ensure privacy.
- **Crystal Clear Display:** Provides 99% visibility without blurring or distorting your screen when viewed directly.
- **Durable Material:**  
Made from a strong and flexible material that guards against scratches and cracks without being brittle like glass.
- **Precise Fit:** Designed to fit the Energizer E288s specifically, ensuring full accessibility to all ports and buttons.
- **Easy Installation:**  
Features a glueless adhesive for automatic clinging to the screen after proper cleaning and alignment.



# ClearTouch® CRYSTAL Privacy



## COLOR BRILLIANCE

High-quality optical film that optimizes color rendition.



## CLARITY

Your vibrant screens don't deserve blur or bland. 99% transparency means perfect clarity. No loss of color. No loss of resolution.



## PRECISION

Precision cut. Precision Accuracy. Cut exactly for your device for increased touchpad accuracy and recognition.



## REUSABILITY

Cleartouch® comes equipped with installation forgiveness. Reuse and reinstall as needed.





Image: Packaging of the BoxWave ClearTouch Crystal Privacy screen protector, highlighting features like color brilliance, clarity, precision, and reusability. A diagram shows the screen protector on a laptop screen and a close-up of the film.



Image: A smartphone screen demonstrating anti-spy privacy protection. The screen is clear when viewed from 0 degrees (directly in front) but becomes obscured at 30 and 45-degree angles, preventing side viewing.

# High Definition Clarity

Provides 99% visual transparency that preserves crystal clear optical clarity with vibrant colors



Image: A visual representation of the screen protector's high definition clarity, showing a clear rectangular overlay on a vibrant yellow field under a blue sky, indicating 99% visual transparency.

# Scratch-Resistant

Helps protect your screen from damaging scratches and scrapes.




Image: A demonstration of the screen protector's scratch-resistant properties, showing a knife and a key near a screen, illustrating how the protector helps prevent damage from scratches and scrapes.

## SETUP AND INSTALLATION

Proper installation is crucial for optimal performance of your ClearTouch Crystal Privacy screen protector. Follow these steps carefully:

1. **Prepare Your Workspace:** Choose a clean, dust-free environment to prevent particles from getting trapped under the protector.
2. **Clean the Device Screen:** Use the included microfiber cloth to thoroughly clean the Energizer E288s screen. Ensure there are no smudges, dust, or fingerprints. A lint-free cloth can also be used.
3. **Align the Screen Protector:**  
Carefully align the ClearTouch Crystal Privacy screen protector with your device's screen. Pay attention to the edges, cutouts for speakers, camera, and buttons to ensure a perfect fit.
4. **Remove the Protective Layer:** Once aligned, gently peel off the bottom protective layer of the screen protector.
5. **Apply to Screen:** As you peel, slowly lower the screen protector onto the device screen. The glueless adhesive will automatically cling to the screen.

## 6. Remove Bubbles:

If any air bubbles appear, gently push them towards the edges of the screen using a soft card (like a credit card wrapped in the microfiber cloth) or your finger.

**Important Note:** The Energizer E288s device is not included with this product.



Image: Contents of the BoxWave ClearTouch Crystal Privacy 2-Pack, showing two screen protectors, a microfiber cleaning cloth, and an applicator card. This image is a general product photo for display purposes; the actual product is tailored specifically to your device.

## OPERATING INSTRUCTIONS

Once installed, the ClearTouch Crystal Privacy screen protector operates automatically to provide privacy and protection.

### Privacy Functionality

The primary function of this screen protector is to safeguard your visual privacy.

- **Direct View:**

When you view your Energizer E288s screen directly from the front, the ClearTouch Crystal Privacy allows for 99% clear visibility, ensuring your display's brilliance and color rendition are maintained.

- **Side View:** For anyone attempting to view your screen from an angle of 25 degrees or more (from either side), the screen protector will automatically obstruct their view, making the screen appear dark or unreadable to them.

## Screen Protection

The flexible and strong material of the screen protector continuously guards your device's screen against daily wear and tear, including scratches, scuffs, and minor impacts, without compromising touch sensitivity.

## MAINTENANCE AND CARE

---

To ensure the longevity and effectiveness of your screen protector, follow these maintenance guidelines:

- **Cleaning:** Use a soft, lint-free cloth, such as the included microfiber cloth, to gently wipe the surface of the screen protector. For stubborn smudges, slightly dampen the cloth with water or a screen-safe cleaning solution. Avoid harsh chemicals or abrasive materials.
- **Avoid Sharp Objects:**  
While the protector is scratch-resistant, extreme pressure or very sharp objects can still cause damage.
- **Reusability:** The ClearTouch Crystal Privacy is equipped with installation forgiveness, allowing for careful removal and reinstallation if needed, provided the adhesive side remains clean and free of dust.

## TROUBLESHOOTING

---

### Common Issues and Solutions

- **Bubbles After Installation:**  
**Cause:** Dust particles or trapped air during application.  
**Solution:** Gently lift the nearest edge of the screen protector and reapply, carefully pushing out air bubbles with a soft card or finger as you go. Ensure the screen is completely clean before reapplying.
- **Misalignment:**  
**Cause:** Incorrect positioning during initial application.  
**Solution:** Carefully peel off the screen protector, clean both the device screen and the adhesive side of the protector (if necessary, with a lint roller), and reapply, paying close attention to alignment with edges and cutouts.
- **Reduced Touch Sensitivity:**  
**Cause:** Improper installation or a faulty protector (rare).  
**Solution:** Ensure the protector is fully adhered without air gaps. If the issue persists, contact customer support.
- **Privacy Effect Not Working:**  
**Cause:** Incorrect product type or viewing angle expectation.  
**Solution:** Verify you have the privacy version. The privacy effect is designed to work from side angles (25 degrees and beyond), not directly from the front. Ensure you are testing from the correct angles.

## SPECIFICATIONS

---

Feature	Detail
---------	--------

Feature	Detail
Product Name	ClearTouch Crystal Privacy Screen Protector
Compatibility	Energizer E288s
Material	Flexible Film
Privacy Angle	Obstructs view from 25 degrees and beyond
Transparency (Direct View)	99%
Adhesive Type	Glueless
Item Weight	0.7 ounces
Manufacturer	BoxWave

## WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the BoxWave official website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

### Contact Information:

- [BoxWave Official Website](#)
- Refer to your product packaging for specific customer service contact details.