

Carego Y42 Pro-B

Carego Wireless Ear Buds Y42 Pro-B User Manual

Model: Y42 Pro-B

Brand: Carego

1. INTRODUCTION

Thank you for choosing Carego Wireless Ear Buds Y42 Pro-B. These earbuds are designed to provide a high-quality audio experience with advanced features such as Bluetooth 5.3 connectivity, smart touch controls, and long battery life. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

2. WHAT'S IN THE BOX

- Charging Case
- Eartips (S, M, L sizes)
- User Manual
- USB-C Charging Cable

3. PRODUCT OVERVIEW

The Carego Wireless Ear Buds Y42 Pro-B feature an ergonomic design for comfortable and stable wear, along with an intuitive LED display on the charging case to show battery status.



Image: The Carego Wireless Ear Buds Y42 Pro-B, shown in their charging case. The case features an LED display indicating the battery percentage and individual earbud charging status (L and R).

4. SETUP

4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. The LED display on the case will show the charging progress.

- Insert the earbuds into the charging case.
- Connect the USB-C charging cable to the charging port on the case and to a power source.
- A full charge provides up to 6 hours of music time for the earbuds, and the charging case extends total playtime to up to 40 hours.



Image: An illustration demonstrating the battery life of the Carego earbuds. It highlights 6 hours of music time, 40 hours of total playtime with the charging case, and shows the battery indicator on the case.

Power Your Day

These earbuds have up to 6 hours of listening time with 5 additional charges provided by its pocket-sized charging case.

40 ⚡
Hrs
With charging case

6 🔋
Hrs
On a single charge



Image: A visual representation of the earbuds' power capabilities, showing 40 hours of total playtime with the charging case and 6 hours on a single charge, set against an airplane window background.

4.2 Pairing with Your Device

The earbuds utilize Bluetooth 5.3 for a fast and stable connection.

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for "Y42 Pro-B" in the list of available Bluetooth devices and select it to connect.
4. Once successfully paired, the earbuds will automatically reconnect to the last connected device when you open the charging case.

BLUETOOTH 5.3

ONE-STEP PAIRING

5.0 24Mbit/s
5.3 48Mbit/s



Image: An illustration demonstrating the one-step pairing process with Bluetooth 5.3, showing a smartphone with Bluetooth settings and the earbuds connecting.

5. OPERATING INSTRUCTIONS

5.1 Smart Touch Controls

The Carego Ear Buds feature intuitive touch controls on each earbud for easy management of your audio and calls.

SMART TOUCH CONTROL

Smart control all functions with your finger tips




Image: A diagram illustrating the smart touch controls on the earbuds, showing icons for Play/Pause, Voice Assistant, Answer, Hang up, Reject, Previous Track, Next Track, and Volume +/-.

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap the right earbud.
- **Previous Track:** Double tap the left earbud.
- **Volume Up:** Triple tap the right earbud.
- **Volume Down:** Triple tap the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call or active call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Press and hold either earbud for 3 seconds.

5.2 Audio Quality

Experience immersive sound with 13mm large drivers, delivering a balanced sound profile with rich bass and clear details.

Hi-Fi SOUND QUALITY



Image: An illustration highlighting the Hi-Fi sound quality of the earbuds, showing internal components like the 13mm driver and a visual representation of sound waves and music notes.

5.3 Environmental Noise Cancellation (ENC)

The earbuds feature Environmental Noise Cancellation (ENC) to provide clearer and more intelligible audio during calls, even in noisy environments.

ENVIRONMENTAL NOISE CANCELLATION(ENC)

Noise 
Voice 



Get a clearer and more intelligible audio in noisy environments

Image: An illustration depicting Environmental Noise Cancellation (ENC), showing a person wearing an earbud with sound waves indicating noise reduction and voice clarity.

6. MAINTENANCE

6.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove any earwax or debris from the ear tips and speaker mesh using a small, soft brush or cotton swab.
- Do not use abrasive cleaners or immerse the earbuds or case in water.

6.2 Storage

When not in use, store the earbuds in their charging case to protect them from dust and damage.

6.3 Water Resistance

The earbuds are water resistant. While they can withstand splashes and sweat, they are not designed for submersion in water. Avoid exposing them to excessive moisture or liquids.

COMFORTABLE & STABLE WEAR

Enjoy sports without worrying about your headphones falling off



Image: A depiction of a person running while wearing the earbuds, emphasizing their comfortable and stable fit during physical activity. The image also shows the different ear tip sizes (S, M, L) for optimal fit.

7. TROUBLESHOOTING

- **Earbuds not pairing:** Ensure the earbuds are charged and in the case. Open the case to activate pairing mode. Turn off and on your device's Bluetooth, then try searching again.
- **Only one earbud working:** Place both earbuds back in the charging case, close the lid for a few seconds, then open it again. This often resets the connection. Check if both earbuds are charged.
- **No sound:** Check the volume level on your device and on the earbuds. Ensure the earbuds are properly connected to your device.

- **Charging issues:** Ensure the charging cable is securely connected to both the case and the power source. Check if the charging port is clean and free of debris.
- **Poor sound quality:** Ensure the earbuds are properly seated in your ears and that you are using the correct size ear tips for a good seal. Check for any obstructions in the speaker mesh.

8. SPECIFICATIONS

Model Name	Y42 Pro-B
Connectivity Technology	Wireless
Wireless Communication Technology	Bluetooth 5.3
Bluetooth Range	10 Meters / 33 Feet
Audio Driver Size	13 Millimeters
Battery Life (Earbuds)	6 Hours (single charge)
Total Playtime (with Case)	40 Hours
Charging Time	Approx. 1.5 - 2 hours for full charge (case)
Control Type	Touch Control
Noise Control	Sound Isolation / Environmental Noise Cancellation (ENC)
Water Resistance Level	Water Resistant
Material	Acrylonitrile Butadiene Styrene (ABS)
Item Weight	2.4 ounces
Product Dimensions	2.44 x 0.94 x 1.77 inches

9. WARRANTY AND SUPPORT

Carego provides a 2-year warranty for this product, reflecting our confidence in its quality and durability. If you encounter any issues with your Carego Wireless Ear Buds Y42 Pro-B during this period, please contact our customer support team for assistance.

For further support or to learn more about Carego products, please visit the official Carego Store on Amazon: [Carego Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question