

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [DEVAISE](#) /

> [DEVAISE 5-Drawer Wood File Cabinet User Manual](#)

DEVAISE ASNG079BL

DEVAISE 5-Drawer Wood File Cabinet User Manual

Model: ASNG079BL

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your DEVAISE 5-Drawer Wood File Cabinet. Please read this manual thoroughly before assembly and use to ensure proper function and safety.





Image 1.1: The DEVAISE 5-Drawer Wood File Cabinet in black, featuring five drawers and a top door, with wheels for mobility.

2. SAFETY INFORMATION

Always follow basic safety precautions when assembling and using this product to reduce the risk of injury or damage.

- Keep all small parts and packaging materials away from children and pets.
- Assemble the unit on a clean, flat, and soft surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use.
- Do not overload drawers. Each drawer has a maximum capacity of 88 pounds. The overall cabinet maximum weight capacity is 150 pounds.
- Use the included anti-tipping device to secure the cabinet to a wall, especially if children are present. This prevents accidental tipping.
- Do not climb on or stand on the cabinet.

- Only open one drawer at a time to maintain stability.



Image 2.1: Diagram illustrating the importance and installation of the anti-tipping device to enhance cabinet stability and prevent accidents.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts are present and undamaged. If any parts are missing or damaged, contact customer support.

| Part | Description | Quantity |
|-------------------|---|----------|
| Cabinet Panels | Side panels, top, bottom, back panel, door panel | Various |
| Drawer Components | Drawer fronts, sides, backs, bottoms | 5 sets |
| Hardware Pack | Screws, dowels, cam locks, drawer slides, hinges, casters, anti-tipping kit | 1 set |
| Assembly Tools | Hex key, screwdriver (may require personal tools like a power drill) | 1 set |

| Part | Description | Quantity |
|--------------------|------------------------|----------|
| Instruction Manual | Printed assembly guide | 1 |

4. SETUP AND ASSEMBLY

Assembly typically takes approximately 1.5 to 2.5 hours with two people. Follow the step-by-step pictorial instructions provided in the package. A power drill is recommended for faster assembly.

4.1 Preparation

- Clear a spacious area for assembly.
- Lay out all parts and hardware, organizing them by type.
- Identify each panel and hardware piece using the provided diagrams.

4.2 Assembly Steps (General Overview)

1. Attach drawer slides to the cabinet side panels.
2. Assemble the main cabinet frame (top, bottom, sides, back).
3. Assemble each of the five drawers. Ensure drawer slides are correctly oriented.
4. Install the top door with hinges.
5. Attach the four 360° swivel casters to the base of the cabinet. Ensure the two front casters with brakes are positioned correctly.
6. Insert the assembled drawers into the cabinet.
7. Install the anti-tipping device to a wall stud for enhanced safety.

Product Size




Image 4.1: Detailed product dimensions (18.7" W x 15.75" D x 41.1" H) and maximum weight capacity (150 lbs) for the cabinet.

360° Swivel Casters



Image 4.2: Close-up view of the 360-degree swivel casters, highlighting the lockable feature on the front two wheels for stability.

5. OPERATING INSTRUCTIONS

5.1 Moving the Cabinet

The cabinet is equipped with four 360° swivel casters for easy mobility. To move the cabinet, unlock the brakes on the front two casters by flipping the lever upwards. Once in the desired position, push the levers downwards to engage the brakes and secure the cabinet.

5.2 Using the Drawers and Door

The cabinet features five spacious drawers and one top door. The drawers are designed for smooth operation. To open a drawer, gently pull the integrated handle. To close, push the drawer firmly until it is fully seated. The top door opens to reveal a large storage compartment, ideal for larger items or a printer.



Image 5.1: The cabinet with its top door open and drawers extended, demonstrating its versatile storage capabilities for various items.

SPACIOUS STORAGE SPACE



Files



Books



Printer



Sundries

Image 5.2: Visual representation of the cabinet's spacious interior, suitable for organizing files, books, a printer, and various sundries.

SAFE CLOSE HINGE



Safe



Silent

Image 5.3: Close-up of the safe-close hinge mechanism on the top door, designed for quiet and gentle closing.

6. MAINTENANCE

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as they may damage the laminate finish.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Drawer Slides:** If drawers do not glide smoothly, a small amount of silicone lubricant can be applied to the drawer slides.
- **Casters:** Keep casters free of debris (hair, dust) to ensure smooth rolling.

7. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|--|--|--|
| Drawers do not close smoothly or are misaligned. | Loose screws on drawer slides or incorrect slide installation. | Check and tighten all screws on drawer slides. Ensure slides are installed correctly according to the assembly instructions. |

| Problem | Possible Cause | Solution |
|-----------------------------------|--|--|
| Cabinet is wobbly or unstable. | Loose assembly hardware or casters not locked. | Verify all assembly screws are tightened. Ensure casters are locked when the cabinet is stationary. Install the anti-tipping device. |
| Casters do not roll freely. | Debris caught in casters or brakes engaged. | Clean any debris from the caster wheels. Ensure brakes are disengaged for movement. |
| Top door does not close properly. | Hinges are loose or misaligned. | Adjust or tighten the screws on the door hinges. |

8. SPECIFICATIONS

- **Brand:** DEVAISE
- **Model Name:** ASNG079wood dresser/BL
- **Item Model Number:** ASNG079BL
- **Color:** Black
- **Product Dimensions:** 18.7" W x 15.75" D x 41.1" H (including wheels)
- **Item Weight:** 55.7 pounds
- **Material:** Quality manufactured wood and durable laminate
- **Drawer Weight Capacity:** Up to 88 pounds per drawer
- **Maximum Weight Capacity (Overall):** 150 pounds
- **Special Features:** Wheeled (360° swivel, lockable casters), Anti-tipping device, Safe-close hinges
- **Assembly Required:** Yes
- **Room Type:** Home Office, Living Room, Bedroom, Studio, Kitchen
- **Country of Origin:** China

9. WARRANTY AND SUPPORT

DEVAISE is committed to providing quality products and customer satisfaction. While specific warranty details are not provided in this manual, please retain your proof of purchase.

- **Customer Support:** If you encounter any quality problems, missing parts, or require assistance with assembly or operation, please contact DEVAISE customer service.
- **Contact Information:** Refer to the contact details provided on the product packaging or the seller's official website for the most up-to-date support information.
- **Returns:** This product typically comes with a 30-day easy return policy. Please check with your retailer for specific return procedures.