Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Snailax 262M

Snailax Memory Foam Vibration Back Massager with Heat User Manual

Model: 262M

Product Overview

The Snailax Memory Foam Vibration Back Massager with Heat is designed to provide soothing relief and relaxation for your back and thighs. This versatile seat cushion features multiple vibration motors and adjustable heat levels, making it suitable for use in various settings such as home, office, or even in a car (with appropriate adapter, not included).



Figure 1: Snailax Memory Foam Vibration Back Massager with Heat, showing the cushion and remote control.

Key Features:

- **Vibration Massage:** 6 powerful vibrating motors target upper back, mid back, lower back, and thighs.
- **Customizable Settings:** 5 program modes (Pulsate, Tapping, Rolling, Auto, Kneading) and 4 variable vibration intensities.
- **Soothing Heat:** Two heat levels for full back and seat, with overheating protection and auto shut-off timer.
- **Premium Comfort:** Made of cozy soft plush material and high-density memory foam.
- **Secure Design:** Dual elastic straps and non-skipping bottom to secure the pad in place.



Figure 2: Detailed view of the massager's construction, highlighting memory foam, ultra-plush polyester, non-slip rubber bottom, and securing straps.

General Safety Information

Please read all instructions carefully before using this product. Failure to follow safety guidelines may result in injury or damage to the product.

- Do not use while sleeping.
- Burns can result from improper use.
- Do not insert pins or sharp objects into the massager.
- Unplug from 12VDC cigarette lighter socket when not in use to prevent battery drain.

- Unplug and let cool down before cleaning.
- This massager is for vibration and heat therapy only; it is**not** a Shiatsu kneading massager with rolling balls.

Setup

To use the Snailax Memory Foam Vibration Back Massager, follow these steps:

1. **Connect to Power:** Connect the massager to a power source using the provided adapter.
2. **Secure the Massager:** Secure the massager to a chair using the dual elastic straps. Ensure it is firmly in place to prevent slipping during use.
3. **Position Yourself:** Position yourself comfortably on the chair, ensuring the massage nodes align with your back and thighs for optimal effect.



Figure 3: Proper setup of the massager on an office chair for a customizable massage experience.

Operating Instructions

The massager is controlled via a wired remote. Familiarize yourself with the remote's functions:



Figure 4: The remote control with clearly labeled buttons for various functions.

- **Power (PWR):** Press to turn the massager ON or OFF.
- **Heat:** Activates or deactivates the heating function. There are two heat levels (High/Low). The heat can be used independently of the massage function.



Figure 5: The soothing heat function provides warmth to relax muscle tension.

- **Intensity (INT):** Adjusts the vibration intensity. There are 4 variable intensity levels.
- **Mode:** Cycles through 5 program modes:
  - Pulsate
  - Tapping
  - Rolling
  - Auto (cycles through all modes randomly)
  - Kneading (Note: This is a vibration-based kneading, not a mechanical Shiatsu kneading)
- **Massage Regions:** Select specific areas for massage:
  - Neck
  - Upper Back
  - Lower Back
  - Hips
  - Thighs

You can select all 4 zones at once or individually. The human body diagram on the remote will light up to indicate the active massage regions.

- **Timer:** Sets the massage duration to 15, 30, or 60 minutes. The massager will automatically shut off after the selected time.



Figure 6: The massager provides vibration to help relieve stress, aches, tension, and eliminate fatigue.

Maintenance

Proper care and maintenance will extend the life of your Snailax massager.

- **Cleaning:** Always unplug the massager from the power source and allow it to cool completely before cleaning. Wipe the surface with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals.

- **Storage:** Store the massager in a cool, dry place away from direct sunlight and excessive heat. Avoid placing heavy objects on top of the massager.
- **Handling:** Do not pull the massager by the power cord. Avoid sharp folds or creases in the material, especially where internal components are located.

Troubleshooting

If you encounter issues with your massager, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Massager does not turn on.	Not properly plugged in; Power outlet issue.	Ensure the power adapter is securely connected to both the massager and a working electrical outlet. Try a different outlet.
Vibration is weak or inconsistent.	Low intensity setting; Overheating protection activated.	Increase the intensity using the remote control. Allow the unit to cool down if it has been in continuous use for an extended period.
Heat function is not working.	Heat function not activated; Overheating protection activated.	Press the HEAT button on the remote. If the unit has been running for a long time, it may have automatically shut off the heat for safety. Allow it to cool.

Specifications

- **Product Dimensions:** 16.54 x 5.71 x 12.6 inches
- **Weight:** 4.14 Pounds
- **Item Model Number:** 262M
- **Manufacturer:** Snailax
- **Power Source:** Corded Electric
- **Material:** Memory Foam, Soft Plush Fabric (100% Polyester)
- **Color:** Dark Black
- **Country of Origin:** China

Warranty and Support

Snailax offers a warranty for this product. To extend your warranty for free from 1 year to 3 years, visit their online service center at http://support.snailax.com and register your product.

For further assistance or inquiries, please contact Snailax customer support.

© 2025 Snailax. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DD3KXJ75

More documents and user manuals: **https://manuals.plus/**