TOZO T11152

TOZO E2 Wireless Earbuds User Manual

Model: T11152

Introduction

Welcome to the TOZO E2 Wireless Earbuds user manual. This guide provides detailed instructions on how to set up, operate, maintain, and troubleshoot your new earbuds. The TOZO E2 earbuds feature 10mm drivers for powerful bass, customizable EQ settings via the TOZO App, extended 30-hour playtime, AI call noise cancellation, and advanced Bluetooth 5.3 connectivity for a superior audio experience.

What's in the Box

- TOZO E2 Wireless Earbuds
- Charging Case
- 3 pairs of Eartips (S/M/L)
- USB-C (A to C) cable (20cm)
- Quick Guide & User Manual



Image: The TOZO E2 Wireless Earbuds, including the earbuds themselves and their charging case.

Setup

1. Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C cable to the charging case and a power source. The indicator light on the case will show charging status.



Image: TOZO E2 earbuds placed inside their charging case, indicating charging status.

2. Pairing with Your Device

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "TOZO E2" in the list of available Bluetooth devices and select it to connect.
4. Once connected, you will hear a confirmation tone.



Image: A close-up of a Bluetooth 5.3 chip, representing the advanced connectivity of the TOZO E2 earbuds.

3. Fitting the Earbuds

Choose the ear tips that provide the most comfortable and secure fit for optimal sound quality and noise isolation. Gently insert the earbuds into your ear canal and twist slightly to secure them.



Image: A person wearing the TOZO E2 earbuds, demonstrating a comfortable and secure fit.

Operating Instructions

Touch Controls

The TOZO E2 earbuds feature intuitive touch controls for easy management of music playback and calls.

Action	Left Earbud	Right Earbud
Play/Pause	Single Tap	Single Tap

Action	Left Earbud	Right Earbud
Next Track	Double Tap	Double Tap
Previous Track	Triple Tap	Triple Tap
Answer/End Call	Single Tap	Single Tap
Reject Call	Press and Hold (2s)	Press and Hold (2s)
Activate Voice Assistant	Press and Hold (2s)	Press and Hold (2s)

TOZO App Integration

Enhance your listening experience by downloading the official TOZO App. The app allows you to:

- Customize 32 EQ settings to match your audio preferences.
- Access over 100 white noise tracks.
- Explore and share custom equalizers with a community of over 2,000 audiophiles in the 'EQ Zone'.



Image: Screenshots of the TOZO App interface, highlighting the 32 EQ modes, white noise tracks, and user-shared EQs.

Call Noise Cancellation

The TOZO E2 earbuds are equipped with 2 built-in microphones and advanced Environmental Noise Cancellation (ENC) technology. This feature works to block out background noise during calls, ensuring clearer communication even in busy environments.



Image: A woman using the TOZO E2 earbuds for a phone call, illustrating the call noise cancellation feature.

Low-Latency Mode

For an immersive gaming or video watching experience, activate the low-latency mode. This minimizes the delay between audio and video, ensuring synchronization.




Image: TOZO E2 earbuds shown with a smartphone displaying a racing game, demonstrating the low-latency mode for gaming.

Maintenance

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and ensure they remain charged.
- **Water Resistance:** The earbuds are waterproof. However, avoid prolonged exposure to water and do not submerge them. Ensure they are dry before placing them back in the charging case.
- **Battery Care:** To prolong battery life, avoid fully discharging the earbuds and case frequently. Charge them regularly.

Troubleshooting

Issue	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Place them back in the case, close, then reopen to re-enter pairing mode. Forget "TOZO E2" on your device's Bluetooth settings and try pairing again.
No sound from one earbud	Ensure both earbuds are charged. Try resetting the earbuds (refer to the quick guide for specific reset instructions). Re-pair with your device.
Low volume or poor sound quality	Adjust volume on both your device and the earbuds. Ensure ear tips are properly fitted and clean. Try different sized ear tips for a better seal.
Earbuds not charging	Ensure the charging cable is securely connected. Check if the charging case has power. Clean the charging contacts on both the earbuds and the case.

Specifications

Feature	Detail

Feature	Detail
Model Name	E2 (T11152)
Connectivity Technology	Wireless (Bluetooth 5.3)
Audio Driver Size	10mm Dynamic Drivers
Playtime (Single Charge)	Up to 8.5 hours
Total Playtime (with Charging Case)	Up to 30 hours
Charging Time	1.5 Hours (Earbuds & Case)
Noise Control	Sound Isolation, AI Call Noise Cancellation (ENC)
Bluetooth Range	12 Meters
Audio Latency	60 Milliseconds (Low-latency Mode)
Water Resistance Level	Waterproof
Control Type	Touch Control / APP
Material	Polycarbonate (PC), Acrylonitrile Butadiene Styrene (ABS)
Item Weight	32.9 Grams

Official Product Videos

Watch these official videos for more information and demonstrations of the TOZO E2 Wireless Earbuds.
No official seller videos are available for embedding at this time.

Warranty and Support

TOZO products typically come with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging or visit the official TOZO website for detailed warranty information and support options.
For further assistance, technical support, or warranty claims, please contact TOZO customer service through their official website or the contact information provided in your product's quick guide.
Online Support: TOZO Official Website Support

© 2025 TOZO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question