Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CACOE X62

CACOE X62 Wireless Foldable Keyboard with Stand User Manual

Model: X62

Introduction

Thank you for choosing the CACOE X62 Wireless Foldable Keyboard. This ultra-slim, portable keyboard is designed to enhance your typing experience across multiple devices, including smartphones, tablets, and computers. Its dual-channel Bluetooth connectivity and integrated stand provide convenience and efficiency for on-the-go productivity. Please read this manual carefully to ensure proper use and optimal performance of your device.

Product Overview

The CACOE X62 keyboard features a compact, foldable design with a built-in stand. It utilizes QWERTY layout keys with a scissor-switch mechanism for quiet and responsive typing. The keyboard supports dual-channel Bluetooth for seamless switching between two devices and is compatible with iOS, Android, and Windows operating systems.

Key Features:

- **Ultra-Slim & Portable:** Weighs only 191 grams and folds to a compact size for easy transport.
- **Dual-Channel Bluetooth:** Connects to two devices simultaneously and allows for quick switching.
- **Multi-System Compatibility:** Works with iOS, Android, and Windows devices.
- **Integrated Adjustable Stand:** Provides flexible viewing angles for your smartphone or tablet.
- **Responsive QWERTY Keys:** Features whisper-quiet scissor-switch keys for comfortable typing.
- **Long-Lasting Rechargeable Battery:** Offers extended use and standby times.

Setup

1. Charging the Keyboard

Before first use, fully charge the keyboard using a Type-C charging cable (not included). The charging port is typically located on the side of the keyboard. A full charge provides over 80 hours of use time and over 100 days of standby time.



Figure 1: The CACOE X62 keyboard connected to a Type-C charging cable, illustrating its long-lasting rechargeable battery with indicators for capacity, use time, and standby time.

2. Powering On/Off

Locate the power switch on the side of the keyboard. Slide the switch to the "ON" position to power on the keyboard. Slide it to "OFF" when not in use to conserve battery life.

3. Bluetooth Pairing

The CACOE X62 keyboard supports dual-channel Bluetooth, allowing connection to two devices simultaneously.

1. **Pairing Device 1:**
    - Turn on the keyboard.
    - Press and hold the **Fn** key and the **1** key (with the Bluetooth icon) simultaneously until the Bluetooth indicator light starts blinking. This indicates the keyboard is in pairing mode for Channel 1.
    - On your device (e.g., smartphone, tablet), go to Bluetooth settings and search for "WirelessKeyboard 1" or a similar name.

- Select the keyboard to connect. The indicator light will stop blinking once successfully paired.

2. **Pairing Device 2:**
    - Press and hold the **Fn** key and the **2** key (with the Bluetooth icon) simultaneously until the Bluetooth indicator light starts blinking. This indicates the keyboard is in pairing mode for Channel 2.
    - On your second device, go to Bluetooth settings and search for "WirelessKeyboard 2" or a similar name.
    - Select the keyboard to connect. The indicator light will stop blinking once successfully paired.



Figure 2: Illustrates the process of pairing the keyboard with two devices simultaneously using the Fn+1 and Fn+2 key combinations.

Your browser does not support the video tag.

Video 1: This video demonstrates the Bluetooth pairing process for the CACOE X62 keyboard with both a tablet and a smartphone, including how to switch between the two connected devices.

4. Using the Integrated Stand

The keyboard features a foldable cover that doubles as an adjustable stand. Simply unfold the keyboard and adjust the back flap to create a stable support for your smartphone or tablet at a comfortable viewing angle (up to 150 degrees).

Ensure your device is securely placed in the stand.



Figure 3: The CACOE X62 keyboard in use with a smartphone, highlighting the adjustable stand and recommended operating range.

Operating Instructions

1. Switching Between Devices

To switch between Device 1 and Device 2, simply press the **Fn** key along with the corresponding channel key (**1** or **2**). The keyboard will seamlessly switch its connection to the selected device.



Figure 4: The CACOE X62 keyboard maintaining a stable wireless connection across multiple devices within a 10-meter range.

2. Special Function Keys

The keyboard includes various function keys (accessed by pressing **Fn** + a specific key) for quick access to common controls:

- **Screen Brightness:** Adjust screen brightness (e.g., **Fn + 3** for decrease, **Fn + 4** for increase).
- **Volume Control:** Adjust audio volume (e.g., **Fn + 8** for mute, **Fn + 9** for decrease, **Fn + 0** for increase).
- **Media Playback:** Control music/video playback (e.g., **Fn + 6** for previous track, **Fn + 7** for play/pause, **Fn + 8** for next track).
- **Home/End/PgUp/PgDn:** Dedicated keys for navigation.




Figure 5: The key layout of the CACOE X62 keyboard, showing the various function keys and their corresponding actions.

3. Special Characters and OS Compatibility

The keyboard's special characters may require different key combinations depending on your operating system (iOS, Android, Windows). Refer to the on-screen input method settings of your device for specific character input instructions.




Figure 6: Key combinations for inputting special characters, demonstrating variations across iOS, Android, and Windows operating systems.



Figure 7: The CACOE X62 keyboard demonstrating compatibility with Android, iOS, and Windows devices.

Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe the keyboard surface. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid excessive moisture.
- **Storage:** When not in use, fold the keyboard to protect the keys and screen. Store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the keyboard frequently. Charge it regularly, even if not in constant use.

Troubleshooting

- **Keyboard not pairing:**
  - Ensure the keyboard is powered on and fully charged.
  - Make sure Bluetooth is enabled on your device.
  - Confirm the keyboard is in pairing mode (indicator light blinking after pressing**Fn + 1** or **Fn + 2**).
  - Forget previous keyboard connections on your device and try pairing again.
  - Move the keyboard closer to your device (within 10 meters).
- **Keys are unresponsive:**
  - Check if the keyboard is connected to the correct device channel.
  - Ensure the keyboard battery is not low.
  - Restart the keyboard and your device.
- **Incorrect characters appearing:**
  - Verify that the input language settings on your device match the keyboard's layout.
  - Refer to the "Special Characters and OS Compatibility" section for specific key combinations.

Specifications

Brand	CACOE
Model Number	X62
Product Dimensions (Folded)	7.68 x 3.74 x 0.71 inches (195 x 85 x 15 mm)
Item Weight	8.4 ounces (191 grams)
Connectivity Technology	Bluetooth
Compatible Devices	Smartphones, Tablets (iOS, Android, Windows)
Keyboard Description	Multi Functional, QWERTY Layout, Scissor-Switch Keys
Special Feature	Foldable, Integrated Stand, Dual-Channel Bluetooth
Battery	1 Nonstandard Battery (included), Rechargeable (Type-C)
Operating Range	Up to 10 meters (33 feet)

Warranty and Support

For warranty information, technical support, or customer service inquiries, please refer to the product packaging or contact CACOE customer support directly. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How long does it take to fully charge the CACOE X62 Wireless Foldable Keyboard?

The user manual for the CACOE X62 Wireless Foldable Keyboard does not specify the exact number of hours required to reach a full charge from 0%. However, it provides the following details regarding the...

Read full answer

Open the live page

https://manuals.plus/asin/B0DD411VYY

More documents and user manuals: **https://manuals.plus/**