

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [OLEVS](#) /
- › [OLEVS Model 9931 Quartz Watch Instruction Manual](#)

OLEVS 9931

OLEVS Model 9931 Quartz Watch Instruction Manual

Your guide to setting up, operating, and maintaining your OLEVS timepiece.

INTRODUCTION

Thank you for choosing the OLEVS Model 9931 Quartz Watch. This timepiece combines elegant design with reliable Japanese Quartz movement, offering accurate timekeeping and a sophisticated aesthetic. This manual provides essential information to ensure proper use and care of your watch.



The OLEVS Model 9931 Quartz Watch, featuring a black stainless steel band and a black dial with luminous hands and diamond hour markers.

SETUP

Before wearing your OLEVS watch, please follow these steps to set the time and date.

1. Setting the Time

1. **Pull the crown out to position 2:** Gently pull the crown (the knob on the side of the watch) out to the second click.
2. **Rotate the crown:** Turn the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.

3. **Push the crown back:** Once the time is set, push the crown back into position 0 (normal operating position) to start the watch.

2. Setting the Date

1. **Pull the crown out to position 1:** Gently pull the crown out to the first click.
2. **Rotate the crown:** Turn the crown clockwise to adjust the date. Avoid setting the date between 9:00 PM and 3:00 AM, as this may interfere with the automatic date change mechanism.
3. **Push the crown back:** Once the date is set, push the crown back into position 0.



The watch crown, used for setting both the time and date. Pulling it out to different positions allows for specific adjustments.

3. Adjusting the Bracelet

The stainless steel bracelet may require adjustment to fit your wrist comfortably. It is recommended to have this done by a professional watchmaker or jeweler to avoid damaging the links or clasp. Links can be added or removed to achieve the desired fit.

OPERATING YOUR WATCH

Your OLEVS Model 9931 watch is designed for daily wear, offering reliable timekeeping and additional

features.

Timekeeping

The watch operates continuously once the crown is pushed back into position 0. The Japanese Quartz movement ensures accurate time display.

Luminous Display

The hands and hour markers feature a luminous coating, allowing for readability in low-light conditions after exposure to light.

Water Resistance

This watch is water-resistant up to 30 meters (98 feet). This means it is suitable for daily use, such as splashes, rain, or brief immersion in water. It is **not** suitable for swimming, diving, or hot water activities (e.g., showering, sauna), as steam and temperature changes can compromise the seals.



The OLEVS watch comfortably worn on a wrist, displaying the current time and date.

MAINTENANCE

Proper care will extend the life and appearance of your OLEVS watch.

Cleaning

- Wipe the watch case and bracelet regularly with a soft, dry cloth to remove dust and smudges.
- For stainless steel parts, a slightly damp cloth can be used, followed by immediate drying.
- Avoid using chemical cleaners, solvents, or abrasive materials, as these can damage the watch's finish.

Battery Replacement

The watch is powered by a battery. When the watch stops or the second hand begins to skip, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure the watch's water resistance is maintained.

Water Resistance Precautions

- Always ensure the crown is fully pushed in before any contact with water.
- Do not operate the crown or push buttons when the watch is wet or submerged.
- Avoid exposing the watch to extreme temperature changes, which can cause seals to expand and contract, potentially leading to water ingress.

Storage

When not wearing the watch, store it in a cool, dry place, away from direct sunlight and strong magnetic fields.

TROUBLESHOOTING

If you encounter any issues with your OLEVS watch, please refer to the following common troubleshooting tips.

- **Watch not running:** Check if the crown is fully pushed into position 0. If it is, the battery may need replacement.
- **Date not changing:** Ensure the time is set correctly, especially the AM/PM cycle. The date typically changes around midnight. If the date changes at noon, you have set the time 12 hours incorrectly.
- **Condensation inside the crystal:** This indicates a potential breach in the watch's water resistance. Immediately contact customer support or a professional watch repair service.
- **Inaccurate timekeeping:** While quartz watches are highly accurate, significant deviation may indicate a low battery or a need for servicing.

SPECIFICATIONS

Detailed technical specifications for the OLEVS Model 9931 Quartz Watch.

Feature	Specification
Model Name	G9931GH
Display Type	Analog
Movement Type	Japanese Quartz
Power Source	Battery Powered

Feature	Specification
Water Resistance Depth	30 Meters (98 Feet)
Case Material	Stainless Steel
Band Material	Stainless Steel
Case Diameter	41 Millimetres
Case Thickness	11 Millimetres
Band Width	20 Millimetres
Band Length	7.4 Inches
Item Weight	0.17 Kilograms (170g)
Crystal Type	Hardlex
Clasp Type	Push Button Hidden Clasp
Included Components	Watch Box

PRODUCT PARAMETERS



Product Size

41

Case diameter(MM)

11

Case thickness(MM)

20

Chain width(MM)

19

Chain length(CM)

Brand model number:

OLEVS/9931

Mirror:

High hardness coated glass mirror

Watch chain:

Stainless steel strap

Movement:

Original quartz movement

Waterproof:

30 meter deep waterproof

Watch weight:

114g

* Tips: All sizes are manually measured, there is a reasonable error, please prevail in kind

Visual representation of the OLEVS watch's key dimensions and material specifications.

WARRANTY

Your OLEVS Model 9931 Quartz Watch comes with a limited warranty. Please refer to the warranty card included in your watch box for specific terms, conditions, and duration of coverage. The warranty typically covers manufacturing defects but does not cover damage resulting from improper use, accidents, or unauthorized repairs.

SUPPORT

For further assistance, technical support, or warranty claims, please contact OLEVS customer service through the retailer where you purchased the watch or visit the official OLEVS website for contact information. Please have your model number (9931) and purchase details ready when contacting support.

© 2023 OLEVS. All rights reserved.