

[Manuals.plus](#) /

› [Brushmo](#) /

› Brushmo e-Series Electric Sonic Toothbrush (Model BM02) Instruction Manual

Brushmo BM02

Brushmo e-Series Electric Sonic Toothbrush (Model BM02) Instruction Manual

Your guide to optimal oral hygiene with Brushmo technology.

[Introduction](#) [Package Contents](#) [Safety Information](#) [Setup](#) [Operating Instructions](#) [Modes & Features](#) [Charging](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the Brushmo e-Series Electric Sonic Toothbrush, Model BM02. This manual provides essential information for the safe and effective use of your new sonic toothbrush. Please read it thoroughly before operation and retain it for future reference.

2. PACKAGE CONTENTS

Your Brushmo e-Series Electric Sonic Toothbrush package includes the following items:

- 1 x Rechargeable Electric Toothbrush Handle
- 1 x Screw-On Brushmo Brush Head
- 1 x Qi Wireless Charging Base
- 1 x USB-C Power Adapter
- Instruction Manual

What's in the box

BRUSHMO



Image: All components included in the Brushmo e-Series Electric Sonic Toothbrush package, including the handle, brush head, charging base, and power adapter.

3. IMPORTANT SAFETY INFORMATION

- **Choking Hazard:** Keep out of reach of children. This product is not intended for use by children without adult supervision.
- Always supervise children when using this product.
- Replace brush head every 3 months or sooner if bristles appear worn for optimal performance and hygiene.
- Do not use this product if it appears damaged.
- Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

4. SETUP

1. **Attach Brush Head:** Align the screw-on brush head with the metal shaft on the toothbrush handle and gently twist until it is securely in place.
2. **Initial Charge:** Before first use, fully charge the toothbrush for at least 24 hours. Place the toothbrush handle onto the Qi wireless charging base and connect the USB-C power adapter to a power source. The

battery indicator lights will illuminate to show charging progress.




Image: A visual guide demonstrating how to attach a screw-on brush head to the toothbrush handle and how to place the handle on the wireless charging base.

5. OPERATING INSTRUCTIONS

1. **Wet Brush Head:** Wet the bristles of the brush head and apply a small amount of toothpaste.
2. **Power On:** Press the power button once to turn on the toothbrush. It will start in the default "Clean" mode.
3. **Select Mode:** Press the power button repeatedly to cycle through the available brushing modes: Clean, Whitening, and Gum Care.
4. **Brushing Technique:** Place the brush head against your teeth at a slight angle towards the gum line. Move the brush slowly across your teeth, allowing the sonic vibrations to clean each tooth surface.
5. **Built-in Timer:** The toothbrush features a 2-minute timer, with 30-second interval pauses to indicate when to move to a different quadrant of your mouth. This ensures thorough cleaning as recommended by dental professionals.
6. **Power Off:** After the 2-minute cycle, the toothbrush will automatically turn off. You can also press and hold the power button to turn it off manually at any time.
7. **Rinse:** Rinse your mouth and the brush head thoroughly after each use.



Image: A person demonstrating the proper use of the Brushmo e-Series Electric Sonic Toothbrush for effective cleaning.

6. BRUSHING MODES AND KEY FEATURES

The Brushmo e-Series Sonic Toothbrush offers three distinct brushing modes to cater to various oral care needs:

- **Clean Mode:** For superior daily cleaning and plaque removal.
- **Whitening Mode:** Designed to remove surface stains and polish teeth for a brighter smile.
- **Gum Care Mode:** Provides a gentle massage for gums, promoting gum health.

Key Features:

- **3 Advanced Brushing Modes:** Customize your brushing experience.
- **2-Minute Smart Timer:** Ensures dentist-recommended brushing time with 30-second interval reminders.
- **IPX7 Waterproof Rating:** The toothbrush is fully waterproof and can be safely used in the shower or bath, and rinsed under running water.
- **Long-Lasting Battery:** Enjoy up to 30 days of brushing on a single full charge.
- **Qi Wireless Charging:** Convenient and space-saving charging.
- **DuPont Filaments & BPA-Free Plastic:** High-quality, safe materials meeting OEHHA Prop 65 standards.

BRUSHMO

MORE than a BRUSH—It's a lifestyle!



Image: The Brushmo e-Series Electric Sonic Toothbrush showcasing its three customizable brushing modes and its ability to remove up to 10 times more plaque.



30 days of
battery life on a
single charge

Built-in 2-minute
timer with
30-second pulses
for an even clean

IPX7 waterproofing
withstands water up
to 1 meter for up to
30 minutes

Compatible with
Screw-on brush heads

Image: Visual representation of the Brushmo toothbrush's key features: 30 days of battery life, a built-in 2-minute timer with 30-second pulses, and IPX7 waterproofing.

7. CHARGING

The Brushmo e-Series Electric Sonic Toothbrush uses a Qi wireless charging base for convenient recharging.

1. Ensure the charging port on the base is clean and dry.
2. Connect the USB-C power adapter to the charging base and then to a suitable power source.
3. Place the toothbrush handle vertically onto the charging base. The battery indicator lights on the handle will illuminate to show that charging has begun.
4. A full charge provides up to 30 days of brushing (based on typical usage).

Your browser does not support the video tag.

Video: An official Brushmo video demonstrating the features and usage of the Super Sonic Toothbrush, including charging.

8. MAINTENANCE

- **Cleaning the Brush Head:** After each use, rinse the brush head thoroughly under running water.
- **Cleaning the Handle:** Wipe the toothbrush handle with a damp cloth. Do not submerge the handle in water for extended periods, despite its waterproof rating.
- **Replacing Brush Heads:** For optimal hygiene and effectiveness, replace the brush head every 3 months or as soon as the bristles show signs of wear. Screw-on brush heads are easy to replace.
- **Storage:** Store the toothbrush in a dry, cool place when not in use.

9. TROUBLESHOOTING

Problem	Possible Cause	Solution
Toothbrush does not turn on.	Low battery or not charged.	Charge the toothbrush fully. Ensure the charging base is connected to power.
Weak vibration.	Low battery or loose brush head.	Recharge the toothbrush. Ensure the brush head is securely attached.
Brush head falls off during use.	Brush head not properly attached.	Ensure the screw-on brush head is twisted securely onto the handle.

10. SPECIFICATIONS

Feature	Detail
Model Number	BM02
Brand	Brushmo
Product Dimensions	1.25 x 1.25 x 5.5 inches
Item Weight	8 ounces
Battery Type	1 Lithium Ion battery (included)
Waterproof Rating	IPX7
Brushing Modes	Clean, Whitening, Gum Care
Timer	2-minute smart timer with 30-second interval pauses

Feature	Detail
Material	Plastic, Rubber (DuPont filaments, BPA-free plastic)
Age Range	Adult

11. WARRANTY AND SUPPORT

For warranty information or customer support, please visit the official Brushmo website or contact our customer service team. Keep your purchase receipt for warranty claims.

Manufacturer: Brushmo

Brand Store: [Visit the Brushmo Store on Amazon](#)