



[Manuals.plus](#) /

› [Oksoar](#) /

› Oksoar Under Sink Organizers and Storage Instruction Manual

## Oksoar Under Sink Organizer

# Oksoar Under Sink Organizers and Storage Instruction Manual

Model: Under Sink Organizer | Brand: Oksoar

## 1. INTRODUCTION

---

Thank you for choosing the Oksoar Under Sink Organizers and Storage. This 2-pack organizer system is designed to maximize storage space in your kitchen, bathroom, or pantry cabinets, especially under sinks where pipes and disposals often limit usable area. Featuring adjustable height and smooth pull-out drawers, these organizers provide convenient access and efficient storage for various items.



Figure 1.1: Oksoar Under Sink Organizers in use, demonstrating efficient storage.

## 2. PRODUCT FEATURES

- **5 Adjustable Height Levels:** Metal holes spaced 0.79 inches apart allow height adjustment from 13.98 inches to 17.14 inches, accommodating various cabinet heights and item sizes, including tall bottles.
- **2-Tier Pull-Out Drawers:** Both upper and lower drawers slide out smoothly on upgraded double rails, providing easy access to items stored deep within cabinets without sticking or noise.
- **Larger Storage Capacity:** Upgraded design with longer and wider drawers. The bottom drawer measures 15.5"L x 11.02"W x 3.74"H, and the top drawer measures 14.57"L x 6.5"W x 2.56"H.
- **L-Shaped Design:** Specifically designed with a narrow top and wide bottom to fit under sinks with pipes and garbage disposals, maximizing otherwise unusable space.
- **Thickened Carbon Steel Construction:** Made from selected carbon steel for enhanced stability, strength, and load-bearing capacity without deformation. Features a heightened fence to prevent items from falling and 4 non-slip suction cups for secure positioning.

# 5-Level Height Adjustment

Suitable for items and cabinets of different heights




Figure 2.1: Demonstration of the 5-level height adjustment feature.

## Double Sliding Drawer



Figure 2.2: Detail of the double sliding drawer and guardrail for secure storage.



Figure 2.3: Key components and material details of the organizer.

### 3. PACKAGE CONTENTS

The Oksoar Under Sink Organizers package includes the following items:

- 2 x 2-Tier Under Sink Organizer units

### 4. SETUP AND ASSEMBLY

The Oksoar Under Sink Organizers are designed for straightforward assembly. While specific step-by-step instructions are not provided, the modular design allows for easy setup.

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components listed in Section 3 are present.
2. **Assemble Frame:** Connect the vertical support frames to the base. Ensure all connections are secure.
3. **Attach Drawers:** Slide the upper and lower basket drawers onto their respective rails on the frame. Ensure they slide smoothly.

4. **Adjust Height:** Determine the desired height for the upper drawer. Align the holes on the vertical supports with the corresponding holes on the upper drawer's attachment points. Secure the upper drawer at the chosen height using the provided fasteners. The adjustable metal holes are spaced 0.79 inches apart, allowing for precise height customization.
5. **Place Suction Cups:** Ensure the 4 non-slip suction cups are securely attached to the bottom of the organizer's base for stability.
6. **Position Organizer:** Place the assembled organizer in your desired location, such as under a kitchen or bathroom sink, or in a pantry cabinet.



Figure 4.1: Detail of height adjustment points.

## 5. OPERATING INSTRUCTIONS

---

Using your Oksoar Under Sink Organizer is simple and intuitive:

- **Loading Items:** Place your desired items, such as cleaning supplies, toiletries, or pantry goods, into the upper and lower drawers. The heightened fence helps prevent items from falling out.
- **Accessing Items:** To access items, simply pull the desired drawer forward. The upgraded double rails ensure a smooth and quiet sliding motion.
- **Adjusting Height (if needed):** If your storage needs change or you acquire taller items, you can re-adjust the height of the upper drawer by loosening the fasteners, repositioning the drawer to a different set of holes, and re-securing.
- **Placement:** These organizers are ideal for under kitchen sinks, bathroom vanities, or pantry cabinets. Their L-shaped design is particularly beneficial for navigating around plumbing.



Kitchen Storage



Toiletry Storage

Figure 5.1: Versatile use for kitchen and toiletry storage.

## 6. MAINTENANCE

To ensure the longevity and optimal performance of your Oksoar Under Sink Organizers, follow these simple maintenance guidelines:

- **Cleaning:** Wipe down the carbon steel frame and drawers with a soft, damp cloth. For stubborn stains, a mild soap solution can be used. Avoid abrasive cleaners or harsh chemicals, as they may damage the finish.
- **Drying:** After cleaning, dry all parts thoroughly to prevent water spots or potential rust, especially in humid environments like under sinks.
- **Drawer Rails:** Periodically check the sliding rails for any debris or obstructions that might hinder smooth operation. Clean as necessary.
- **Stability Check:** Occasionally verify that the non-slip suction cups are firmly attached to the surface and that the organizer remains stable.

## 7. TROUBLESHOOTING

If you encounter any issues with your Oksoar Under Sink Organizers, refer to the following common problems and solutions:

<b>Problem</b>	<b>Possible Cause</b>	<b>Solution</b>
Drawers are not sliding smoothly.	Debris on rails, uneven load, or misaligned installation.	Clean rails of any dust or debris. Redistribute items evenly in the drawer. Check if the organizer is level and re-adjust if necessary.
Organizer feels unstable or wobbly.	Suction cups not properly engaged, uneven surface, or loose connections.	Ensure suction cups are clean and pressed firmly onto a smooth, dry surface. Place the organizer on a level surface. Check all assembly connections and tighten if loose.
Items falling out of drawers.	Overloading or items placed too high.	Do not overload drawers beyond their capacity. Ensure items are within the height of the drawer's guardrail.

## 8. SPECIFICATIONS

<b>Attribute</b>	<b>Detail</b>
Brand	Oksoar
Model Number	Under Sink Organizer
Material	Carbon Steel
Color	White
Finish Type	Brushed
Item Weight	8.5 Pounds (for the pack of 2)
Product Dimensions	15 x 11 x 17 inches (approximate assembled dimensions)
Number of Items	2 (pack)
Special Feature	Adjustable Height, Pull-Out Drawers
Bottom Drawer Dimensions	15.5"L x 11.02"W x 3.74"H
Top Drawer Dimensions	14.57"L x 6.5"W x 2.56"H
Adjustable Height Range	13.98" to 17.14"

## 9. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Oksoar Under Sink Organizers, please contact the seller or manufacturer directly through your purchase platform. Please retain your proof of purchase for any warranty claims or support inquiries.

