



Manuals.plus /

› BoostArea /

› BoostArea Dimmable Floor Lamp User Manual

BoostArea B1381

BoostArea Dimmable Floor Lamp User Manual

Model: B1381

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your BoostArea Dimmable Floor Lamp. This arc floor lamp features stepless dimming, adjustable color temperature (2700K-6500K), and convenient control via a remote or foot switch. Please read this manual thoroughly before use to ensure proper functionality and safety.



Image 1.1: The BoostArea Dimmable Floor Lamp, showcasing its arc design, white lampshade, and included remote control. An inset image displays the range of color temperatures from warm white to cool white.

2. PACKAGE CONTENTS

Verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer support.

- Lamp Base
- Lamp Poles (multiple sections)
- Arc Lamp Arm with Bulb Socket
- Lampshade
- Dimmable LED Bulb (E26)
- Remote Control
- User Manual



Image 2.1: A visual representation of all components included in the package, such as the lamp poles, base, bulb, remote control, and lampshade.

3. SETUP AND ASSEMBLY

Assembly typically takes approximately 5 minutes and requires no additional tools. Follow these steps:

1. **Install the Lampshade:** Unroll the lampshade and attach it to the metal frame.
2. **Assemble the Lamp Poles:** Screw all lamp pole sections together from top to bottom, ensuring they are securely tightened.
3. **Attach to Base:** Insert the assembled lamp poles into the sturdy lamp base and rotate clockwise until firmly secured.
4. **Prepare Bulb Socket:** Unscrew the socket ring from the lampholder on the arc arm.
5. **Install Lampshade:** Place the assembled lampshade onto the lampholder and secure it by screwing the socket ring back on.
6. **Install LED Bulb:** Carefully screw the provided E26 LED bulb into the lampholder.



Image 3.1: Visual instructions detailing the six steps for assembling the floor lamp, from installing the lampshade to screwing in the bulb.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

- **Foot Switch:** Press the foot switch located on the power cord to turn the lamp on or off.
- **Remote Control:** Press the power button (**U**) on the remote control to turn the lamp on or off.

4.2 Brightness Adjustment (Stepless Dimming)

The lamp offers stepless brightness adjustment from 10% to 100%.

- **Remote Control:** Use the brightness up (+) and brightness down (-) buttons to adjust the light intensity.

Stepless Color Temperature



Image 4.1: An illustration demonstrating the stepless brightness adjustment feature, showing the lamp's output from a dim 5% to a bright 100% illumination.

4.3 Color Temperature Adjustment

Adjust the color temperature from 2700K (warm white) to 6500K (cool white).

- **Remote Control:** Press the 'K' button to cycle through preset color temperatures or use the color temperature up (**C+**) and color temperature down (**C-**) buttons for stepless adjustment.

Mid Century Dimmable Floor Lamp




Image 4.2: This image displays the lamp's ability to adjust both color temperature (2700K Warm White, 4000K Neutral Light, 5000K Daylight, 6500K Cool White) and brightness (5% to 100%).

4.4 Preset Lighting Modes

The remote control includes dedicated buttons for various lighting modes:

- **Night Light Mode:** Provides a soft, low-intensity light for nighttime use.
- **Babyfeeding Mode:** A gentle light setting suitable for nurseries.
- **Working Mode:** Brighter, cooler light optimized for tasks and concentration.
- **Reading Mode:** A comfortable light level and color temperature for reading.

Four Lighting modes easy for your Choose




Sleeping Mode



Nursery Mode



Reading Mode



Working Mode

Image 4.3: A visual guide to the four lighting modes: Sleeping Mode, Nursery Mode, Reading Mode, and Working Mode, each depicted with an appropriate icon on the remote control.

4.5 Flexible Lamp Head

The lamp head can be rotated 350° horizontally and 90° vertically, allowing you to direct light precisely where needed for reading or working.



Image 4.4: A close-up view illustrating the flexible lamp head, demonstrating its ability to tilt and rotate to various angles.

4.6 Timer Function

Activate the 1-hour timer function via the remote control. The lamp will automatically turn off after one hour.



Image 4.5: This image shows the lamp with an overlay indicating a "1 Hour Timer" function, demonstrating its ability to automatically switch off after a set period.

4.7 Remote Control Overview

Convenient Remote Control & Different Modes



Image 4.6: A detailed diagram of the remote control, labeling each button and its corresponding function, including 1-hour timing, on/off, brightness adjustment, color temperature adjustment, and various preset modes.

5. MAINTENANCE

To maintain your BoostArea Dimmable Floor Lamp:

- Ensure the lamp is unplugged before cleaning.
- The inner PVC lining of the lampshade is waterproof and oil-resistant.
- The outer lampshade material can be cleaned with a damp cloth. Avoid harsh chemicals.
- Regularly check all connections to ensure they remain secure.
- Replace the E26 LED bulb only with a dimmable E26 LED bulb, maximum 60W.

6. SAFETY INFORMATION

- Do not use the lamp in wet or damp conditions. This product is designed for indoor use only.
- Ensure the lamp is placed on a stable, level surface. The sturdy base (10 inch, 6.6 LB) provides stability, but proper placement is crucial.
- Keep the lamp away from heat sources and direct sunlight.
- Do not attempt to modify or disassemble the lamp beyond the assembly instructions.
- Always unplug the lamp from the power outlet before cleaning or performing any maintenance.
- Keep the remote control and small parts out of reach of children.

7. SPECIFICATIONS

Model Name	Dimming floor lamp with Lampshade
Model Number	B1381
Brand	BoostArea
Product Dimensions	10"D x 10"W x 67"H
Item Weight	9.88 pounds
Material	Linen, Metal
Shade Material	Linen
Base Material	Metal
Light Source Type	LED
Bulb Base	E26
Wattage	10 watts (Max 60W for E26 LED dimming bulbs)
Color Temperature	2700K-6500K
Control Method	Remote, Foot Switch
Special Features	Adjustable Color Temperature, Dimmable, Flexible Lamp Head, Remote Control, Timer
Power Source	Corded Electric

Size Information

Classic design, more stability and durability



Image 7.1: A diagram illustrating the dimensions of the floor lamp (66.5 inches height, 10 inches base diameter, 17.3 inches arc extension) and highlighting key features like the flexible lamp head, remote control, sturdy base, and easy foot switch.

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official BoostArea website. Please retain your proof of purchase for any warranty claims.