



Manuals.plus /

› BoostArea /

› BoostArea Dimmable Floor Lamp User Manual


BoostArea B1383

BoostArea Dimmable Floor Lamp User Manual

Model: B1383

1. INTRODUCTION

Thank you for purchasing the BoostArea Dimmable Floor Lamp. This arc-style floor lamp is designed to provide versatile lighting for your living room, bedroom, study, or office. It features stepless dimming for brightness and color temperature, a convenient remote control, and a flexible lamp head for optimal light positioning. Please read this manual thoroughly before assembly and operation to ensure safe and efficient use.



An overview of the BoostArea Dimmable Floor Lamp, showcasing its arc design, linen lampshade, sturdy base, and the included remote control.

2. SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, please follow these safety guidelines:

- Ensure the power is OFF before assembly, disassembly, or cleaning.
- Do not connect the electricity until your lamp is fully assembled.
- Use only the specified bulb type and wattage (E26 LED dimming bulb, Max 60W).
- Do not use with a damaged cord or plug. If the cord or plug is damaged, contact customer support.
- Keep the lamp away from water and moisture.
- This product is for indoor use only.
- Do not attempt to modify or repair the lamp yourself. Refer all servicing to qualified personnel.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with assembly:

- Lamp Poles (various sections)
- Lamp Base
- Linen Lampshade
- Lampshade Frame
- E26 Dimmable LED Bulb (10W/1200LM)
- Remote Control
- User Manual



Image displaying all components included in the package: lamp poles, base, E26 bulb, lampshade frame, remote control, and linen lampshade.

4. ASSEMBLY GUIDE

Assembly typically takes about 5 minutes and requires no additional tools.

1. **Prepare the Lampshade:** Unroll the linen lampshade and attach it to the lampshade frame. Secure it firmly.
2. **Assemble the Lamp Poles:** Screw the lamp poles together from top to bottom, ensuring each section is tightly connected.
3. **Attach to Base:** Insert the assembled lamp poles into the lamp base and rotate clockwise until securely fastened.
4. **Install Lampshade:** Unscrew the socket ring from the lampholder. Place the assembled lampshade onto the lampholder and screw the socket ring back on to secure the lampshade.
5. **Insert Bulb:** Carefully screw the provided E26 LED bulb into the lampholder.
6. **Connect Power:** Plug the power cord into a suitable electrical outlet.



Visual guide illustrating the assembly process, including installing the lampshade, screwing poles together, attaching to the base, and inserting the bulb.

5. OPERATION

5.1 Remote Control

The lamp can be controlled wirelessly using the included remote control (range up to 16.5ft). The remote is magnetic and can be attached to metal surfaces for easy access.



Detailed image of the remote control, highlighting buttons for 1-hour timer, on/off/matching, brightness adjustment, color temperature adjustment (2700K to 6500K), neutral light mode, night light mode, babyfeeding mode, working mode, and reading mode.

- **Power Button:** Turns the lamp On/Off. Also used for remote pairing.
- **Brightness Adjustment (+/-):** Steplessly adjusts brightness from 10% to 100%.
- **Color Temperature Adjustment (K button):** Cycles through preset color temperatures or allows stepless adjustment between 2700K (Warm White) and 6500K (Cool White).
- **Preset Modes:**
 - **Night Light Mode:** Provides a very dim, warm light.
 - **Babyfeeding Mode:** A soft, gentle light suitable for nurseries.
 - **Working Mode:** Brighter, cooler light for focus.
 - **Reading Mode:** Optimized light for reading comfort.
- **1-Hour Timer (1H):** Activates a 1-hour countdown timer, after which the lamp will turn off automatically.

5.2 Foot Switch

The lamp also features a convenient foot switch on the power cord for basic On/Off functionality.

5.3 Flexible Lamp Head

The lamp head offers 350° horizontal rotation and 90° vertical adjustment, allowing you to direct light precisely where needed for reading, working, or ambient lighting.

Convenient Remote Control & Different Modes



Image showing the flexible lamp head, capable of 350° horizontal rotation and 90° vertical adjustment for directed lighting.

5.4 Brightness and Color Temperature

The lamp provides stepless adjustment for both brightness and color temperature, allowing you to customize your

lighting experience.



Visual representation of the lamp's ability to adjust color temperature from 2700K (Warm White) to 6500K (Cool White), showing the effect on room ambiance.



Illustration of the lamp's stepless brightness dimming feature, adjustable from 5% to 100% intensity.

6. CARE AND MAINTENANCE

- **Cleaning:** Disconnect the power before cleaning. Wipe the lamp with a soft, dry cloth. Do not use abrasive cleaners or solvents. The inner PVC of the lampshade is waterproof and oil-resistant, while the outer can be cleaned with a damp cloth.
- **Bulb Replacement:** Ensure the lamp is unplugged and cool before replacing the bulb. Use only E26 LED dimming bulbs, Max 60W.
- **Storage:** If storing the lamp for an extended period, disassemble it and store it in its original packaging in a dry, cool place.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	No power, loose connection, faulty bulb.	Check power outlet, ensure plug is fully inserted. Verify all lamp sections are tightly screwed. Replace bulb if necessary.
Remote control not working.	Dead batteries, remote not paired, obstruction.	Replace remote batteries. Re-pair remote (refer to remote instructions). Ensure no obstructions between remote and lamp.
Light flickers or dims unexpectedly.	Loose bulb, unstable power supply, incompatible bulb.	Tighten bulb. Try a different power outlet. Ensure bulb is an E26 LED dimming type.
Lamp is unstable.	Base not securely attached, uneven surface.	Ensure lamp poles are fully screwed into the base. Place lamp on a flat, stable surface.

8. SPECIFICATIONS

Feature	Specification
Model Name	Dimming floor lamp with Lampshade
Model Number	B1383
Product Dimensions	10"D x 10"W x 67"H
Item Weight	6.63 Pounds
Material	Linen, Metal
Finish Type	Matte
Base Material	Metal
Bulb Base	E26
Light Source Type	LED
Wattage	10 watts (Max 60W compatible)
Voltage	120 Volts
Light Color Temperature	2700K-6500K (Adjustable)
Control Method	Remote and Foot Switch
Special Features	Adjustable Color Temperature, Dimmable, Flexible Lamp Head, Remote Control, Timer
Indoor/Outdoor Usage	Indoor
Manufacturer	Xiang He Lighting Co.,Ltd

9. WARRANTY AND SUPPORT

BoostArea products are manufactured with quality and durability in mind. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official BoostArea website. Please retain your proof of purchase for any warranty claims.