

[manuals.plus](#) /

› [WIN STELLAR](#) /

› [WIN STELLAR French Pivot Door Installation and User Manual \(Model: B0DD7JSZ8P\)](#)

WIN STELLAR B0DD7JSZ8P

WIN STELLAR French Pivot Door Installation and User Manual

Brand: WIN STELLAR | **Model:** B0DD7JSZ8P

INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your WIN STELLAR French Pivot Door, Model B0DD7JSZ8P. Designed to maximize space and enhance accessibility, this door features durable, water-resistant, and scratch-resistant mirror and engineering wood panels. Please read all instructions carefully before beginning installation to ensure proper assembly and safe operation.



Image: The WIN STELLAR French Pivot Door, open, showcasing its design and functionality within a modern kitchen setting.

SAFETY INFORMATION

Please observe the following safety precautions during installation and use:

- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, during installation.
- It is recommended to have at least two people for installation due to the size and weight of the door panels.
- Ensure the door opening dimensions are accurate and suitable for the product before beginning installation.
- Use only the provided hardware and recommended tools.
- Keep children and pets away from the installation area.
- Do not attempt to modify the door or hardware, as this may compromise its structural integrity and void the warranty.

PACKAGE CONTENTS

Door Panels

The package includes two door panels constructed from durable mirror and engineering wood, featuring a water-resistant and scratch-resistant surface. These solid core panels are designed for long-lasting use.



Image: Detail of the door panel construction, showing the durable MDF surface and internal layers.

Hardware List

All necessary hardware for installation is included. Please verify that all components are present before starting assembly:



Bottom
Bracket x2



Hanger
Plate x2



Magnet Brackt x1
Magnet Plate x2



Pull Set x2



Top Pivot x2



Wrench x1
Bumper x2



Track



Hardware List

Image: A visual representation of all hardware components provided for the pivot door installation.

- 2x Door Panels
- 1x Magnet Bracket
- 2x Top Pivot
- 1x Wrench
- 3x 5/8" Pan Head Screws
- 2x Magnet Plate
- 2x Mount Plate
- 2x 2" Pan Head Screws
- 10x 1-1/2" Flat Head Screws
- 2x Bottom Pivot
- 2x Jamb Pivot
- 12x 1-1/4" Pan Head Screws
- 2x Pull Set

- 2x Bumper
- 1x Track
- 1x Fascia

TOOLS REQUIRED

The following tools are recommended for installation:

- Tape Measure
- Phillips Screwdriver
- Pencil
- Cordless Drill
- 3/16" Drill Bit
- Level

INSTALLATION INSTRUCTIONS

Installation Video Guide

Your browser does not support the video tag.

Video: Official WIN STELLAR installation instructions for pivot doors, demonstrating each step of the assembly process.

Step-by-Step Written Guide

1. Step 1: Install Top Location and Track

- Insert top pivots into both ends of the track. Ensure securing screws face outward.
- Align the center of the pivot at the 2-1/4 inch mark from the end of the track (both ends).
- Tighten the screws with a Phillips screwdriver.
- Measure 1/4 inch from the front of the opening to correctly position the track.
- Secure the track in place using the 2-1/4 inch pan head Phillips screws.

2. Step 2: Prepare Door Panel Hardware

- At the top of the door panel, position the mounting plate's outer edge 1/2 inch from the door edge. The pivot should be 2 inches from the door edge.
- Secure with 1-1/4 inch pan head screws.
- At the door panel bottom, position the bottom pivot's outer edge 5/8 inch from the door edge. The overall pivot should be 2 inches from the door edge.
- Secure with 1-1/2 inch flat head screws.
- Repeat this installation for the mounting plate and bottom pivot for the second panel.

3. Step 3: Install Jamb Pivot Bracket

- Place the bottom jamb pivot bracket 13/16 inch from the opening front.
- Secure all three holes with 1-1/2 inch flat head screws using a Phillips screwdriver.
- Extend the bracket to 2-1/4 inches and tighten the screw.

4. Step 4: Install Floor Bumper & Adjust Door Panel

- Start the door panel installation from the bottom, engaging the bottom pivot.

- Secure the top mounting plate with the locking latch into the track.
- Position the floor bumper 3-1/2 inches from the door edge and 11/16 inch from the opening front.

5. Step 5: Install Door Pull

- Measure up 36 inches from the bottom of the door.
- Measure 1-1/2 inches inward from the opening edge to determine the knob locations.
- Drill pilot holes and install the door pulls.

6. Step 6: Install Magnetic Catch and Fascia

- With both door panels installed, secure each magnet plate holder to the back of the door panels.
- Peel the double-sided tape off the back of the fascia.
- Apply the fascia directly onto the front surface of the track to conceal the hardware.

OPERATING INSTRUCTIONS

To operate your WIN STELLAR French Pivot Door, gently push or pull the door panels using the installed pulls. The pivot mechanism allows the doors to swing smoothly, maximizing access to your space. Ensure no obstructions are in the path of the door panels when opening or closing.



Image: The WIN STELLAR French Pivot Door in a closed position, demonstrating its aesthetic appeal.

MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your pivot door:

- **Cleaning:** Wipe the door panels and hardware with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the mirror or wood finish.
- **Hardware Check:** Periodically inspect all screws and hardware for tightness. Tighten any loose fasteners to ensure smooth operation and prevent rattling.
- **Pivot Lubrication:** If the pivot mechanism becomes stiff, apply a small amount of silicone-based lubricant to the pivot points.
- **Mirror Care:** Clean the mirror surface with a glass cleaner and a lint-free cloth.

TROUBLESHOOTING

If you encounter any issues with your pivot door, refer to the following common solutions:

- **Door not closing properly:** Check for obstructions in the door's path. Verify that the magnetic catch is aligned and securely installed. Adjust the jamb pivot bracket if necessary to ensure proper alignment.
- **Door rattling:** Ensure all hardware screws, especially those on the top and bottom pivots and mounting plates, are tightened. The magnetic latch should hold the door firmly.
- **Stiff operation:** Lubricate the top and bottom pivot points with a silicone-based lubricant. Check if the track is clean and free of debris.
- **Gap between door panels:** Ensure the door panels are correctly aligned and the pivot points are set according to the installation instructions. Minor adjustments to the jamb pivot bracket may be needed.

SPECIFICATIONS

Key specifications for the WIN STELLAR French Pivot Door (Model: B0DD7JSZ8P):

Feature	Specification
Brand	WIN STELLAR
Model	B0DD7JSZ8P
Color	Full Mirror
Material	Mirror & Engineering Wood
Style	Modern
Product Dimensions	0.83 x 36 x 80 inches
Opening Size	36" x 80.5±0.25"
Item Weight	54.9 pounds
Assembly Required	Yes

Mounting Type

Floor Mount

Size Chart



Pivot Door Size Chart

Size Choice	Each Panel Size	Number of Panels Included	Fit Opening Width
24" * 80"	11 3/4" W x 77 3/4" H	2	24"
30" * 80"	14 3/4" W x 77 3/4" H	2	30"
36" * 80"	17 3/4" W x 77 3/4" H	2	36"
48" * 80"	23 3/4" W x 77 3/4" H	2	48"
60" * 80"	29 3/4" W x 77 3/4" H	2	60"

Image: A comprehensive size chart illustrating different door opening options and their respective panel sizes.

WARRANTY AND SUPPORT

WIN STELLAR is committed to providing quality products and customer satisfaction. If you experience any issues, require replacement parts, or have questions regarding your French Pivot Door, please contact our customer support team. Refer to your purchase documentation for specific warranty details and contact information.