



Manuals.plus /

› Accutime /

› Accutime Marvel Venom Kids Watch Instruction Manual

Accutime Marvel Venom Watch

Accutime Marvel Venom Kids Watch Instruction Manual

Model: Marvel Venom Watch

INTRODUCTION

This manual provides essential information for the setup, operation, and maintenance of your Accutime Marvel Venom Kids Watch. Please read these instructions carefully to ensure proper use and longevity of the product.



Figure 1: Front view of the Marvel Venom Kids Watch, displaying the LCD screen and light-up bezel.

SETUP

1. Unboxing

Carefully remove the watch from its packaging. The watch typically comes in a decorative tin box. Ensure all components are present and undamaged.



Figure 2: The Marvel Venom Kids Watch presented in its themed tin box.

2. Adjusting the Strap

The watch features an adjustable plastic strap designed for a comfortable and secure fit. To adjust, simply thread the strap through the buckle and select the hole that provides a snug fit without being too tight on the wrist.






Figure 3: The watch strap detached from the watch face, illustrating the adjustable buckle and strap holes.

OPERATING INSTRUCTIONS

1. Reading the LCD Display

The watch is equipped with a clear LCD display that shows the time in a digital format. The time is continuously

displayed for easy readability.

2. Activating the Light-Up Bezel

To activate the multi-colored rotating lights on the bezel, press the button located on the side of the watch case. The lights will illuminate and rotate for a short duration before automatically turning off.



Figure 4: Side profile of the watch, highlighting the button used to activate the light-up bezel.

3. Setting the Time

This watch model is primarily designed for its display and light features. Time setting capabilities may be limited or pre-set at the factory. If time adjustment is possible, it typically involves a small, recessed button on the side or back of the watch that requires a pointed object (like a pen tip) to press. Please refer to the original product packaging or contact Accutime customer support for specific time-setting instructions if needed.

MAINTENANCE

1. Cleaning

To clean the watch, wipe it gently with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the plastic case, strap, or display. The watch is not waterproof; avoid submerging it in water.

2. Battery Replacement

The watch is powered by two LR41 (1.5V) Lithium Ion batteries. When the display dims or the lights stop working, it may be time to replace the batteries. Battery replacement should ideally be performed by an adult or a qualified technician to ensure proper sealing and function. The battery compartment is located on the back of the watch.



Figure 5: Rear view of the watch, indicating the battery compartment and product details.

3. Storage

Store the watch in a cool, dry place away from direct sunlight and extreme temperatures to prevent damage to the plastic components and internal electronics.

TROUBLESHOOTING

- **Display is blank or dim:** This usually indicates low battery power. Replace the two LR41 (1.5V) batteries.
- **Lights are not working:** Check the battery level. If the display is working but lights are not, ensure the light activation button is being pressed firmly. If the issue persists after battery replacement, contact support.
- **Time is incorrect or cannot be set:** As noted in the operating instructions, time setting on this model may be limited. If the time is significantly off and cannot be adjusted via any visible buttons, it might be a fixed-time display or require specific instructions not provided with the watch itself. Consult the original packaging or Accutime customer support.

- **Watch appears damaged:** Discontinue use if the watch casing is cracked or broken, especially if internal components or batteries are exposed.

SPECIFICATIONS

Model Number	Marvel Venom Watch (VEN4002AZ)
Display Type	LCD Digital
Power Source	2 x LR41 (1.5V) Lithium Ion Batteries (included)
Case Material	Durable Plastic
Strap Material	Adjustable Plastic
Features	Light-Up Bezel with Rotating Lights
Approximate Dimensions	3.98 x 3.19 x 3.11 inches (Packaged)
Weight	2 ounces (Packaged)

WARRANTY AND SUPPORT

For warranty information or technical support, please contact Accutime directly. Refer to the contact details provided on the product packaging or visit the official Accutime website for the most current support information.

Manufacturer: Accutime