

[Manuals.plus](#) /

› [YOTON](#) /

› YOTON YM07 MP3 Player User Manual

YOTON YM07

YOTON YM07 MP3 Player User Manual

Model: YM07

1. INTRODUCTION

The YOTON YM07 MP3 Player is a portable music device designed for ease of use and high-quality audio playback. Featuring a 2.4-inch full touchscreen, Bluetooth 5.2 connectivity, and multi-functional capabilities, it is an ideal companion for music on the go. This manual provides comprehensive instructions for setting up, operating, and maintaining your device.



Figure 1: YOTON YM07 MP3 Player

2. PACKAGE CONTENTS

Upon unboxing your YOTON YM07 MP3 Player, please ensure all the following items are included:

- YOTON YM07 MP3 Player
- Type-C USB Cable
- 3.5mm Wired Earphones
- 64GB TF Card (pre-inserted in the MP3 player)
- Quick Guide / User Manual

Package List



Figure 2: Complete Package Contents

3. PRODUCT FEATURES AND COMPONENTS

- **2.4-inch Full Touchscreen:** For intuitive navigation and control.
- **Bluetooth 5.2:** Seamless wireless connection to headphones and speakers.
- **80GB Storage:** 16GB internal memory with a pre-installed 64GB TF card, expandable up to 128GB.
- **HiFi Sound:** Delivers pure, high-fidelity audio experience.
- **Built-in Speaker:** For direct audio playback without earphones.
- **Multi-functional:** Includes FM radio, voice recorder, e-book reader, calculator, stopwatch, and alarm clock.
- **Lightweight Design:** Weighs only 61g, making it highly portable.

Smooth Touch Screen



2.4-inch



Touch screen



Home



Figure 3: Touchscreen Interface

More Than A Music Player




Figure 4: Multi-functional Capabilities

4. BASIC SETUP AND GETTING STARTED

Before first use, it is recommended to fully charge your MP3 player. Connect the device to a USB power source using the provided Type-C USB cable. The battery icon on the screen will indicate charging status.

5. TRANSFERRING FILES TO THE MP3 PLAYER

You can easily transfer music, videos, and other supported files from your computer to the YOTON YM07 MP3 Player.

1. Connect the MP3 player to your computer using the provided USB cable.
2. The MP3 player screen will display "Charging and Transfer" indicating a successful connection.
3. On your computer, locate the disks named "Yoton-YM07" (for internal storage) and "USB Drive" (for the TF Card Storage).
4. Drag and drop your desired files into the respective folders on the MP3 player. Ensure songs are numbered with three digits for proper sorting.

5. Once transfer is complete, safely eject the MP3 player from your computer before unplugging the USB cable.

Video 1: Steps for transferring files to the YM07 MP3 Player.

6. CONNECTING WITH BLUETOOTH DEVICES

The YM07 MP3 Player supports Bluetooth 5.2 for wireless audio streaming.

1. Ensure your Bluetooth device (headphones, speaker) is in pairing mode.
2. On the MP3 player, navigate to the Bluetooth settings.
3. Activate the Bluetooth function and select "Search for Devices".
4. Choose your device from the list and wait for pairing. The Bluetooth icon on the MP3 player will turn green once connected.

Video 2: Guide to connecting your YM07 MP3 Player to Bluetooth devices.



Figure 5: Stable Bluetooth Connection

7. USING OTHER FUNCTIONS

7.1 FM Radio

To use the FM radio, plug in the wired earphones as they act as the antenna. Navigate to the FM Radio icon on the main screen. You can manually tune or use the auto-tune feature to find available stations. You can also record FM broadcasts.

7.2 Voice Recorder

The MP3 player has a built-in microphone for voice recording. Select the Voice Recorder icon, then choose "Start Voice Recording". Recordings are saved in WAV or MP3 format and can be accessed via the Recordings Library.

7.3 E-book Reader

The device supports e-books in TXT format. Transfer your TXT files to the player and open them via the E-book icon.

7.4 Calculator, Stopwatch, and Alarm Clock

Access these utility functions from the main menu. The alarm clock can be set with multiple alarms and uses the built-in speaker or connected earphones for alerts.

Video 3: Detailed introduction to the YM07 MP3 Player's various functions.

8. TROUBLESHOOTING

- **Device not turning on:** Ensure the battery is charged. Press and hold the power button for 10 seconds to perform a reset.
- **Cannot connect to computer:** Try a different USB port or cable. Ensure the MP3 player displays "Charging and Transfer" upon connection.
- **Bluetooth pairing issues:** Ensure the external Bluetooth device is in pairing mode. Turn Bluetooth off and on again on the MP3 player and re-scan for devices.
- **Poor sound quality:** Check earphone connection. Ensure audio files are not corrupted. Adjust equalizer settings.

9. SPECIFICATIONS

Feature	Detail
Product Dimensions	2.64 x 1.97 x 0.35 inches
Item Weight	2.39 ounces (61g)
Item Model Number	YM07
Batteries	1 Lithium Ion battery required (included)
Memory Storage Capacity	16 GB (internal), 64 GB (TF card included), 128 GB (expandable)
Connectivity Technology	Bluetooth 5.2
Screen Size	2.4 Inches

Supported Media Types	MP3, WMA, OGG, APE, FLAC, WAV, AAC (Music); AVI, AMV (Video); JPEG, BMP, GIF (Image); TXT (E-book)
-----------------------	--

10. WARRANTY AND SUPPORT

YOTON offers comprehensive after-sale support for your peace of mind:

- **24-Hour Prompt Response:** For any inquiries or issues.
- **30-Day Return Policy:** If you are not satisfied with your purchase.
- **One-Year Repair Service:** For manufacturing defects.
- **Lifetime Professional Support:** Assistance throughout the product's lifespan.

For support, please contact YOTON Direct via their official channels or the contact information provided in the Quick Guide.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question