



[Manuals.plus](#) /

› [ZEYUAN](#) /

› ZEYUAN Reclining Garden Chairs User Manual

## **ZEYUAN 365672**

# **User Manual**

## **ZEYUAN RECLINING GARDEN CHAIRS (MODEL: 365672)**

---

### **1. Introduction**

---

Thank you for choosing the ZEYUAN Reclining Garden Chairs. This manual provides essential information for the safe and efficient use, assembly, maintenance, and troubleshooting of your new garden chairs. Please read this manual thoroughly before use and retain it for future reference.



Image 1.1: Overview of the ZEYUAN Reclining Garden Chairs set on a patio.

## 2. Safety Instructions

- Ensure all components are securely assembled before use.
- Do not exceed the maximum weight capacity (if known, otherwise state general caution).
- Keep children and pets away from the chairs during assembly.
- Avoid placing the chairs on uneven surfaces to prevent tipping.
- Protect the chairs from extreme weather conditions (heavy rain, strong winds, prolonged direct sunlight) to prolong their lifespan.

## 3. Package Contents

Please check the package contents carefully. If any parts are missing or damaged, contact customer support immediately.

- 2 x ZEYUAN Reclining Garden Chairs (Polyrattan frame)

- 2 x Thick Padded Cushions (Grey)
- Assembly hardware (if any, otherwise state "Pre-assembled components")

#### 4. Setup

---

The ZEYUAN Reclining Garden Chairs are largely pre-assembled. Follow these steps to prepare them for use:

1. Carefully remove all packaging materials.
2. Place the chairs on a flat, stable surface in your desired outdoor location.
3. Unpack the cushions and place them onto the chairs, ensuring they are properly aligned for comfortable seating.
4. Inspect the chairs for any signs of damage or loose components before first use.





Image 4.1: Front view of the ZEYUAN Reclining Garden Chair, ready for cushion placement.

## 5. Operating Instructions

The chairs feature an adjustable backrest and footrest for optimal comfort.

1. **Adjusting Recline:** Locate the handle on the side of the chair (as shown in Image 5.1). Pull this handle to release the locking mechanism.
2. While holding the handle, gently lean back to recline the backrest and extend the footrest to your desired position. Release the handle to lock the chair in place.
3. **Returning to Upright Position:** Pull the handle again and gently push forward with your body weight to bring the backrest and footrest back to their original upright position. Release the handle to lock.





Image 5.1: Side view illustrating the location of the reclining handle.




Image 5.2: Detailed view of the reclining mechanism handle.



Image 5.3: Visual representation of the chair's reclining movement.

## 6. Maintenance

Proper maintenance will ensure the longevity and appearance of your ZEYUAN garden chairs.

- **Polyrattan Frame:** Clean the PE rattan regularly with a soft cloth dampened with mild soap and water. Rinse thoroughly with clean water and dry completely. Avoid harsh chemicals or abrasive cleaners.
- **Cushions:** The cushions are designed for outdoor use but should be stored indoors during heavy rain or off-season to prevent mildew and fading. Spot clean with a damp cloth and mild detergent. Allow to air dry completely before storing.
- **General Care:** Periodically check all screws and connections to ensure they are tight. If the chairs are exposed to direct sunlight for extended periods, consider using a protective cover when not in use to prevent UV damage.



Image 6.1: Detail of the cushion and polyrattan material, highlighting areas for cleaning.

## 7. Troubleshooting

Problem	Possible Cause	Solution
Chair does not recline smoothly.	Mechanism might be stiff or obstructed.	Ensure the handle is fully pulled. Check for any debris obstructing the mechanism. Apply a silicone-based lubricant if necessary.
Chair feels unstable.	Uneven surface or loose connections.	Move the chair to a flat, level surface. Check and tighten all visible screws and bolts.

Problem	Possible Cause	Solution
Cushions appear flattened or discolored.	Prolonged exposure to elements or heavy use.	Fluff cushions regularly. Store cushions indoors when not in use or during adverse weather. Clean as per maintenance instructions.

## 8. Specifications

---

- **Brand:** ZEYUAN
- **Model:** 365672
- **Material:** PE Rattan (Polyrattan), Metal Frame, Fabric Cushions
- **Color:** Grey (Rattan and Cushions)
- **Features:** Adjustable backrest and footrest, Thick padded cushions, Weather-resistant PE rattan.
- **Quantity:** 2 chairs per set

## 9. Warranty and Support

---

For warranty information, product support, or to report missing/damaged parts, please contact the seller directly through your purchase platform. Keep your purchase receipt as proof of purchase.

For general inquiries, you may also visit the ZEYUAN official website (if applicable) or refer to the contact information provided with your purchase.