

[Manuals.plus](#) /

› [Xixini](#) /

› Xixini 6-Drawer Dresser Instruction Manual

Xixini HLG014-WH

Xixini 6-Drawer Dresser Instruction Manual

Model: HLG014-WH

INTRODUCTION

Thank you for choosing the Xixini 6-Drawer Dresser. This modern chest of drawers is designed to provide ample storage and enhance the aesthetic of your living space. Crafted from durable P2 engineered wood, it offers a sturdy and scratch-resistant surface suitable for long-term use. Each drawer is equipped with smooth-gliding rails and metal handles for easy operation. This manual provides essential information for assembly, usage, maintenance, and troubleshooting to ensure optimal performance and longevity of your dresser.



Image: The Xixini 6-Drawer Dresser, white, with six drawers and black metal handles, positioned in a bedroom setting with decorative items on top.

SAFETY INFORMATION

To ensure safe use of your Xixini dresser, please adhere to the following guidelines:

- **Anti-Tipping Device:** It is crucial to install the included anti-tip kits to prevent the dresser from tipping over, especially in households with children or pets. Follow the assembly instructions carefully for proper installation.
- **Weight Capacity:** The thickened top surface of the dresser can support up to 150 lbs (68 kg). Each drawer is designed to hold up to 35 lbs (15.8 kg). Do not exceed these weight limits to prevent damage or instability.
- **Even Distribution:** Distribute weight evenly across the top surface and within the drawers to maintain balance and stability.
- **Placement:** Place the dresser on a flat, level surface. Uneven surfaces can compromise stability.

Ample Storage Space



40+
Shirt



25+
Toys



70+
Socks



40+
Snacks



50+
Underwear



30+
Tissue



Image: A diagram illustrating the dresser's dimensions (47.24"W x 15.75"D x 29.52"H), the 150 lbs top weight capacity, 35 lbs drawer capacity, and a visual guide for installing the anti-tipping device.

PACKAGE CONTENTS

Upon opening the package, please verify that all components and hardware are present and undamaged. A detailed parts list and hardware pack are typically included within the packaging. If any items are missing or damaged, please contact customer support immediately.

SETUP (ASSEMBLY INSTRUCTIONS)

Assembly of the Xixini 6-Drawer Dresser is required. Please follow the step-by-step instructions provided in the separate assembly manual included with your product.

1. **Preparation:** Clear a spacious area for assembly. Lay out all parts on a soft, clean surface to prevent scratches.
2. **Tools Required:** Typically, a Phillips head screwdriver and a hammer are needed (not included).

3. **Follow Manual:** Refer to the numbered steps and diagrams in your specific assembly manual for precise instructions on attaching panels, installing drawer slides, and assembling drawers.
4. **Drawer Assembly:** Ensure drawer components are aligned correctly for smooth operation. The drawers feature built-in slide rails for easy opening and closing.
5. **Anti-Tipping Device Installation:** This is a critical safety step. Securely attach the anti-tipping device to the dresser and to a wall stud as per the instructions. This prevents accidental tipping.
6. **Final Check:** Once assembled, ensure all screws are tightened and the dresser is stable.



Image: Detailed views of the dresser's construction, highlighting the metal corner decor, the stable base design, the black metal handle, and the smooth, natural texture of the surface.

OPERATING (USAGE)

The Xixini 6-Drawer Dresser is designed for versatile storage and display.

- **Drawer Use:** Gently pull and push the drawers using the metal handles. The built-in slide rails ensure smooth

operation. Avoid forcing drawers open or closed.

- **Storage Capacity:** The six deep drawers provide ample space for organizing clothes, blankets, scarves, socks, and other accessories. Each drawer measures approximately 21.45"W x 13.78"D.
- **Top Surface:** The wide wooden tabletop can be used as a dresser, TV stand, entertainment center, or for displaying decorative items, photo frames, and plants. Ensure items placed on top do not exceed the 150 lbs weight limit.
- **Versatile Placement:** This modern wooden dresser is suitable for various spaces, including bedrooms, living rooms, hallways, entryways, and closets. It is an ideal choice for both large and small living areas.



Image: An illustration demonstrating the ample storage capacity of the dresser, indicating it can hold over 40 shirts, 25 toys, 70 pairs of socks, 40 snacks, 50 pieces of underwear, and 30 tissues.

MAINTENANCE

Proper care will help maintain the appearance and functionality of your dresser.

- **Cleaning:** For easy cleaning, simply wipe the surface with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish. Air-dry the surface after wiping.

- **Spills:** Wipe up spills immediately to prevent water damage or staining. The dresser surface is designed to be waterproof.
- **Scratch Resistance:** While the material is scratch-resistant, avoid dragging sharp or heavy objects across the surface to prevent damage.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration over time.



Image: A close-up view highlighting the dresser's waterproof and easy-to-clean surface, the anti-tipping device attached to the wall, and the smooth operation of the sliding drawers.

TROUBLESHOOTING

If you encounter any issues with your Xixini dresser, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Misaligned drawer slides, debris in tracks, or uneven assembly.	◦ Check that drawer slides are correctly installed and aligned. ◦ Clean any dust or debris from the drawer tracks. ◦ Ensure the dresser is on a level surface. ◦ Verify all assembly screws are tightened.
Dresser feels wobbly or unstable.	Loose connections, uneven floor, or anti-tip device not installed.	◦ Tighten all assembly screws. ◦ Ensure the dresser is placed on a flat, level surface. ◦ Install the anti-tipping device securely to a wall stud.
Damage to surface (scratches, stains).	Sharp objects, excessive force, or harsh cleaning agents.	◦ Use a soft, damp cloth for cleaning. ◦ Avoid abrasive materials or chemical cleaners. ◦ For minor scratches, furniture repair kits may be used (consult manufacturer for recommendations).

SPECIFICATIONS

Feature	Detail
Brand	Xixini
Model Name	6 Drawer Dresser
Model Number	HLG014-WH
Product Dimensions	15.75"D x 47.2"W x 29.5"H (approx. 40cm D x 120cm W x 75cm H)
Color	White (also available in Black, Brown, Grey)
Item Weight	80.9 Pounds (36.4 kg)
Material	P2 Engineered Wood
Mounting Type	Floor Mount
Room Type	Bedroom, Closet, Entryway, Hallway, Living Room
Special Features	Adjustable Feet, Safety Stop (Anti-tip kit), Scratch Resistant, Space Saving, Waterproof
Drawer Type	Center Mounted Slide
Assembly Required	Yes
Top Surface Weight Capacity	Up to 150 lbs

Feature	Detail
Drawer Weight Capacity	Up to 35 lbs per drawer

WARRANTY AND SUPPORT

For any questions, concerns, or assistance with your Xixini dresser, please contact Xixini customer support.

- **Return Policy:** This product is typically eligible for a 30-day return policy from the date of purchase. Please refer to the retailer's specific return policy for details.
- **Protection Plans:** Extended protection plans may be available for purchase from third-party providers. Check with your retailer for options.
- **Manufacturer Support:** For direct support from Xixini, please visit the official Xixini store or contact their customer service channels. You can find more information at the [Xixini Store on Amazon](#).

© 2024 Xixini. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DDC1647Z>

More documents and user manuals: <https://manuals.plus/>