

[Manuals.plus](#) /

› [Coleshome](#) /

› Coleshome 63 Inch Computer Desk Instruction Manual

Coleshome B0DDCB53YL

Coleshome 63 Inch Computer Desk Instruction Manual

Model: B0DDCB53YL

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Coleshome 63 Inch Computer Desk. Please read this manual thoroughly before beginning assembly and retain it for future reference.

SAFETY INFORMATION

Always follow basic safety precautions when assembling and using this product to reduce the risk of injury or damage. Ensure all components are securely fastened before use. Do not overload the desk beyond its specified weight capacity.

- Keep small parts away from children.
- Assemble on a clean, flat, and soft surface to prevent scratches.
- Do not use power tools for assembly unless specifically instructed, as overtightening can damage components.
- Ensure the desk is placed on a level surface to prevent instability.

PACKAGE CONTENTS

Before assembly, verify that all parts listed in the assembly guide (included in the package) are present and undamaged. Contact customer support if any parts are missing or defective.



Image: The Coleshome 63 Inch Computer Desk, showcasing its design and potential use in a dual-workstation setup.

SETUP AND ASSEMBLY

The Coleshome 63 Inch Computer Desk is designed for straightforward assembly. All necessary tools are included in the package. Assembly typically takes approximately 30 minutes.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches.
2. **Identify Parts:** Refer to the included assembly diagram to identify each component (desktop panels, frame pieces, screws, etc.). Note that there are primarily two sizes of screws.
3. **Assemble Frame:** Attach the metal frame pieces together using the provided screws and hex key. Ensure all connections are snug but do not overtighten until all frame pieces are in place.
4. **Attach Desktop Panels:** Carefully place the desktop panels onto the assembled frame. It may be easier to position the desktop by resting it across a stable surface like a sofa before aligning it with the frame. Secure the desktop panels to the frame using the remaining screws.
5. **Install Accessories:** If included, attach the headphone hook to the desired location on the desk frame.
6. **Level the Desk:** Adjust the feet pads at the bottom of each desk leg to ensure the desk is stable and level on your floor. Consider adding felt pads to the feet if placing the desk on easily scratchable flooring.

Dimensions

Ergonomic height and width




Image: Dimensional overview of the desk, indicating its length, depth, and height for ergonomic setup.

OPERATING INSTRUCTIONS (USAGE)

The Coleshome 63 Inch Computer Desk is designed for versatile use in various environments, including home offices, study areas, and gaming setups.

- **Workstation Setup:** The spacious 63-inch (L) x 21.7-inch (W) desktop provides ample room for multiple monitors, a printer, and other office essentials.
- **Study Area:** Suitable for students, offering a dedicated surface for books, laptops, and writing materials.
- **Gaming Desk:** Accommodates gaming setups with space for large monitors, keyboards, mice, and other peripherals.
- **Conference Table:** Its generous length allows it to function as a small conference table or a large workstation for collaborative tasks.
- **Weight Capacity:** The desk is designed to support a maximum weight of approximately 110 pounds (50 kg). Distribute weight evenly across the desktop.



Image: The desk configured for a single-user home office setup, highlighting its spacious surface.



Image: Illustrates the desk in a relaxed home environment, suitable for various daily activities.



Image: The desk optimized for a gaming setup, demonstrating its capacity for extensive equipment.

MAINTENANCE AND CARE

Proper care will ensure the longevity and appearance of your Coleshome computer desk.

- **Cleaning:** The melamine veneer tabletop is waterproof, heat-resistant, and dust-free. For routine cleaning, simply wipe the surface with a damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Spills:** Wipe up spills immediately to prevent water damage, although the surface is designed to be waterproof.
- **Protection:** While the desktop is scratch-resistant, using coasters for drinks and pads under heavy or sharp objects is recommended to maintain its pristine condition.
- **Frame Care:** The heavy-duty powder-coated steel frame can be wiped clean with a damp cloth.
- **Regular Checks:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary to maintain stability.

Premium Desktop

| Made of Particleboard



Easy to clean



Waterproof



Scratch-Resistant

Image: Close-up view of the desktop material, highlighting its durability and ease of maintenance.

TROUBLESHOOTING

If you encounter any issues with your Coleshome 63 Inch Computer Desk, refer to the following common solutions:

- **Desk is Wobbly:**

- Ensure all screws are securely tightened.
- Adjust the leveling feet at the bottom of each leg to compensate for uneven flooring.
- Verify that the desk is placed on a flat, stable surface.

- **Missing or Damaged Parts:**

- Carefully re-check the packaging and assembly guide to confirm all parts were accounted for.
- Contact Coleshome customer support immediately for assistance with replacements.

- **Difficulty Assembling:**

- Review the assembly instructions and diagrams carefully.
- Ensure you are using the correct screws for each step.
- Do not force components together; if parts do not fit, re-check alignment.

SPECIFICATIONS

Brand	Coleshome
Model Number	B0DDCB53YL
Desk Design	Computer Desk
Shape	Rectangular
Product Dimensions (L x W x H)	160 cm x 54.9 cm x 73.7 cm (63 in x 21.7 in x 29 in)
Color	Vintage and Black
Style	Modern
Top Material Type	Engineered Wood (Melamine Veneer)
Frame Material	Alloy Steel (Powder-Coated)
Tabletop Thickness	0.6 inches
Maximum Weight Capacity	Approximately 110 lbs (50 kg)
Special Features	Waterproof, Heat-Resistant, Scratch-Resistant Desktop, Leveling Feet
Recommended Uses	Office, Writing, Gaming

Warranty Information

Coleshome products are manufactured to high-quality standards. While specific warranty details are not provided in this manual, please retain your proof of purchase. For any warranty-related inquiries or claims, contact Coleshome customer support directly.

Customer Support

Your satisfaction is important to Coleshome. If you have any questions, concerns, or require assistance with your product, please do not hesitate to contact our customer support team. We are available to help you before and after your purchase.

Please refer to the contact information provided with your product packaging or visit the official Coleshome website for support details.

Ask a Question About This Manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DDCB53YL>

More documents and user manuals: **<https://manuals.plus/>**