

[Manuals.plus](#) /

› [Briloner](#) /

› BRILONER Mini LED Table Lamp Instruction Manual - Model 7561011

Briloner 7561011

BRILONER Mini LED Table Lamp - Model 7561011

Instruction Manual

1. INTRODUCTION

Thank you for choosing the BRILONER Mini LED Table Lamp. This wireless, touch-dimmable lamp is designed for versatile use, both indoors and outdoors, thanks to its IP54 rating. Please read this manual carefully before using the product to ensure proper operation and to maximize its lifespan. Keep this manual for future reference.

2. SAFETY INSTRUCTIONS

- Do not expose the lamp to extreme temperatures or direct sunlight for extended periods.
- Avoid dropping the lamp or subjecting it to strong impacts.
- Do not immerse the lamp in water. While it is IP54 rated for splash protection, it is not waterproof.
- Only use the provided USB-C cable for charging.
- Keep out of reach of children.
- Do not attempt to open or repair the lamp yourself, except for battery and light source replacement as instructed.
- Ensure the mechanical on/off switch is in the 'off' position when storing the lamp for long periods to prevent deep discharge of the battery.

3. PACKAGE CONTENTS

Please check that all items are present in the package:

- BRILONER Mini LED Table Lamp (Model 7561011)
- USB-C Charging Cable
- Instruction Manual

4. PRODUCT OVERVIEW

The BRILONER Mini LED Table Lamp features a compact design with a wooden-look base and a spherical light diffuser. It is equipped with a touch sensor for dimming and a mechanical switch on the base.



Image 1: BRILONER Mini LED Table Lamp highlighting key features: wireless operation, 2700K warm white light, IP54 protection, and 3-step touch dimming (15%, 50%, 100%).



Image 2: Underside of the lamp showing the USB-C charging port and the mechanical On/Off switch, along with an indication of replaceable battery and light source.

5. SETUP

5.1 Initial Charging

1. Before first use, fully charge the lamp.
2. Connect the provided USB-C cable to the charging port located on the underside of the lamp.
3. Connect the other end of the USB-C cable to a suitable USB power adapter (not included).
4. The charging indicator (if present, refer to product for specific indicator) will show charging status.
5. Once fully charged, disconnect the cable.

5.2 Placement

Place the lamp on a stable, flat surface. Its IP54 rating makes it suitable for both indoor and outdoor environments,

offering protection against dust and splashing water.



Image 3: The lamp placed on an outdoor table, demonstrating its suitability for various settings.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off

1. Locate the mechanical On/Off switch on the underside of the lamp.
2. Flip the switch to the 'On' position to enable the lamp's touch functionality.
3. To completely power off the lamp and prevent battery drain during long storage, flip the switch to the 'Off' position.

6.2 Adjusting Brightness (Touch Dimmer)

The lamp features a 3-step touch dimmer:

1. With the mechanical switch 'On', touch the metallic area on the lamp's base (often indicated by a power symbol) to turn the light on to its brightest setting (100%).

2. Touch again to cycle to the medium brightness setting (50%).
3. Touch a third time to cycle to the lowest brightness setting (15%).
4. Touch a fourth time to turn the lamp off.




Image 4: Visual representation of the three dimming levels (100%, 50%, 15%) controlled by the touch sensor.

7. MAINTENANCE

7.1 Cleaning

- Ensure the lamp is turned off and disconnected from any charging source before cleaning.
- Wipe the lamp with a soft, dry cloth.
- For stubborn dirt, a slightly damp cloth can be used, but ensure no water enters the charging port or internal components.
- Do not use abrasive cleaners or solvents.

7.2 Battery and Light Source Replacement

The BRILONER Mini LED Table Lamp is designed for longevity with replaceable battery and LED light source components. This process should ideally be performed by a qualified technician or by following specific instructions provided by Briloner Leuchten. Attempting replacement without proper guidance may void your warranty or damage the product.



Image 5: Illustration emphasizing the lamp's sustainable design, including replaceable battery and light module, repairability, USB-C charging, and compliance with EU directives for 2027.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Battery is depleted. Mechanical switch is off.	Charge the lamp. Ensure the mechanical switch on the underside is in the 'On' position.

Problem	Possible Cause	Solution
Lamp does not dim.	Touch sensor malfunction or improper touch.	Ensure you are touching the designated touch area. Try turning the lamp off and on again using the mechanical switch.
Short battery life.	Battery degradation. Frequent use at highest brightness.	Consider replacing the battery (refer to Section 7.2). Use lower brightness settings when possible.
Charging not working.	Faulty cable or adapter. Charging port issue.	Try a different USB-C cable and power adapter. Ensure the cable is fully inserted.

9. SPECIFICATIONS

- Model Number:** 7561011
- Brand:** Briloner
- Dimensions (L x W x H):** 9 x 8 x 10 cm (approximately 3.5 x 3.1 x 3.9 inches)
- Weight:** 122 g
- Light Source:** Integrated LED
- Color Temperature:** 2700 Kelvin (Warm White)
- Luminous Flux:** 150 Lumens
- Dimmable:** Yes, 3-step touch dimmer (100%, 50%, 15%)
- Battery:** 1 Lithium Ion (included, replaceable)
- Charging Port:** USB-C
- Protection Rating:** IP54 (Dust protected, splash-proof)
- Base Material:** Wood (finish)
- Shade Material:** Wood (finish) / Diffuser




Image 6: Dimensional drawing of the BRILONER Mini LED Table Lamp, indicating its compact size.

10. WARRANTY AND SUPPORT

10.1 Warranty Information

Briloner Leuchten products are manufactured with high-quality materials and undergo strict quality control. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Briloner Leuchten website. Keep your proof of purchase for warranty claims.

10.2 Customer Support

If you encounter any issues or have questions regarding your BRILONER Mini LED Table Lamp that are not covered in this manual, please contact Briloner Leuchten customer support. Contact details can typically be found on the product packaging or the official Briloner Leuchten website.

Briloner Leuchten Official Website: www.briloner.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DDCF4QL5>

More documents and user manuals: <https://manuals.plus/>