

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [BUGANI](#) /

› [BUGANI Bluetooth Speaker User Manual](#)

BUGANI M192

BUGANI Bluetooth Speaker User Manual

Model: M192 | Brand: BUGANI

INTRODUCTION

Thank you for choosing the BUGANI Bluetooth Speaker. This powerful and versatile speaker is designed to deliver high-fidelity audio with deep bass and clear highs, perfect for both indoor and outdoor environments. Featuring advanced Bluetooth 5.4 technology, TWS connectivity, and a durable, portable design, it ensures an immersive listening experience wherever you go. Please read this manual carefully to ensure proper use and maintenance of your speaker.



Image: Front view of the BUGANI Bluetooth Speaker in gold and black, showcasing its sleek design and integrated handle.

WHAT'S IN THE BOX

Please check the contents of your package to ensure all items are present:

- 1 x BUGANI Brief Pro Speaker
- 1 x USB-C Cable
- 1 x AUX IN Cable
- 1 x User Manual
- 1 x Quick Start Guide

What's in the Package

- | | |
|------------------------|------------------|
| ❶ BUGANi Brief Pro *1 | ❷ USB-C Cable *1 |
| ❸ AUX IN Cable *1 | ❹ User Manual *1 |
| ❺ Quick Start Guide *1 | |



Image: The BUGANI Brief Pro speaker, USB-C cable, AUX cable, user manual, and quick start guide laid out, indicating package contents.

PRODUCT FEATURES

Powerful 160W Audio System

Experience thunderous low-end clarity and rich sound with the BUGANI speaker's 160W peak output. It features a rear-mounted super-sized passive bass radiator, two 4-inch subwoofers, and two 1.6-inch tweeters (41mmx2) with AK-Y Silk Film Material for low distortion and natural sound up to 50kHz.



Image: An exploded view of the speaker's internal components, highlighting the 4-inch subwoofers and 1.6-inch tweeters, and the 160W power output.

Hi-Res Audio Support

The BUGANI Brief Pro is Hi-Res Audio certified, delivering exceptional detail and clarity to your music. Rediscover the charm of jazz and other genres with pure, rich sound that brings melodies, rhythms, and bass lines to life.



Image: The BUGANI speaker prominently displaying Hi-Res Audio and Hi-Res Audio Wireless certifications, emphasizing its high-fidelity sound capabilities.

Bluetooth 5.4 and TWS Connectivity

Equipped with the latest Bluetooth 5.4 module, the speaker ensures stable pairing, extended range, and high-fidelity sound. Utilize True Wireless Stereo (TWS) technology to connect two BUGANI Brief Pro speakers for an even more immersive stereo sound experience.

TWS Connection



Image: Two BUGANI speakers shown connecting wirelessly via TWS (True Wireless Stereo) technology, indicating stereo pairing capability.

12-Hour Playtime & Portable Design

Enjoy up to 12 hours of continuous playtime on a single charge, making it ideal for all-day outdoor use. The speaker features an ergonomic handle design, making it easy to carry and enjoy music anytime, anywhere.

Long Playback

12-Hour Continuous Play



Image: The BUGANI speaker on a golden pedestal, highlighting its 12-hour continuous playtime feature.

Portable Handle

Hear Everywhere



Image: A person carrying the BUGANI speaker by its integrated handle, emphasizing its portability and ease of transport.

Versatile Connectivity & IPX5 Water Resistance

In addition to Bluetooth, the speaker supports AUX and USB inputs, allowing you to connect various devices. With IPX5 water resistance, it is protected against splashing water from any direction, making it suitable for outdoor adventures, beach parties, or poolside enjoyment.

12 Hours of Playtime

Enjoy the outdoor music life to the fullest with 12 hours of playtime.



Image: The BUGANI speaker with water droplets on its surface, illustrating its IPX5 water-resistant feature for outdoor use.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB-C cable to the speaker's charging port and the other end to a compatible USB power adapter (not included). The charging indicator light will show the charging status. A full charge takes approximately 5 hours.

2. Powering On/Off

To power on the speaker, press and hold the power button located on the control panel until you hear an audible prompt. To power off, press and hold the power button again.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing LED).
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "BUGANI Brief Pro" from the list of devices.
4. Once connected, you will hear a confirmation sound, and the LED indicator will become solid.

4. True Wireless Stereo (TWS) Pairing

For an enhanced stereo experience, you can pair two BUGANI Brief Pro speakers together:

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the TWS button (if available, or a specific button designated for TWS pairing, usually indicated in the quick start guide).
3. The speakers will automatically search for and connect to each other. Once paired, you will hear a confirmation sound.
4. Connect your device to the primary speaker via Bluetooth as described in step 3. Audio will now play in stereo through both speakers.

5. AUX/USB Connection

To play audio from devices without Bluetooth, use the provided AUX IN cable or a USB drive:

- **AUX Input:** Connect one end of the 3.5mm AUX cable to the speaker's AUX IN port and the other end to your audio device's headphone jack. The speaker will automatically switch to AUX mode.

- **USB Input:** Insert a USB drive containing audio files into the speaker's USB port. The speaker will automatically switch to USB mode and begin playing.

OPERATING INSTRUCTIONS

Volume Control

The speaker features a prominent rotary knob for volume adjustment. Rotate the knob clockwise to increase volume and counter-clockwise to decrease volume.



Image: A close-up view of the gold rotary volume knob on the BUGANI speaker, indicating its control functionality.

Playback Control

Specific playback controls (play/pause, next/previous track) are typically integrated into the speaker's control panel. Refer to the Quick Start Guide for detailed button functions.

Mode Switching

The speaker automatically switches modes when an AUX cable or USB drive is inserted. To manually switch between Bluetooth, AUX, and USB modes, press the mode button (if available) on the control panel.

Your browser does not support the video tag.

Video: An official product video showcasing the BUGANI Brief Pro Speaker's design, internal components, and key features like 160W power, Bluetooth 5.3 (note: product specs say 5.4, video might be older), and TWS connectivity. This video provides a visual overview of the speaker's capabilities and aesthetic.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker's surface. For stubborn dirt, a slightly damp cloth can be used. Do not use harsh chemicals or abrasive cleaners.
- **Water Resistance:** The speaker is IPX5 water-resistant, meaning it can withstand splashes. Do not submerge the speaker in water or expose it to strong jets of water. Ensure the charging port cover is securely closed when near

water.

- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery; Power button not held long enough.	Charge the speaker fully. Press and hold the power button for 3-5 seconds.
Cannot pair via Bluetooth.	Speaker not in pairing mode; Device Bluetooth off; Too far from speaker; Already connected to another device.	Ensure speaker is flashing LED for pairing. Turn device Bluetooth off/on. Move device closer. Disconnect from other devices.
No sound or low volume.	Volume too low on speaker/device; Incorrect input mode; Cable not fully inserted (AUX).	Increase volume on both speaker and device. Check if speaker is in correct mode (Bluetooth/AUX/USB). Re-insert AUX cable firmly.
Sound distortion.	Volume too high; Low battery; Interference.	Reduce volume. Charge the speaker. Move speaker away from other electronic devices.
TWS pairing failed.	Speakers already connected to other devices; Speakers too far apart.	Ensure both speakers are disconnected from other devices. Place speakers close to each other during pairing.

SPECIFICATIONS

Feature	Detail
Model Name	Brief Pro (M192)
Output Power	160W (Peak)
Speaker Type	Subwoofer
Woofer	4" x 2
Tweeter	1.6" x 2 (41mm x 2)
Bluetooth Version	5.4 (Note: Video mentions 5.3, product specs indicate 5.4)
Special Feature	Hi-Res Audio, TWS Function
Battery Capacity	52.92Wh (Lithium Polymer)
Charging Time	Approx. 5 hours
Play Time	Approx. 12 hours (Normal Volume)
Charging Port	USB-C

Feature	Detail
Water Resistance	IPX5
Product Dimensions	18.5"D x 7.9"W x 7.9"H
Item Weight	10.08 pounds
Connectivity Protocol	Bluetooth
Compatible Devices	Projector, Laptop, MP3 Player, Television, Tablet, Smartphone



Image: A visual representation of the BUGANI Brief Pro speaker's technical specifications, including output power, input types, speaker dimensions, and battery life.

WARRANTY AND SUPPORT


The BUGANI Bluetooth Speaker comes with a **Limited Warranty**. For specific warranty terms and conditions, please refer to the warranty card included in your package or contact BUGANI customer support.


If you encounter any issues or have questions not covered in this manual, please contact BUGANI customer support through the retailer's platform or the official BUGANI website for assistance.

© 2025 BUGANI. All rights reserved.

Related Documents - M192

 BRIEF PRO  QUICK START GUIDE 	Bugani Brief Pro Quick Start Guide A quick start guide for the Bugani Brief Pro real jazz music speaker, covering charging, power, Bluetooth connection, TWS mode, AUX input, button controls, and reset.
--	--


 BUGANI BRIEF PRO BENUTZERHANDBUCH	BUGANI Brief Pro Benutzerhandbuch: Funktionen, Einrichtung und Garantie Umfassendes Benutzerhandbuch für den tragbaren BUGANI Brief Pro Bluetooth-Lautsprecher, das Produktübersicht, Aufladen, Bluetooth- und TWS-Kopplung, Tastenbedienung und eingeschränkte Garantieinformationen abdeckt.
 BUGANI BOOST MAX QUICK START GUIDE	BUGANI BOOST MAX Portable Bluetooth Speaker Quick Start Guide Concise quick start guide for the BUGANI BOOST MAX portable Bluetooth speaker, covering charging, power, Bluetooth pairing, TWS mode, inputs, and button controls.
 BUGANI BUGANI Free B10 OPEN-EAR HEADPHONE USER MANUAL	BUGANI Free B10 Open-Ear Headphone User Manual User manual for the BUGANI Free B10 Open-Ear Wireless Headphones, covering product overview, power, charging, pairing, volume control, call functions, music playback, wearing instructions, voice control, factory reset, indicator lights, and warranty information.
 BUGANI B09 WIRELESS EARBUDS QUICK START GUIDE	BUGANI B09 Wireless Earbuds Quick Start Guide A quick start guide for the BUGANI B09 wireless in-ear earbuds, covering setup, features, controls, and warranty information.
 BUGANI Pro 1 WIRELESS EARBUDS HIGH FIDELITY SOUND	BUGANI Pro 1 Wireless Earbuds User Manual - High Fidelity Sound Comprehensive user manual for BUGANI Pro 1 wireless earbuds, covering functions, wearing, charging, pairing, controls, and specifications. Experience high-fidelity sound with these Bluetooth earbuds.



[Bugani Brief Pro Quick Start Guide](#)

A quick start guide for the Bugani Brief Pro real jazz music speaker, covering charging, power, Bluetooth connection, TWS mode, AUX input, button controls, and reset.

lang:en **score:49** filesize: 5.24 M page_count: 6 document date: 2025-03-21



[\[pdf\] Instructions Guide](#)

BUGANI M192 20250219 m192 instructions à bugani global BUGANi Brief Pro GUIDE DE DEMARRAGE RAPIDE 20250321 v 1742890196 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO GUIDE DE DMARRAGE RAPIDE VRAI HAUT-PARLEUR DE MUSIQUE JAZZ CHARGER L ENCEINTE USB-C RESET AUX IN Lumire rouge clignotante Lumire rouge fixe Ne branchez pas le cble lorsque votre haut-parleur et le port de chargement ne sont pas complètement secs. Laissez votre haut-parleur dans un end...


lang:fr **score:48** filesize: 1.34 M page_count: 6 document date: 2025-03-21



[\[pdf\]](#) User Manual Instructions

BUGANI M192 20250220 m192 instructions à bugani global BUGANi Brief Pro MANUAL DE USUARIO 20250321 v 1742890590 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO MANUAL DEL USUARIO ALTAVOZ DE MSICA DE JAZZ REAL
DESCRIPCIN DEL PRODUCTO Altavoz --- 1 ud. Cable USB-C --- 1 pieza Cable de entrada auxiliar --- 1 unidad Manual de usuario --- 1 pieza Gua de inicio rpido --- 1 pieza USB-C RESET AUX IN 1 2 1 . Botn multifuncin 2. Actuador de pe...
lang:es score:46 filesize: 1.34 M page_count: 7 document date: 2025-03-21



[\[pdf\]](#) Instructions Guide

BUGANI M192 20250219 m193 instructions à bugani global BUGANi Brief Pro GUIDE DE DEMARRAGE RAPIDE 20250321 9179ce23 690a 4c11 bab7 eaede97323c8 v 1742891446 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO GUIDE DE DMARRAGE RAPIDE VRAI HAUT-PARLEUR DE MUSIQUE JAZZ CHARGER L ENCEINTE USB-C RESET AUX IN Lumire rouge clignotante Lumire rouge fixe Ne branchez pas le cble lorsque votre haut-parleur et le port de chargement ne sont pas compltement secs. Laissez votre haut-parleur dans un end...
lang:fr score:44 filesize: 1.34 M page_count: 6 document date: 2025-03-21



[\[pdf\]](#) User Manual Quick Start Guide Instructions Guide

BUGANI M192 20250220 m193 instructions à bugani global BUGANi Brief Pro USER MANUAL
20250321 9b22ba79 5c21 4893 ab81 938252dafb5a v 1742891827 cdn shopify s files 1 0660 1772 2548

|||

BRIEF PRO USER MANUAL REAL JAZZ MUSIC SPEAKER PRODUCT OVERVIEW
Speaker --- 1pc USB-C Cable --- 1pc AUX IN Cable --- 1pc User Manual --- 1pc Quick
Start Guide --- 1pc USB-C RESET AUX IN 1 2 1 . Multi-function Button 2. Knob
Actuator 3. AUX IN 4. RESET 5. USB-C AUX IN USB-C RESET 34 5 C...
lang:en score:43 filesize: 1.38 M page_count: 9 document date: 2025-03-21



[\[pdf\]](#) User Manual Instructions

BUGANI M192 20250220 m193 instructions à bugani global BUGANi Brief Pro MANUAL DE
USUARIO 20250321 92288bb2 d1b7 48d0 9b74 663ac78f484f v 1742891796 cdn shopify s files 1 0660
1772 2548 |||

BRIEF PRO MANUAL DEL USUARIO ALTAVOZ DE MSICA DE JAZZ REAL
DESCRIPCIN DEL PRODUCTO Altavoz --- 1 ud. Cable USB-C --- 1 pieza Cable de
entrada auxiliar --- 1 unidad Manual de usuario --- 1 pieza Gua de inicio rpido --- 1
pieza USB-C RESET AUX IN 1 2 1 . Botn multifuncin 2. Actuador de pe...
lang:es score:42 filesize: 1.34 M page_count: 7 document date: 2025-03-21



[BUGANI Brief Pro Benutzerhandbuch: Funktionen, Einrichtung und Garantie](#)

Umfassendes Benutzerhandbuch für den tragbaren BUGANI Brief Pro Bluetooth-Lautsprecher, das Produktübersicht, Aufladen, Bluetooth- und TWS-Kopplung, Tastenbedienung und eingeschränkte Garantieinformationen abdeckt.

lang:de score:40 filesize: 1.36 M page_count: 7 document date: 2025-03-21



[\[pdf\] Instructions](#)

BUGANI M192 20250220 m192 instructions â bugani global BUGANi Brief Pro 20250321 b683125e 586a 40a6 8bfe f80463220bca v 1742890671 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO --- 1 . USB-C --- 1 . AUX IN --- 1 . --- 1 . --- 1 . USB-C RESET AUX IN 1 2 1 . 2. 3. 4. 5. USB-C AUX IN USB-C RESET 34 5 USB-C RESET AUX IN , . , . RU // ON 2s ON OFF 2s OFF 2 , . 2 ,...

lang:en score:39 filesize: 2.9 M page_count: 7 document date: 2025-03-21



[\[pdf\]](#) Instructions

BUGANI M192 20250220 m192 instructions à bugani global BUGANi Brief Pro 20250321 28772d8c
6052 4bb7 b4f1 e999a823ad8f v 1742890696 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO --- 1 USB-C --- 1 AUX IN --- 1 --- 1 --- 1 USB-C RESET AUX IN 1 2 1 . 2. 3.
AUX IN 4. 5. USB-C AUX IN USB-C RESET 34 5 USB-C RESET AUX IN JP / ON 2s
ON OFF 2s OFF 2 2 2 2 15 JP BLUETOOTH Bluetooth Bluetooth Blu...
lang:it **score:39** filesize: 1.46 M page_count: 7 document date: 2025-03-21




[\[pdf\]](#) Instructions

BUGANI M192 20250219 m192 instructions à bugani global BUGANi Brief Pro 20250321 v
1742890302 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO USB-C RESET AUX IN , , , / / ON 2s OFF 2s ON OFF 2 , . 2 , . RU
BLUETOOTH 1 2s 2 BUGANi Brief Pro 3 , 2 , , Bluetooth. RU TWS 1 2 x2 1 / 2 1 2 1
BUGANi ...

lang:it **score:39** filesize: 1.38 M page_count: 6 document date: 2025-03-21



[\[pdf\]](#) Instructions Guide

BUGANI M192 20250108 m192 instructions à bugani global BUGANi Brief Pro MANUEL DE L UTILISATEUR20250321 v 1742890460 cdn shopify s files 1 0660 1772 2548 |||


BRIEF PRO MANUEL DE L UTILISATEUR VRAI HAUT-PARLEUR DE MUSIQUE JAZZ PRSENTATION DU PRODUIT Haut-parleur --- 1 pice Cble USB-C --- 1 pice Cble AUX IN --- 1 pice Manuel d utilisation --- 1 pice Guide de dmarrage rapide --- 1 pice USB-C RESET AUX IN 1 2 1 . Bouton multifonction 2. Actionne...
lang:fr score:39 filesize: 1.32 M page_count: 7 document date: 2025-03-21



[\[pdf\]](#) Instructions

BUGANI M192 20250220 m192 instructions à bugani global BUGANi Brief Pro 20250321 2920e10c 0511 4008 a262 1d891cab715e v 1742890720 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO --- pc USB-C --- pc --- pc --- pc --- pc USB-C RESET AUX IN 1 2 . .AUX IN . .USB-C AUX IN USB-C RESET 34 5 USB-C RESET AUX IN CN / 2s 2s // CN
BUGANi Brief Pro : 1 2 2s BUGANi Brief Pro ...
lang:i-klngon score:38 filesize: 1.42 M page_count: 7 document date: 2025-03-21



[\[pdf\]](#) Instructions

BUGANI M192 20250219 m192 instructions à bugani global BUGANi Brief Pro 20250321 4aaf4960 6964 495a 8643 08281946f697 v 1742890330 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO USB-C RESET AUX IN / ON 2s OFF 2s ON OFF 2 2 JP BLUETOOTH 1 2s 2 BUGANi Brief Pro 3 2 Bluetooth JP TWS 2 Brief Pro 1 2 x2 1 2 1 2 1 BUGANi Brief Pro 1 TWS TWS AUX IN AUX IN USB-C RESET AUX IN JP 1 2 TW...
lang:i-klngon score:37 filesize: 1.36 M page_count: 6 document date: 2025-03-21



[\[pdf\]](#) Instructions

BUGANI M192 20250219 m192 instructions à bugani global BUGANi Brief Pro GUIA DE INICIO

RAPIDO 20250321 v 1742890169 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO GUA DE INICIO RPIDO ALTAVOZ DE MSICA DE JAZZ REAL CARGAR EL ALTAVOZ USB-C RESET AUX IN Luz roja parpadeante Luz roja fija No enchufes el cable cuando el altavoz y el puerto de carga no estn completamente secos. Deje su altavoz en un rea seca con algo de flujo de aire para permitir qu...

lang:es score:37 filesize: 1.34 M page_count: 6 document date: 2025-03-21



[\[pdf\]](#) Instructions

BUGANI M192 20250220 m193 instructions à bugani global BUGANi Brief Pro 20250321 28ff75ee

6b2d 462f b91a d93fb8389ebb v 1742891888 cdn shopify s files 1 0660 1772 2548 |||

BRIEF PRO --- 1 . USB-C --- 1 . AUX IN --- 1 . --- 1 . --- 1 . USB-C RESET AUX IN 1 2 1 . 2. 3. 4. 5. USB-C AUX IN USB-C RESET 34 5 USB-C RESET AUX IN , . , . RU // ON 2s ON OFF 2s OFF 2 , . 2 ,...

lang:en score:37 filesize: 2.9 M page_count: 7 document date: 2025-03-21




[\[pdf\]](#) Instructions

BUGANI M192 20250220 m193 instructions à bugani globalBUGANi Brief Pro 20250321 4a2c9200
0cfc 4c6a b36f ecc62bcc4d05cdn shopify s files 1 0660 1772 2548 BUGANi ecc62bcc4d05 v 1742891973
|||
BRIEF PRO --- 1 USB-C --- 1 AUX IN --- 1 --- 1 --- 1 USB-C RESET AUX IN 1 2 1 . 2. 3.
AUX IN 4. 5. USB-C AUX IN USB-C RESET 34 5 USB-C RESET AUX IN JP / ON 2s
ON OFF 2s OFF 2 2 2 2 15 JP BLUETOOTH Bluetooth Bluetooth Blu...
lang:it score:37 filesize: 1.46 M page_count: 7 document date: 2025-03-21



[\[pdf\]](#) Instructions

BUGANI M192 20250219 m193 instructions à bugani global BUGANi Brief Pro 20250321 54b16f42
fa86 442b b429 8f81caee1bca v 1742891666 cdn shopify s files 1 0660 1772 2548 |||
BRIEF PRO USB-C RESET AUX IN / 2s 2s // CN 1 2s 2 BUGANi Brief Pro 3 CN TWS
x2 / BUGANi Brief Pro AUX IN AUX IN TWS TWS USB-C RESET AUX IN CN 1 2
TWS 2s / 1 CN 1 AUX IN USB-C RESET CN ...
lang:it score:35 filesize: 5.23 M page_count: 6 document date: 2025-03-21



[\[pdf\]](#) User Manual Instructions


BUGANI M192 20250219 m193 instructions à bugani global BUGANi Brief Pro KURZANLEITUNG
20250321 86c143e2 dcea 47cc bc78 c2f9acc3649b v 1742891507 cdn shopify s files 1 0660 1772 2548

|||

BRIEF PRO KURZANLEITUNG ECHTER JAZZ-MUSIK-LAUTSPRECHER LADEN SIE
DEN LAUTSPRECHER AUF USB-C RESET AUX IN Blinkendes rotes Licht

Durchgehend rotes Licht Schließen Sie das Kabel nicht an, wenn Ihr Lautsprecher und
der Ladeanschluss nicht vollständig trocken sind. Lassen Sie Ihren Lautsprecher an
ei...

lang:de score:34 filesize: 1.35 M page_count: 6 document date: 2025-03-21



[\[pdf\]](#) Instructions


BUGANI M192 20250219 m193 instructions à bugani globalm193 globalBUGANi Brief Pro 20250321
ca89004a cd71 491b 9426 62928e036753BUGANi 62928e036753cdn shopify s files 1 0660 1772 2548

BUGANi 62928e036753 v 1742891637cdn 1742891637 |||

BRIEF PRO USB-C RESET AUX IN / ON 2s OFF 2s ON OFF 2 2 JP BLUETOOTH 1
2s 2 BUGANi Brief Pro 3 2 Bluetooth JP TWS 2 Brief Pro 1 2 x2 1 2 1 2 1 BUGANi

Brief Pro 1 TWS TWS AUX IN AUX IN USB-C RESET AUX IN JP 1 2 TW...

lang:de score:34 filesize: 1.36 M page_count: 6 document date: 2025-03-21



[\[pdf\]](#) Instructions

BUGANI M192 20250219 m193 instructions à bugani global BUGANi Brief Pro GUIA DE INICIO RAPIDO 20250321 efc45ec4 28b5 4d56 a991 954de572cd5a v 1742891376 cdn shopify s files 1 0660 1772 2548 |||


BRIEF PRO GUA DE INICIO RPIDO ALTAVOZ DE MSICA DE JAZZ REAL CARGAR EL ALTAVOZ USB-C RESET AUX IN Luz roja parpadeante Luz roja fija No enchufes el cable cuando el altavoz y el puerto de carga no estn completamente secos. Deje su altavoz en un rea seca con algo de flujo de aire para permitir qu...
lang:es score:33 filesize: 1.34 M page_count: 6 document date: 2025-03-21



[\[pdf\]](#) User Manual Quick Start Guide Guide

BUGANI M192 20250220 cdn shopify Mar 21 2025 · com BUGANi Brief Pro USER MANUAL 20250321 v 1742890617 s files 1 0660 1772 2548 |||

BRIEF PRO USER MANUAL REAL JAZZ MUSIC SPEAKER PRODUCT OVERVIEW
Speaker --- 1pc USB-C Cable --- 1pc AUX IN Cable --- 1pc User Manual --- 1pc Quick Start Guide --- 1pc USB-C RESET AUX IN 1 2 1 . Multi-function Button 2. Knob Actuator 3. AUX IN 4. RESET 5. USB-C AUX IN USB-C RESET 34 5 C...
lang:en score:33 filesize: 1.38 M page_count: 9 document date: 2025-03-21



[\[pdf\]](#) User Manual Quick Start Guide Guide

BUGANI M192 0627 Administrator User manual Bugani Acoustics Co Limited BS12303 2BGTK 2BGTKBS12303 bs12303

95*110mm 4C 1 95 110 BRIEF PRO PORTABLE BLUETOOTH SPEAKER
Model/HVIN:BS12303 USER MANUAL / MANUEL DE L UTILISATEUR / BENUTZERHANDBUCH / MANUAL DE USUARIO / REAL JAZZ MUSIC SPEAKER VRAI HAUT-PARLEUR DE MUSIQUE JAZZ ECHTER JAZZ-LAUTSPRECHER / ALTAVOZ DE MSICA DE JAZZ REAL / PRODUCT OVER...
lang:en score:33 filesize: 5.48 M page_count: 1 document date: 2024-06-27