

[Manuals.plus](#) /

› [SURKER](#) /

› SURKER SK-993A Professional Digital Display Zero Gapped Pro Li Outliner Rechargeable Electric Cordless Hair Clipper Grooming Kit T-Blade Close Cutting 0mm Bald Head Clipper 120 min Runtime, GOLD C User Manual

SURKER SK 993A

SURKER SK-993A Professional Hair Clipper

USER INSTRUCTION MANUAL

1. Introduction

Thank you for choosing the SURKER SK-993A Professional Digital Display Hair Clipper. This device is engineered for precise and efficient hair and beard trimming, offering both cordless and corded operation. Its advanced features, including a T-Blade, powerful motor, and digital display, ensure a superior grooming experience. Please read this manual thoroughly before first use to ensure proper operation and maintenance.

2. Package Contents

Please verify that all items listed below are included in your package:

- 1 x SURKER SK-993A Hair Clipper
- 3 x Attachment Guide Combs (1mm, 2mm, 3mm)
- 1 x USB Type-C Charging Cable
- 1 x Cleaning Brush
- 1 x Lubricating Oil Bottle
- 1 x Protective Cover



Image: Contents of the SURKER SK-993A package, including the clipper, guide combs, charging cable, cleaning brush, and oil.

3. Product Features

3.1 Pro Li Outliner Grooming

The clipper features an enhanced automatic sharpened precision T-Blade, designed for durable, fast, easy, and precise haircuts, beard trimming, and shaping. Its stylish and portable design allows for easy creation of various hairstyles.

3.2 Cordless/Corded Operation with Extended Runtime

Equipped with a rechargeable 2000 mAh Li-ion battery, the clipper provides up to 120 minutes of cordless operation after a full 3-hour charge. It supports dual-purpose charging and plugging, allowing use while charging.



Image: Charging capabilities and battery life of the clipper, indicating 3 hours charging for 120 minutes runtime.

3.3 0mm Cutting with Multiple Lengths

The clipper comes with 3 attachment combs (1mm, 2mm, 3mm) for varying cutting lengths. For a close trim, the grooming kit can be used without any comb, offering a trimming range from 0mm to 3mm.

3.4 LED Digital Display

An integrated LED digital display clearly shows the remaining battery charge and provides over-charge protection. It also includes maintenance and charging reminders for user convenience.

POWERFUL MOTOR

Powerful motor with high rotation speed and low noise



Surging power



High rotational
speed



Low beep



Image: The LED digital display on the clipper, indicating power status and reminders.

3.5 Powerful yet Quiet Clipper Motor

The heavy-duty motor allows for easy and efficient cutting through various hair types. Despite its power, the noise level is kept below 60 dB, ensuring a quiet experience suitable for home use.

LED DIGITAL DISPLAY

CLEAR POWER STATUS AT A GLANCE

LED digital display is clearly visible



Image: Visual representation of the clipper's powerful and low-noise motor.

3.6 Sharp and Wear-Resistant Precision Steel Sharp Angle Blade

The blade is smooth, sharp, and designed to prevent hair pinching. It features an R-shaped fillet for safe skin care and is made of precision steel for durability and wear resistance. The design includes a transparent protective cover and a stainless steel suspension bracket.

SHARP AND WEAR-RESISTANT PRECISION STEEL SHARP ANGLE BLADE

Smooth and sharp blade, anti pinch hair, matching cutting and shaving angle and sharp angle blade



R-shaped fillet



Safe skin care



Transparent protective cover



Stainless steel suspension bracket

Image: Detailed view of the clipper's sharp and wear-resistant blade, emphasizing its design for safety and precision.

4. Setup

1. **Initial Charge:** Before first use, fully charge the clipper for approximately 3 hours. Connect the USB Type-C charging cable to the clipper and a suitable USB power source (e.g., wall adapter, computer, power bank). The LED display will indicate charging status.
2. **Blade Inspection:** Ensure the blade is clean and free of debris. Apply a small drop of lubricating oil to the blade before first use and after each cleaning.
3. **Attaching Guide Combs:** To achieve desired hair length, select one of the three attachment guide combs (1mm, 2mm, or 3mm). Align the comb with the clipper head and snap it securely into place. Ensure it is firmly attached before operation.

5. Operating Instructions

1. **Power On/Off:** Press the power button located on the clipper to turn it on or off. The LED display will illuminate upon activation.
2. **Selecting Cutting Length:** Attach the desired guide comb for longer hair lengths. For a 0mm close cut or detailing,

operate the clipper without any guide comb.

3. **Trimming Technique:**

- For hair cutting, move the clipper against the direction of hair growth.
- For beard trimming, hold the clipper at a slight angle and move it slowly and steadily.
- Use short, controlled strokes for precision work like outlining and detailing.

4. **Safety Precautions:**

- Do not immerse the clipper in water.
- Keep out of reach of children.
- Avoid using the clipper on wet hair or skin to prevent electric shock.
- If the clipper makes unusual noises or becomes excessively hot, discontinue use immediately.

6. Maintenance

1. **Cleaning the Blade:** After each use, turn off the clipper and use the provided cleaning brush to remove any hair clippings from the blade and housing. For thorough cleaning, the blade can be carefully detached and rinsed under running water, ensuring it is completely dry before reattaching.
2. **Lubricating the Blade:** Regularly apply 1-2 drops of the provided lubricating oil to the blade teeth. Turn on the clipper for a few seconds to allow the oil to distribute evenly. This helps maintain blade sharpness and smooth operation.
3. **Storage:** Store the clipper in a cool, dry place, away from direct sunlight and moisture. Use the protective cover to shield the blade when not in use.
4. **Battery Care:** To prolong battery life, avoid completely draining the battery before recharging. If storing for an extended period, charge the clipper to approximately 50% and recharge every few months.

7. Troubleshooting

Problem	Possible Cause	Solution
Clipper does not turn on.	Battery is depleted.	Charge the clipper for 3 hours.
Poor cutting performance / Pulling hair.	Blade is dirty or not lubricated.	Clean the blade and apply lubricating oil.
Clipper gets hot during use.	Extended continuous use or lack of lubrication.	Allow the clipper to cool down. Ensure blade is lubricated.
Battery not charging.	Faulty charging cable or power source.	Try a different USB cable or power adapter.

8. Specifications

Feature	Detail
Model Number	SK 993A
Power Source	Battery Powered (Cordless/Corded)

Feature	Detail
Battery Type	2000 mAh Li-ion Battery
Charging Time	Approx. 3 hours
Runtime	Up to 120 minutes (cordless)
Blade Material	Stainless Steel
Cutting Lengths	0mm (without comb), 1mm, 2mm, 3mm (with combs)
Noise Level	Below 60 dB
Product Dimensions	21.5 x 12.2 x 5 cm
Item Weight	280 g

9. Warranty and Support

The SURKER SK-993A Hair Clipper comes with a **12-month quality warranty** from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use.

If you encounter any issues with your product or require assistance, please contact SURKER customer service. Our team is dedicated to providing satisfactory support and will respond to inquiries within 24 hours.

For service and support, please refer to the contact information provided on the product packaging or the official SURKER website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question