

[Manuals.plus](#) /

› [Techni Home](#) /

› Techni Home 32" W Premium Foldable Accordion Door Instruction Manual (Model RTA-LF32FD-WHT)

Techni Home RTA-LF32FD-WHT

Techni Home 32" W Premium Foldable Accordion Door Instruction Manual

MODEL: RTA-LF32FD-WHT

Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Techni Home 32" W Premium Foldable Accordion Door. Crafted from durable, double-walled PVC, this door is designed for interior use, offering privacy and space-saving functionality. Please read all instructions carefully before beginning installation to ensure proper setup and safe operation.



Figure 1: Techni Home 32" W Premium Foldable Accordion Door, White Oak.

Product Features

- **Durable Construction:** Crafted from double-walled, high-quality, scratch-resistant PVC, these UV-resistant accordion folding doors are built for longevity and easy maintenance.
- **Easy Assembly:** Comes ready to install with all necessary components including a track, hardware, door handle, and clear instructions for a hassle-free setup.
- **Standard Widths:** Available in 3 standard widths: 32", 36", and 48". The track can be trimmed to fit door openings with a minimum width of 24".
- **Trimable Height:** Each door has a standard height of 80", which is trimmable to perfectly fit various door frame heights, adding versatility to your interior design options.
- **Innovative Design:** Made with lead-free PVC, the doors are equipped with a magnet and striker plate, ensuring secure closure for privacy and safety.
- **Space Efficient:** Ideal for indoor spaces such as bedrooms, closets, and other internal passageways, these folding

doors offer excellent space-saving solutions.

- **Warranty:** Includes a 1-Year Limited Warranty.

FEATURES

LOFT SERIES

COLORS AVAILABLE:

- WHITE OAK
- TAUPE
- GREY
- WALNUT



Top track can be trimmed to fit different door widths

Built with premium double walled PVC

Scratch and UV-Resistant PVC panels

Available in 3 standard widths: 32", 36", and 48"

Actual Door Height: 79.5"

Designed for 80"H Standard Openings

Includes ½" clearance for track and smooth operation.

Figure 2: Key Features of the Accordion Door.

Package Contents

Verify that all components are present and undamaged before beginning installation. If any parts are missing or damaged, please contact customer support.

- Accordion Door Panels (pre-assembled)
- Top Track
- Hardware Kit (screws, anchors, etc.)
- Door Handle(s)
- Striker Plate(s)
- Assembly Instructions

Safety Information

- Always wear appropriate safety gear, including eye protection, during installation.
- Ensure the installation area is clear of obstructions and well-lit.
- Use the correct tools for each step as specified in the instructions.
- If trimming the door or track, use caution and appropriate cutting tools.
- Keep small parts and hardware away from children and pets.
- Do not hang or swing on the installed door.

Setup and Installation

The Techni Home accordion door is designed for straightforward installation. Follow these steps carefully for optimal performance.


1. Measure and Prepare the Opening

Measure the width and height of your door opening. The door is 80" high and can be trimmed. The track can be trimmed to fit openings down to 24" wide. Ensure the opening is plumb and level.

DIMENSIONS

LOFT SERIES

COLORS
AVAILABLE:



Designed to accommodate
a range of openings
up to 80"H

Actual Door Dimensions

Height: 79.5"
Width: 32"

Includes 1/2" clearance
for track and smooth
operation

Figure 3: Door Dimensions and Trimming Areas.

2. Install the Top Track

Secure the top track to the top of your door frame using the provided screws. Ensure it is centered and level. If necessary, trim the track to fit the width of your opening.



Figure 4: Top Track Detail.

3. Hang the Door Panels

Carefully insert the rollers on the top edge of the door panels into the installed top track. Ensure all rollers are properly seated for smooth operation.



Figure 5: Bottom Rollers and Panel Connections.

4. Install Door Handle and Striker Plate

Attach the door handle(s) to the lead panel of the door. Install the striker plate on the opposing door frame, aligning it with the magnet on the door for secure closure.



Figure 6: Door Handle Detail.

5. Watch the Installation Video

For a visual guide to the installation process, please watch the official product video below. This video demonstrates each step, from measuring to final adjustments.

Video 1: Premium Foldable Accordion Door - Double Walled Build Installation Guide. This video provides a step-by-step visual demonstration of how to install your Techni Home accordion door, including measuring, track installation, and attaching the door panels and hardware.

Operation

To open the accordion door, gently pull the handle towards the side of the door frame. The panels will fold smoothly along the track. To close, pull the handle back across the opening until the magnet engages with the striker plate, securing the door in the closed position.

Video 2: Premium Foldable Accordion Doors Overview. This video demonstrates the smooth operation of the accordion door, showing how it opens and closes effortlessly.

Maintenance

Your Techni Home accordion door is designed for low maintenance. The durable vinyl panels have a scratch and UV-resistant coating that is easy to clean.

- **Cleaning:** Wipe the door panels with a soft, damp cloth and mild soap as needed. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Track Maintenance:** Periodically check the top track for any debris or dust that might hinder smooth operation. Clean the track with a dry cloth or vacuum cleaner.
- **Hardware:** Ensure all screws and hardware remain tight. Tighten if necessary.

Troubleshooting

Problem	Possible Cause	Solution
Door does not slide smoothly.	Debris in track, misaligned track, or damaged rollers.	Clean the track. Check if the track is level and securely installed. Inspect rollers for damage and replace if necessary.
Door does not close securely.	Misaligned striker plate or weak magnet.	Adjust the position of the striker plate to align with the door's magnet. Ensure the magnet is clean.
Door panels appear uneven.	Improper installation or uneven floor/frame.	Re-check track levelness and door panel alignment. Ensure the door was trimmed correctly.

Specifications

- **Brand:** Techni Home
- **Model Number:** RTA-LF32FD-WHT
- **Color:** White Oak
- **Material:** Polyvinyl Chloride (PVC)
- **Style:** Modern
- **Item Weight:** 10 Pounds

- **Standard Height:** 80 inches (trimmable)
- **Standard Widths:** 32", 36", 48" (track trimmable to minimum 24")
- **Included Components:** Hardware Kit, Tracks, Assembly Instructions
- **UPC:** 815764017627

Warranty and Support

This Techni Home product is covered by a **1-Year Limited Warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use.

For warranty claims, technical assistance, or missing parts, please contact Techni Home customer support. Keep your proof of purchase for warranty validation.

Customer Support: Please refer to the contact information provided with your product packaging or visit the official Techni Home website for assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question