

UPBRIGHT ErGear 48 x 24 Inches Desk Power Supply

UpBright AC DC Adapter User Manual

Brand: UPBRIGHT | Model: ErGear 48 x 24 Inches Desk Power Supply

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your UpBright AC DC Adapter. This power supply is designed for compatibility with various ErGear electric standing desks, including models EGESD5B, EGESD4N, EGESD5LV, and EGESD5V (48 x 24 Inches Sit Stand up Height Adjustable Electric Standing Desk Power Supply).

Key Features:

- World Wide Input Voltage: 100-240VAC 50/60Hz, ensuring global compatibility.
- Advanced Protection: Features OVP (Over Voltage output Protection), OCP (Over Current output Protection), and SCP (Short Circuit output Protection) for enhanced safety and device longevity.
- Designed for ErGear Desks: Specifically compatible with ErGear EGESD5B, EGESD4N, EGESD5LV, EGESD5V 48 x 24 Inches Sit Stand up Height Adjustable Electric Standing Desk Power Supply.

2. PACKAGE CONTENTS


Please verify that all items are present and in good condition upon opening the package:

- 1 x UpBright AC DC Adapter Unit
- 1 x AC Power Cord (suitable for your region)



Image 1: The UpBright AC DC Adapter unit with its attached DC output cable and a detachable AC input power cord.

Come With A Suitable AC Power Cord (Only One) to Fit Your Country/Area



THIS PRODUCT COMES WITH A UPBRIGHT®

LIMITED WARRANTY CERTIFICATE
+ UpBright® LIMITED WARRANTY



Image 2: Illustration of different AC power cord types (US, EU, UK, AU) that may be included, depending on your region.

3. SETUP INSTRUCTIONS

1. **Verify Compatibility:** Ensure that your ErGear electric standing desk model (EGESD5B, EGESD4N, EGESD5LV, EGESD5V) is listed as compatible with this UpBright AC DC Adapter.
2. **Connect AC Power Cord:** Insert the regional AC power cord into the AC input port of the UpBright adapter unit. Ensure a firm connection.
3. **Connect to Desk:** Locate the power input port on your ErGear electric standing desk. Insert the DC output connector from the UpBright adapter into this port. Ensure the connector is fully seated.
4. **Plug into Wall Outlet:** Plug the AC power cord into a standard wall electrical outlet.
5. **Power On:** Your electric standing desk should now receive power. Refer to your desk's manual for specific power-on procedures.

4. OPERATING INSTRUCTIONS

The UpBright AC DC Adapter functions as a dedicated power supply for your compatible ErGear electric standing desk. Once properly connected, it continuously provides the necessary power for the desk's operation.

- **Automatic Operation:** The adapter operates automatically when plugged into a live electrical outlet and connected to the desk.
- **Safety Features:** The adapter is equipped with Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) to safeguard both the adapter and your connected device from electrical anomalies.
- **Indoor Use Only:** This adapter is designed for indoor use in dry locations. Avoid exposure to moisture or extreme temperatures.

5. MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your AC DC adapter.

- **Cleaning:** Disconnect the adapter from the power outlet and the desk before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use for extended periods, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly coiling the cables.
- **Cable Inspection:** Periodically inspect the power cords and adapter casing for any signs of damage, such as cuts, fraying, or exposed wires. If damage is found, discontinue use immediately and replace the adapter.
- **Ventilation:** Ensure the adapter is placed in a location with adequate ventilation to prevent overheating. Do not cover the adapter during operation.

6. TROUBLESHOOTING

If you encounter issues with your UpBright AC DC Adapter, please refer to the following common troubleshooting steps:

- **No Power to Desk:**
 - Ensure the AC power cord is securely plugged into both the adapter and the wall outlet.
 - Verify that the wall outlet is functional by testing it with another device.
 - Check that the DC output connector is firmly inserted into the desk's power input port.
 - Inspect all cables for visible damage.
- **Desk Not Responding:**
 - If the desk has its own power switch, ensure it is in the 'On' position.
 - Consult your ErGear desk's user manual for specific troubleshooting steps related to the desk itself.
- **Adapter Overheating:**
 - Ensure the adapter is in a well-ventilated area and not covered.
 - If overheating persists, disconnect the adapter and contact support.

If these steps do not resolve the issue, please contact customer support for further assistance.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	6 x 4 x 2 inches
Item Weight	12 ounces
ASIN	B0DDFTNCY7
Item Model Number	ErGear 48 x 24 Inches Desk Power Supply
Manufacturer	UpBright
Brand	UPBRIGHT

Connector Type	Connector
Compatible Devices	ErGear EGESD5B, EGESD4N, EGESD5LV, EGESD5V 48 x 24 Inches Sit Stand up Height Adjustable Electric Standing Desk Power Supply
Special Feature	Short Circuit Protection
Color	Black
Input Voltage	100-240 Volts (AC)
Number of Items	1 (Adapter Unit + AC Power Cord)
Specification Met	CE

8. WARRANTY AND SUPPORT

UpBright stands behind the quality of its products.

- **Refund Policy:** UpBright offers a 30-day refund policy from the date of purchase.
- **Exchange Policy:** The product is covered by a 24-month exchange policy.
- **Warranty Certificate:** This product comes with an UpBright Limited Warranty Certificate.

For warranty claims, technical support, or any inquiries, please refer to the contact information provided with your purchase or visit the official UpBright website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DDFTNCY7>

More documents and user manuals: <https://manuals.plus/>