

[manuals.plus](#) /› [typecase](#) /› **typecase Touch Case with Keyboard for iPad Pro 13-inch (M4, 2024), iPad Air 13-inch (M3, 2025/M2, 2024) & iPad Pro 12.9 (6th/5th/4th/3rd Gen) Instruction Manual**

typecase Touch Case with Keyboard 12.9

typecase Touch Case with Keyboard Instruction Manual

For iPad Pro 13-inch (M4, 2024), iPad Air 13-inch (M3, 2025/M2, 2024) & iPad Pro 12.9 (6th/5th/4th/3rd Gen)

1. INTRODUCTION

Thank you for choosing the typecase Touch Case with Keyboard. This manual provides detailed instructions for the proper installation, operation, and maintenance of your new keyboard case. This product is designed to enhance your iPad experience by providing a protective case, a responsive keyboard, and a precise trackpad, transforming your tablet into a versatile laptop-like device.



Image: The typecase Touch Case with Keyboard, showcasing an iPad securely housed within the case, with the backlit keyboard and trackpad visible.

2. COMPATIBILITY

This keyboard case is compatible with the following iPad models:

- New iPad Air 13-inch (M3, 2025)
- iPad Air 13-inch (M2, 2024)
- iPad Pro 13-inch (M4, 2024)
- iPad Pro 12.9 (6th, 5th, 4th, 3rd Gen)

Refer to the image below to verify your iPad model number. You can find the model number on the back of your iPad or by navigating to Settings > General > About > Model Number.

Compatible Models



for New iPad Air 13-in.(M3) 2025
(A3268, A3269, A3271)



for New iPad Pro 13-in.(M4) 2024
(A2925, A2926, A3007)



for New iPad Air 13-in.(M2) 2024
(A2898, A2899, A2900)



for iPad Pro 12.9 2022(6th Gen)
(A2436, A2437, A2764, A2766)



for iPad Pro 12.9 2021 (5th Gen)
(A2378, A2379, A2461, A2462)



for iPad Pro 12.9 2020 (4th Gen)
(A2229, A2069, A2232, A2233)



for iPad Pro 12.9 2018(3rd Gen)
(A1876, A2014, A1895, A1983)

How to verify your iPad model?

Method 1


Verify on back of iPad



Method 2

Verify in iPad Settings App

1. Open **Settings** App on Pad
2. Navigate to **General>About**
3. Tap on **Model Number** to display it



✗ NOT FOR



✗ iPad Pro 12.9 2015(1st Gen)

✗ iPad Pro 12.9 2017(2nd Gen)

Image: Visual guide illustrating compatible iPad models and methods to verify your iPad's model number.

3. PACKAGE CONTENTS

Please ensure all items are present in the package:

- 1 x Keyboard Case for iPad Pro 13
- 1 x USB-C Cable
- 1 x User Manual (this document)

4. INSTALLATION

4.1 Installing Your iPad into the Case

1. Align the iPad's bottom edge with the keyboard case's bottom slot.
2. Gently press and hold the middle of the upper edge of the iPad, guiding it into the case.
3. Press the top corners of the iPad firmly to securely fit it into the case.



Image: Step-by-step visual guide for installing the iPad into the keyboard case.

4.2 Removing Your iPad from the Case

1. Press and hold the middle of the upper edge of the iPad.
2. Push the top corners to detach the case.
3. Pull up to remove your iPad from the case.



Image: Step-by-step visual guide for removing the iPad from the keyboard case.

5. SETUP: BLUETOOTH PAIRING

Follow these steps to connect your keyboard case to your iPad via Bluetooth:

1. Locate the ON/OFF switch on the keyboard and slide it to the 'ON' position.
2. Press and hold the Bluetooth pairing button on the keyboard for 3 seconds. The Bluetooth indicator light will begin to flash.
3. On your iPad, go to **Settings > Bluetooth**.
4. Ensure Bluetooth is turned ON.
5. Under 'MY DEVICES', tap on "Typecase Flexbook" (or similar name) to connect. The indicator light on the keyboard will stop flashing once connected.



Image: Visual guide demonstrating the Bluetooth pairing process between the keyboard case and an iPad.

6. OPERATING INSTRUCTIONS

6.1 Keyboard Features

The keyboard features a full set of PadOS multimedia shortcuts for easy control of volume, music, and other functions. The keys are designed with a scissor mechanism for a comfortable and responsive typing experience.

Laptop-like Typing



Lap Usability



Image: Illustration of the keyboard layout, highlighting PadOS shortcut keys and the scissor-design key structure for a premium typing experience.

6.2 11-Color Backlit Keyboard

The keyboard features 11-color backlighting with 3 levels of brightness adjustment, allowing for comfortable typing in various lighting conditions, including low-light environments.

11 Color Backlight

3-level Brightness Adjustment



Image: A user typing on the backlit keyboard in a dimly lit room, demonstrating the visibility of the 11-color backlight feature.

6.3 Precise Multi-touch Trackpad

The integrated multi-touch trackpad provides precise responses for navigation, editing, and browsing, enhancing productivity and creativity. It supports various gestures for efficient interaction with your iPad.




Image: A hand demonstrating multi-touch gestures on the trackpad, indicating its responsiveness and functionality.

6.4 Versatile Usage Modes

The 360° hinge allows for 7 different usage modes, providing flexibility for various activities such as typing, drawing, watching videos, or browsing. The case offers a 180° flip and 360° rotation for optimal viewing angles.




Image: A collage illustrating various usage modes including Laptop, Stand, Tent, Tablet, Protect, and Corner modes, showcasing the case's versatility.



360° Rotation

Versatile Viewing Angles



180°Flip
Open and Close

Secure Fit

Image: Diagrams demonstrating the 360° rotation and 180° flip capabilities of the case, highlighting the durable hinge mechanism.

6.5 Apple Pencil Holder

The case includes a built-in pencil holder to ensure your Apple Pencil is accessible and securely stored, allowing for convenient charging and safekeeping.

7. CHARGING THE KEYBOARD

To charge your keyboard, use the provided USB-C cable:

1. Turn on the keyboard. If the battery indicator is flashing, it requires charging.

2. Plug the USB-C charging cable into the keyboard's charging port and connect the other end to a power adapter (not included). An iPad or iPhone power adapter is recommended.
3. The battery indicator will turn red while charging and green when charging is complete.



Image: Diagram showing how to connect the USB-C cable to the keyboard for charging and the recommended power adapter types.

8. MAINTENANCE

To ensure the longevity and optimal performance of your typecase Touch Case with Keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, damp cloth to wipe the exterior of the case and keyboard. Avoid harsh chemicals or abrasive materials. For the keyboard keys, use a soft brush or compressed air to remove dust and debris.
- **Storage:** When not in use for extended periods, store the keyboard case in a cool, dry place. Ensure the keyboard is turned off to conserve battery life.
- **Protection:** While the case offers robust protection, avoid dropping it from significant heights or exposing it to extreme temperatures or liquids.

9. TROUBLESHOOTING

9.1 Bluetooth Connection Issues / Reset

If you experience issues with the Bluetooth connection, try resetting the keyboard's Bluetooth:

1. Press and hold the "C+R+L" keys simultaneously for 2-3 seconds.
2. Release the keys when the indicator light starts flashing.
3. Press the Bluetooth pairing button on the keyboard to reconnect as per the setup instructions (Section 5).



Image: Diagram illustrating the keys to press for a Bluetooth reset and the location of the Bluetooth indicator.

9.2 Keyboard Lag or Unresponsiveness

If the keyboard experiences lag or becomes unresponsive:

- **Check Battery:** Ensure the keyboard is sufficiently charged. Low battery can affect performance.
- **Re-pair Bluetooth:** Disconnect and re-pair the keyboard with your iPad (refer to Section 5).
- **Restart iPad:** Sometimes, restarting your iPad can resolve connectivity issues.
- **Interference:** Move away from other wireless devices that might cause interference.

10. SPECIFICATIONS

Feature	Detail
---------	--------

Product Dimensions	12.99" L x 10.63" W x 0.98" H (33 x 27 x 2.5 cm)
Item Weight	1.54 pounds (0.7 kg)
Manufacturer	typecase
Item Model Number	Touch Case with Keyboard 12.9
Batteries	1 Lithium Polymer battery required (included)
Connectivity Technology	Bluetooth
Keyboard Description	Multi Functional
Special Features	Backlit, Hotkeys and Media Keys, Rechargeable, Trackpad
Keyboard Backlighting Color Support	RGB (11 colors)
Style	Classic

11. WARRANTY AND SUPPORT

typecase is committed to product quality and customer satisfaction.

- Warranty:** This product includes a 1-year replacement service from the date of purchase.
- Returns:** You are eligible for a refund within 30 days of purchase.
- Customer Support:** For any questions, concerns, or support needs, please contact typecase customer service. Quick feedback is provided for all inquiries.

For further assistance, please visit the official typecase store or contact their support channels.

© 2025 typecase. All rights reserved.

Related Documents - Touch Case with Keyboard 12.9

 <p>typecase® EDGE compatible with iPad Pro 12.9</p> <p>For warranty registration and product support: www.typecase.com 1-800-123-4567 support@typecase.com</p>	<p>Typecase Edge Magic Style Keyboard for iPad Pro 12.9 Inch User Manual</p> <p>Comprehensive user manual for the Typecase Edge Magic Style Keyboard, detailing setup, features, and usage for iPad Pro 12.9 Inch (6th, 5th, 4th, 3rd Gen) with trackpad and backlit keys.</p>
---	--

 <p>For warranty registration and product support: support.typecase.us 1-800-333-9840 support@typecase.us</p>	<p><u>Typecase Touch iPad Pro 11 Keyboard Case with Trackpad - User Manual</u></p> <p>User manual for the typecase Touch iPad Pro 11-inch keyboard case (model KB201T-110). Discover features like the multi-touch trackpad, 360° rotation, and customizable backlighting. This thin and light case is designed for iPad Pro 11" (2021), iPad Air 5th Gen, and iPad Air 4th Gen, available in Pacific Blue and Violet.</p>
 <p>For more support, please email us at support@typecase.us. Your questions will be answered promptly.</p>	<p><u>Typecase Flexbook Touch User Manual</u></p> <p>User manual for the Typecase Flexbook Touch keyboard case, detailing setup, compatibility, features, troubleshooting, and product specifications for iPad devices.</p>
 <p>For warranty registration and product support: support.typecase.us 1-800-333-9840 support@typecase.us</p>	<p><u>Typecase TOUCH User Manual for iPad Mini 6th Gen</u></p> <p>User manual for the Typecase TOUCH keyboard case, providing setup instructions, shortcut maps, touchpad functions, installation guides, troubleshooting tips, and product specifications for compatibility with iPad Mini 6th Generation.</p>
 <p>For warranty registration and product support: support.typecase.us 1-800-333-9840 support@typecase.us</p>	<p><u>Typecase TOUCH User Manual: Keyboard Case for iPad</u></p> <p>Comprehensive user manual for the Typecase TOUCH keyboard case, detailing setup, touchpad functions, shortcuts, charging, and troubleshooting for compatible iPad models.</p>
 <p>For warranty registration and product support: support.typecase.us 1-800-333-9840 support@typecase.us</p>	<p><u>Typecase Touch User Manual for iPad Pro 12.9 - Setup, Features, and Troubleshooting</u></p> <p>Comprehensive user manual for the Typecase Touch keyboard case compatible with iPad Pro 12.9. Learn about setup, compatibility, touchpad functions, shortcuts, installation, battery, charging, and troubleshooting.</p>