

TYBERLEY PD1779-UUU

TYBERLEY Pagani Design 1779 Quartz Chronograph Watch User Manual

Model: PD1779-UUU

INTRODUCTION

This manual provides detailed instructions for the proper use, setup, and maintenance of your TYBERLEY Pagani Design 1779 Quartz Chronograph Watch. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.

PRODUCT OVERVIEW

The Pagani Design 1779 is a sophisticated quartz chronograph watch featuring a partially skeletonized dial and a durable leather strap. It is designed for reliability and precision.

Key Features:

- **Movement:** Japanese quartz calibre VK63 for precise timekeeping and chronograph functions.
- **Case Material:** Stainless steel with a 40 mm diameter.
- **Crystal:** Hard synthetic sapphire glass with double anti-glare treatment for enhanced visibility and scratch resistance.
- **Water Resistance:** 100 meters (10 ATM), suitable for splashes, accidental showers, and swimming. Not suitable for hot baths, saunas, or diving.
- **Strap:** Leather strap with a unique perforated design and pin buckle closure.
- **Dial:** Dazzling all-black dial with a fine-grained brushed surface, featuring a classic three-dial layout (small seconds, 60-minute, 24-hour).
- **Luminescence:** Luminous coating on hands and graduated scale for clear reading in low light conditions.

Visual Guide:



Front view of the TYBERLEY Pagani Design 1779 watch, showcasing the black dial and leather strap.



Close-up view of the watch dial, highlighting the chronograph sub-dials and skeletonized elements.



Rear view of the watch, showing the engraved case back with model number PD-1779 and water resistance rating.

Product Video:

Your browser does not support the video tag.

An official video showcasing the TYBERLEY Pagani Design 1779 Quartz Chronograph Watch, demonstrating its design and features.

SETUP INSTRUCTIONS

Setting the Time:

1. **Unscrew the Crown:** Gently unscrew the crown (located on the right side of the watch case) counter-clockwise until it is free.
2. **Pull Out the Crown:** Pull the crown out to the second click position.
3. **Adjust Time:** Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
4. **Push In and Screw Down:** Once the time is set, push the crown back in to the first click position and then screw it down clockwise firmly to ensure water resistance.

Adjusting the Chronograph:

The chronograph features a 60-minute counter, a small seconds sub-dial, and a 24-hour sub-dial.

1. **Start Chronograph:** Press the upper pusher button to start the chronograph. The large second hand will begin to move.
2. **Stop Chronograph:** Press the upper pusher button again to stop the chronograph.
3. **Reset Chronograph:** Press the lower pusher button to reset the chronograph. All chronograph hands will return to their zero positions.

OPERATING INSTRUCTIONS

Water Resistance Guidelines:

Your watch is water-resistant to 100 meters (10 ATM). This means it can withstand:

- Accidental splashes
- Rain
- Showering (avoid direct hot water spray)
- Swimming (shallow depths)

Important Warnings:

- **Do not press any buttons or unscrew the crown while the watch is submerged in water.**
- Avoid using the watch in extremely hot or cold temperatures.
- This watch is **not suitable for diving**.
- Avoid wearing the watch in hot baths or saunas, as water vapor can penetrate the seals and cause damage.
- Always ensure the crown is fully screwed down before exposing the watch to water.

MAINTENANCE AND CARE

Proper care will help maintain the appearance and functionality of your watch.

- **Cleaning:** Regularly clean the strap and case with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, but ensure the watch is completely dry afterward.
- **Avoid Chemicals:** Do not expose the watch to harsh chemicals, solvents, or detergents, as these can damage the case, strap, or seals.
- **Temperature Extremes:** Protect your watch from extreme temperatures, direct sunlight for prolonged periods, and strong magnetic fields.
- **Storage:** When not in use, store the watch in a cool, dry place, preferably in its original box or a watch case to prevent scratches.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch not running or running intermittently	Depleted battery.	Replace the battery at an authorized service center.
Time is incorrect	Crown not fully screwed down or accidentally pulled out.	Reset the time as per "Setting the Time" instructions and ensure the crown is fully screwed down.
Moisture inside the watch	Exposure to water with crown open, or extreme temperature changes.	Immediately take the watch to an authorized service center for inspection and repair to prevent further damage.
Chronograph hands do not reset to zero	Requires calibration or internal adjustment.	Consult an authorized service center.

SPECIFICATIONS

Feature	Detail
Brand Name	TYBERLEY
Model Name	PD1779-UUU
Watch Movement Type	Japanese Quartz (VK63)
Display	Analog
Case Material Type	Stainless Steel
Case Diameter	40 Millimeters
Case Thickness	14 Millimeters
Crystal	Synthetic Sapphire
Band Material Type	Leather
Band Width	20 Millimeters
Band Length	220 Millimeters

Feature	Detail
Clasp Type	Pin Buckles
Water Resistance Depth	100 Meters
Additional Features	Chronograph, Luminous Hands
Power Source	Battery Powered
Face Style	Skeleton

WARRANTY AND SUPPORT

Your TYBERLEY Pagani Design 1779 watch is covered by a **1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

For any questions regarding the use, maintenance, or warranty of your watch, please contact the seller or TYBERLEY customer support. Please have your purchase details and model number (PD1779-UUU) ready when contacting support.

Contact Information: Refer to your purchase documentation or the seller's contact details on the platform where the watch was purchased.