



[Manuals.plus](#) /

› [Signature Design by Ashley](#) /

› Signature Design by Ashley Neymorton Contemporary Dining Extension Table D618-35 User Manual

Signature Design by Ashley D618-35

Signature Design by Ashley Neymorton Contemporary Dining Extension Table D618-35 User Manual

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Signature Design by Ashley Neymorton Contemporary Dining Extension Table, Model D618-35. Please read these instructions carefully before beginning assembly and retain this manual for future reference.

SAFETY INFORMATION

Always use appropriate tools and follow assembly instructions carefully to avoid injury. Keep hands and body parts away from moving parts during assembly. Do not attempt to lift or move the table without proper assistance to prevent injury or damage.

- Ensure all hardware is securely tightened before use.
- Do not stand or sit on the table.
- Keep small children and pets away from the assembly area.
- Use caution when extending or retracting the table leaf to prevent pinching.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Dining Table Top
- Sled Base Legs (2 units)
- Self-Storing Butterfly Leaf (pre-installed or separate)
- Assembly Guide
- Installation Tool (Hex Key/Allen Wrench)
- Hardware Pack (screws, bolts, washers, etc.)

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the Neymorton Dining Extension Table requires two people. Please ensure you have a screwdriver and wrench (not included) in addition to the provided installation tool.

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to prevent scratches.
2. **Attach Sled Bases:** Securely attach the two sled base legs to the underside of the table top using the provided hardware. Ensure all bolts are tightened evenly.
3. **Upright the Table:** With assistance, carefully flip the table upright onto its legs.
4. **Final Inspection:** Check all connections to ensure they are tight and stable.



Image: The fully assembled Signature Design by Ashley Neymorton Dining Extension Table, showcasing its dark brown finish and sled base design.



Image: The Neymorton Dining Extension Table positioned in a contemporary dining room, illustrating its scale and aesthetic.

OPERATING INSTRUCTIONS: SELF-STORING BUTTERFLY LEAF

The Neymorton Dining Extension Table features a convenient self-storing butterfly leaf mechanism, allowing you to easily adjust the table length for different seating needs.

1. To Extend the Table:

- Unlock any table latches located underneath the table ends.
- Gently pull the two halves of the table top apart. The self-storing leaf will automatically begin to unfold from its stored position beneath the table.
- Continue pulling until the leaf is fully extended and flat.
- Push the two table halves back together, ensuring they align with the extended leaf.
- Secure any latches underneath the table to lock the extended table in place.

2. To Retract the Table:

- Unlock any table latches located underneath the table ends.
- Gently pull the two halves of the table top apart slightly.
- Carefully fold the butterfly leaf back into its stored position beneath the table.
- Push the two table halves back together until they meet.
- Secure any latches underneath the table to lock the retracted table in place.



Image: A detailed view of the table's self-storing butterfly leaf mechanism as it begins to unfold, revealing the internal structure.




Image: An illustration demonstrating the flexible seating provided by the butterfly leaf, showing how it extends and retracts for convenience.

MAINTENANCE

Proper care will ensure the longevity and appearance of your dining table. Refer to the following guidelines:

- **Cleaning:** Wipe the table surface with a soft, damp cloth. Avoid harsh chemicals, abrasive cleaners, or silicone-based polishes, as these can damage the finish.
- **Spills:** Blot spills immediately with a clean, dry cloth. Do not rub.
- **Heat and Moisture:** Use coasters and placemats to protect the surface from hot items and moisture.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or cracking.

- **Humidity:** Maintain a consistent humidity level in your home to prevent wood from expanding or contracting excessively.
- **Hardware:** Periodically check and tighten all hardware connections to ensure stability.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Table wobbles	Loose hardware; uneven floor	Check and tighten all bolts. Use furniture glides or shims to level the table on an uneven floor.
Leaf mechanism is stiff	Dust or debris in tracks; lack of lubrication	Clean the leaf extension tracks with a dry cloth. Apply a small amount of silicone-based lubricant (avoid oil-based products) to the tracks if necessary.
Table halves do not align properly	Improper alignment during extension/retraction; loose hardware	Ensure the leaf is fully extended or retracted before pushing the table halves together. Check and tighten all hardware.

SPECIFICATIONS

Brand	Signature Design by Ashley
Model Name	Neymorton Dining Extension Table
Model Number	D618-35
Product Dimensions (D x W x H)	90"D x 40"W x 30"H (Extended)
Unextended Seating Capacity	8
Extended Seating Capacity	10
Item Weight	162.8 Pounds
Color	Dark Brown
Furniture Finish	Dark Gray/Brown Stained Wood-Tone
Material Type	Engineered Wood, Mango Wood, Wood
Table Extension Mechanism	Self Storing Leaf
Recommended Number of People for Assembly	2
Tools Recommended For Assembly	Screw Driver, Wrench
UPC	024052896220

WARRANTY INFORMATION

Specific warranty details for the Signature Design by Ashley Neymorton Dining Extension Table are not provided in this manual. For information regarding warranty coverage, please refer to the documentation included with your purchase or

visit the official Signature Design by Ashley website.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Signature Design by Ashley customer service. Contact information can typically be found on the brand's official website or on your purchase receipt.

You may also visit the [Signature Design by Ashley Store on Amazon](#) for more product information.

