Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOMCOM 801-060V81LB

HOMCOM Rolling Kitchen Island Cart with Drop Leaf

Model: 801-060V81LB

Brand: HOMCOM

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your HOMCOM Rolling Kitchen Island Cart with Drop Leaf. Please read all instructions carefully before assembly and use to ensure safe and proper functionality. Keep this manual for future reference.



Image: The HOMCOM Rolling Kitchen Island Cart, Model 801-060V81LB, in a light blue finish.

Safety Information

- **Weight Capacity:** Do not exceed the maximum weight capacity of 110 lbs (50 kg) for the entire unit. Overloading can cause instability and damage.
- **Movement:** Use caution when moving the cart, especially on uneven surfaces, to prevent tipping. Ensure the locking casters are engaged when the cart is stationary to prevent unintended movement.
- **Assembly:** Assembly requires careful attention to detail. It is recommended that two people assemble the unit to ensure stability and ease of construction.
- **Tools:** Use appropriate tools for assembly. Avoid over-tightening screws, which can damage the wood.
- **Children:** Keep children away from the assembly area. Do not allow children to climb on or play with the cart.

Parts List

Before beginning assembly, verify that all parts are present and undamaged. Refer to the included hardware and parts diagram for identification.

- Main frame panels (left, right, back, bottom)
- Drawer components (front, back, sides, bottom)

- Cabinet doors and shelves
- Rubberwood countertop sections (fixed and drop leaf)
- Casters (4, with 2 locking)
- Drawer slides and handles
- Door hinges and knobs
- Spice rack, knife rack, and towel bar components
- Assorted screws, dowels, and cam locks

Setup and Assembly

Assembly is required for this kitchen island cart. Follow the step-by-step instructions provided in the packaging. It is recommended to have a second person assist with assembly for easier handling of larger components.

Assembly Video

Your browser does not support the video tag.

Video: Official HOMCOM video demonstrating the assembly and features of the kitchen cart.

General Assembly Steps:

1. **Unpack and Inspect:** Carefully unpack all components and compare them against the parts list. Report any missing or damaged parts immediately.
2. **Attach Casters:** Secure the four casters to the bottom panel of the main frame. Ensure the two locking casters are positioned at the front for easy access.
3. **Assemble Main Frame:** Connect the side and back panels to the bottom panel using the provided hardware.
4. **Install Drawer Slides:** Attach the drawer slides to the interior side panels of the main frame and to the drawer components.
5. **Assemble Drawers:** Construct the two drawers and insert them into the installed slides. Attach drawer handles.
6. **Install Cabinet Shelves:** Place the adjustable shelves inside the cabinet sections at your desired height.
7. **Attach Cabinet Doors:** Mount the cabinet doors using the provided hinges. Adjust hinges as needed to ensure doors close properly. Attach door knobs.
8. **Attach Countertop:** Secure the fixed rubberwood countertop section to the top of the main frame.
9. **Install Drop Leaf:** Attach the drop leaf countertop section using the provided hinges and support mechanisms.
10. **Attach Side Accessories:** Install the spice rack, knife rack, and towel bar to the designated side panels.



Image: Detail of the hinge for the drop leaf extension.

Operating Instructions

Expandable Countertop

The cart features a drop leaf countertop that can be extended for additional workspace or dining area, and folded down to save space.

- **To Extend:** Gently lift the drop leaf section until it is level with the main countertop. Engage the support brackets underneath to secure it in place.
- **To Fold Down:** Disengage the support brackets and carefully lower the drop leaf section until it rests against the side of the cart.



Image: The drop leaf countertop in both extended and folded positions.

Storage Features

The cart includes two drawers and two storage cabinets with adjustable shelves for organizing kitchen and dining essentials.

- **Drawers:** Pull the handles to open the smooth-gliding drawers for cutlery, utensils, or smaller items.
- **Cabinets:** Open the cabinet doors to access the interior storage. The shelves can be adjusted to accommodate items of various heights.



Image: Interior view of the storage cabinets with adjustable shelves.



Image: Detail of an adjustable shelf.

Side Racks

The cart is equipped with a spice rack, knife rack, and towel bar on its sides for convenient access to frequently used items.





Image: Integrated spice rack, knife rack, and towel bar.

Mobility

Four casters allow for easy movement of the island cart. Two of these casters are lockable to secure the cart in place.

- **To Move:** Ensure both locking casters are disengaged. Gently push the cart to your desired location.
- **To Secure:** Once in position, press down on the levers of the two locking casters until they click into place. This will prevent the cart from rolling.



Image: Casters with locking mechanism for stability.

Maintenance

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Wood Care:** The rubberwood top is water and scratch-resistant. For prolonged life, wipe up spills immediately and use cutting boards when preparing food.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Re-tighten as necessary to maintain stability.

Troubleshooting

- **Wobbly Cart:** Ensure all screws and fasteners are securely tightened. Check that the casters are properly installed and engaged if stationary.
- **Drawers Not Sliding Smoothly:** Verify that the drawer slides are correctly installed and aligned. Ensure no debris is

obstructing the tracks.

- **Cabinet Doors Not Closing Properly:** Adjust the door hinges. There are usually adjustment screws on the hinges that allow for minor alignment corrections.
- **Missing Parts:** If any parts are missing upon delivery, contact customer support for assistance.

Specifications

Overall Dimensions	57.5" W x 29.25" D x 36.75" H
Top Size (Large)	47.25" W x 18" D
Top Size (Small)	47.25" W x 11.25" D
Weight Capacity	110 lbs (total)
Material	Engineered Wood, Rubberwood Top
Color	Light Blue
Number of Drawers	2
Number of Shelves	2 (adjustable)
Assembly Required	Yes



Image: Dimensional drawing of the kitchen island cart.

Warranty and Support

This product is sold by Aosom Direct. For any product-related inquiries, missing parts, or support, please contact Aosom Direct customer service. The product is eligible for 30-day easy returns. Protection plans are available for purchase separately.

- **Returns:** 30-day easy returns.
- **Customer Support:** Contact Aosom Direct for assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DDK38QMG

More documents and user manuals: **https://manuals.plus/**