

[Manuals.plus](#) /

› [GlasFlength](#) /

› GlasFlength Zero Gravity Lounge Chair Set of 2 Instruction Manual (Model DDP-HX-HW-TY01-2P-BK)

GlasFlength DDP-HX-HW-TY01-2P-BK

GlasFlength Zero Gravity Lounge Chair Set of 2

Model: DDP-HX-HW-TY01-2P-BK

1. SAFETY INFORMATION

Please read all safety instructions carefully before using the Zero Gravity Lounge Chair. Failure to follow these instructions may result in injury or damage to the product.

- This chair has a maximum weight capacity of **300 lbs**. Do not exceed this limit.
- Always ensure the chair is fully locked in your desired position before use.
- Keep fingers and other body parts away from moving parts when adjusting the chair to prevent pinching.
- Do not leave the chair unattended with children or pets, especially when it is in a reclined or folded position.
- Place the chair on a stable, level surface to prevent tipping.

2. PACKAGE CONTENTS

Verify that all components are present before assembly. If any parts are missing or damaged, please contact customer support.

- Zero Gravity Lounge Chair (x2)
- Adjustable Headrest Pillow (x2)
- Detachable Cup Holder Tray (x2)
- Instruction Manual (x1)



Image: Two GlasFlength Zero Gravity Lounge Chairs, showcasing the complete set with accessories.

3. SETUP AND ASSEMBLY

Your GlasFlength Zero Gravity Lounge Chairs come pre-assembled and are designed for easy unfolding and setup. No complex assembly is required.

1. Carefully remove the chair from its packaging.
2. Unfold the chair by gently pulling the armrests apart until the chair is fully extended.
3. Attach the adjustable headrest pillow to the chair back using the integrated straps. Adjust its position for optimal comfort.
4. Slide the detachable cup holder tray onto the side frame of the chair. Ensure it is securely attached.
5. Before sitting, ensure all parts are stable and the chair is fully open.

4. OPERATING INSTRUCTIONS

Adjusting the Recline Angle

The chair features an adjustable lying angle from 0 to 160 degrees, allowing you to find your preferred position for sitting, relaxing, or napping.

1. While seated, gently push back on the armrests to recline the chair.
2. To lock the chair in your desired position, locate the locking levers under the armrests. Push the levers forward to engage the lock.
3. To unlock and adjust the position again, pull the levers backward.
4. To return to an upright position, lean forward and gently push the armrests forward.



Image: Illustration demonstrating the chair's lockable recline function, adjustable up to 160 degrees.

Using the Detachable Tray

The chair is equipped with a detachable tray for convenience.

- The tray has multiple compartments suitable for holding drinks, snacks, and small electronic devices.
- To attach, slide the tray onto the designated slots on the side of the chair's frame.

- To remove, simply slide the tray off.

Folding for Portability and Storage

The chair's folding design allows for easy transport and compact storage.

1. Ensure the chair is in the fully upright position and unlocked.
2. Remove the detachable cup holder tray.
3. Gently push the front and back legs towards each other until the chair folds flat.
4. Secure any locking mechanisms if present to keep the chair folded.

5. MAINTENANCE


Proper care will extend the life of your Zero Gravity Lounge Chair.

- **Cleaning the Mesh Fabric:** The breathable mesh fabric is designed for easy cleaning. Wipe down with a damp cloth and mild soap. Rinse thoroughly and allow to air dry completely before folding or storing.
- **Frame Care:** The alloy steel frame is robust. Wipe with a damp cloth to remove dirt and debris. Avoid harsh chemicals that may damage the finish.
- **Storage:** When not in use for extended periods, especially during inclement weather, it is recommended to fold the chairs and store them in a dry, protected area to prevent wear and tear.
- **Inspection:** Periodically check all bolts, screws, and moving parts to ensure they are secure. Tighten if necessary.

COMFORTABLE DESIGN

Body Curve Fitting

- ✓ Superior sitting experience



Thickened Headrest

- ✓ Thick sponge filling
- ✓ Relieve head pressure

Image: Detail of the high-quality, wear-resistant mesh fabric used in the chair's construction.

6. TROUBLESHOOTING

If you encounter any issues with your Zero Gravity Lounge Chair, please refer to the following common solutions:

- **Chair does not recline smoothly:** Check for any obstructions in the reclining mechanism. Ensure the locking levers are fully disengaged.
- **Chair feels unstable:** Verify that the chair is placed on a flat, level surface. Check all frame connections and tighten any loose bolts.
- **Cup holder tray is loose:** Ensure the tray is correctly aligned and fully slid into its designated slots on the chair frame.

If these steps do not resolve the issue, please contact GlasFlength customer support for further assistance.

7. SPECIFICATIONS

Brand	GlasFlength
Model Name	Zero Gravity Lounge Chair Set of 2
Item Model Number	DDP-HX-HW-TY01-2P-BK
Product Dimensions	33.8"D x 8.6"W x 25.9"H (Folded)
Item Weight	34 pounds (per set)
Material	Alloy Steel (Frame), Mesh (Fill Material)
Color	Black
Maximum Weight Recommendation	300 Pounds
Reclining Position Count	Adjustable (0-160 degrees)
Indoor/Outdoor Usage	Outdoor

8. WARRANTY AND SUPPORT

GlasFlength is committed to providing high-quality products. For warranty information or customer support, please refer to the contact details provided at the point of purchase or visit the official GlasFlength website.

When contacting support, please have your product model number (DDP-HX-HW-TY01-2P-BK) and purchase date available.

© 2024 GlasFlength. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question