Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOMCOM 921-171V85BG

HOMCOM 921-171V85BG Vibrating Massage Office Chair User Manual

Model: 921-171V85BG

Introduction

This manual provides essential information for the safe and efficient use of your HOMCOM 6-Point Vibrating Massage Office Chair with Heat. Please read these instructions carefully before assembly and operation, and retain them for future reference.

Safety Information

For your safety and to prevent damage to the product, observe the following:

- This chair has a maximum weight capacity of 264 pounds (120 kg). Do not exceed this limit.
- This chair is recommended for office use only.
- Ensure all components are securely fastened before use. Regularly check and tighten fasteners as needed.
- Keep children and pets away from the chair during assembly.
- Do not stand on the chair.
- Avoid exposing the chair to direct sunlight or extreme temperatures.

Package Contents

Verify that all parts are present before beginning assembly. Refer to the included assembly diagram for a complete list of components.



Figure 1: The product is delivered in one package.

Setup and Assembly

Assembly typically takes approximately 30 minutes. Tools required for assembly are included. Follow the pictorial instructions

provided in the separate assembly guide.



Figure 2: Main components for assembly. Ensure all parts are accounted for before starting.

General Assembly Tips:

- Lay out all parts on a clean, soft surface to prevent scratches.
- Do not fully tighten screws until all components are loosely assembled.
- If wheels are difficult to insert, a rubber mallet can be used to gently tap them into place.

Operating Instructions

1. Massage and Heat Functions

The chair features a six-point vibration massage system and lumbar heating. These functions are controlled via the included remote control, which can be stored in the side pocket.



Figure 3: Remote control for massage and heat settings.

Remote Control Functions:

- **Power Button:** Turns the massage and heat functions on/off.
- **Mode Selection:** Cycle through 9 different massage modes (e.g., pulse, constant, variable).
- **Intensity Adjustment:** Select from 3 intensity levels for the vibration massage.
- **Timer Setting:** Set the massage duration to 15 or 30 minutes.
- **Zone Selection:** Independently activate massage for the back, lumbar, and seat areas.
- **Heat Function:** Activates lumbar heating. Allow a few minutes for the heat to warm up.

2. Reclining Function

The chair features a 125° reclining backrest, allowing you to lean back for relaxation.



Figure 4: The chair's 125° reclining capability.

To recline, pull the lever located on the side of the chair upwards. Lean back to your desired angle, then push the lever down to lock the position. To return to an upright position, pull the lever up and lean forward.

3. Tilt Function and Adjustable Height

The chair offers a tilt function and adjustable seat height to customize your seating experience.



Figure 5: Demonstrating tilt and height adjustment.

Adjusting Seat Height: Pull the lever located under the seat upwards while taking your weight off the seat to raise it, or while sitting on it to lower it. Release the lever to lock the height.
Activating/Deactivating Tilt: The same lever used for height adjustment can also control the tilt function. Push the lever inwards to lock the chair in an upright position, or pull it outwards to allow the chair to tilt freely. A tension knob under the seat allows you to adjust the resistance of the tilt mechanism.

[redacted]

Video 1: Demonstration of the chair's massage, recline, and height adjustment features.

Maintenance

Proper maintenance ensures the longevity and performance of your office chair.

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the microfiber fabric.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary.
- **Moving:** When moving the chair, lift it rather than dragging it to prevent damage to the base and floor.

Troubleshooting

If you encounter issues with your chair, refer to the following common solutions:

Problem	Possible Cause	Solution
Chair does not recline or tilt.	Recline/tilt lock engaged.	Ensure the recline/tilt lever is pulled outwards to unlock. Check the tension knob for appropriate resistance.
Massage/Heat function not working.	Power connection issue or remote battery.	Ensure the chair is properly plugged into a power outlet. Check the remote control for battery issues.
Chair height adjustment not working.	Gas lift lever not engaged or faulty gas lift.	Ensure the height adjustment lever is fully pulled up. If the issue persists, contact customer support.
Chair is unstable or wobbly.	Loose fasteners.	Check and tighten all assembly screws and bolts.

Specifications

Detailed specifications for your HOMCOM office chair:



Figure 6: Key dimensions of the office chair.

Feature	Detail
Model Number	921-171V85BG
Overall Dimensions	25.5"W x 28"D x 43.25"-47.25"H
Seat Size	20.5"W x 19.75"D
Adjustable Seat Height	17.75"-21.75"H
Arm Height (from floor)	25.5"-29.5"H
Backrest Width	20.5 Inches
Maximum Weight Capacity	264 lbs (120 kg)
Material	Microfiber Fabric, Foam Fill
Massage Points	6-point vibration
Heat Function	Lumbar heating
Recline Angle	Up to 125°
Included Components	Remote Control
Item Weight	37 Pounds

Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official HOMCOM website. Keep your purchase receipt for warranty claims.

© 2024 HOMCOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DDKDQ49R

More documents and user manuals: **https://manuals.plus/**