HAPPYGRILL HG2825

HAPPYGRILL 3 Pieces Acacia Wood Patio Bistro Set Instruction Manual

Model: HG2825

PRODUCT OVERVIEW

This HAPPYGRILL 3-piece patio bistro set is crafted from solid acacia wood, featuring a round table and two patio chairs. Each chair includes soft cushions for enhanced comfort. Designed for outdoor use, this set is suitable for various settings such as porches, balconies, decks, gardens, and backyards. Its folding design allows for convenient storage and space-saving when not in use.

The set is constructed from high-quality acacia wood, known for its longevity and splinter-free properties. The robust framework ensures stability, with each chair supporting up to 400 lbs and the table supporting up to 180 lbs.

Image: The HAPPYGRILL 3 Pieces Acacia Wood Patio Bistro Set, featuring a round table and two chairs with off-white cushions, placed on a balcony overlooking greenery.

Setup Instructions

Your HAPPYGRILL patio bistro set comes with all necessary components for assembly. Please follow the detailed assembly instructions provided in the package. It is crucial to ensure all holes are aligned before tightening any screws. Failure to do so may result in misaligned screw holes or uneven furniture legs.

- Unpack all components and verify against the parts list in the included instruction manual.
- Identify all hardware and tools required for assembly.
- Assemble the chairs and table according to the step-by-step guide.
- **Important:** Do not fully tighten screws until all parts are loosely assembled and aligned. Once aligned, tighten all screws securely.
- Place the seat cushions on the chairs and secure them using the integrated fixing ties.

Image: The bistro set in its folded state, demonstrating its space-saving design. A close-up shows the swivel snap fastening mechanism for the table.

OPERATING THE FOLDING MECHANISM

The HAPPYGRILL bistro set is designed for easy folding and unfolding, allowing for flexible use and storage.

Folding the Table:

1. Ensure the table surface is clear of all items.
2. Locate the swivel snap fastenings underneath the tabletop.
3. Release the fastenings to allow the table legs to fold inward.
4. Carefully fold the table flat for compact storage.

Folding the Chairs:

1. Remove the seat cushions.
2. Gently push the backrest towards the seat, allowing the chair to collapse.
3. Fold the chair flat for storage.

Using the Cushions:

The included soft cushions provide enhanced comfort. Each cushion features fixing ties to prevent it from slipping off the chair seat. Securely tie the cushions to the chair frame when in use.

Image: A detailed view of the soft cushion, highlighting its washable cover with a zipper and the fixing ties used to secure it to the chair.

CARE AND MAINTENANCE

Proper care will extend the lifespan and maintain the appearance of your HAPPYGRILL patio bistro set.

Acacia Wood Frame:

- Wipe the acacia wood frame with a dry cloth to remove dust and debris.
- For deeper cleaning, use a damp cloth with mild soap, then wipe dry immediately.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the wood finish.
- To maintain the wood's natural beauty and protect it from weathering, periodic application of wood oil is recommended.
- Store the set in a dry, covered area during prolonged periods of non-use or harsh weather conditions.

Cushions:

- The cushion covers are removable and washable for convenience.
- Follow the washing instructions on the cushion label. Typically, machine wash cold on a gentle cycle and air dry.
- Always keep cushions dry to prolong their service life and prevent mold or mildew growth. Store cushions indoors when not in use or during inclement weather.

TROUBLESHOOTING

If you encounter any issues with your bistro set, please refer to the following common solutions:

- **Wobbling or Instability:** Ensure all screws and bolts are securely tightened. If the issue persists, disassemble and reassemble the affected part, paying close attention to alignment.
- **Difficulty Folding/Unfolding:** Check for any obstructions in the folding mechanism. Ensure the swivel snap fastenings on the table are fully released. Apply a small amount of lubricant to hinges if movement is stiff.
- **Cushions Slipping:** Verify that the fixing ties are securely fastened to the chair frame.
- **Wood Discoloration/Weathering:** This is natural for outdoor wood furniture. Regular cleaning and application of wood oil can help maintain its appearance.

For issues not covered here, please contact HAPPYGRILL customer support.

PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	HG2825
Material	Acacia Wood, Polyester, Sponge, Non-Woven Fabric
Color of Cushion	Off White
Color of Frame	Natural
Unfolded Chair Dimensions (L x W x H)	22.5" x 19.5" x 34" (57 x 49 x 86 cm)
Folded Chair Dimensions (L x W x H)	39.5" x 19.5" x 5" (100 x 49 x 13 cm)
Unfolded Table Dimensions (Dia x H)	24" x 29" (60 x 74 cm)
Folded Table Dimensions (L x W x H)	38" x 24" x 2.5" (97 x 60 x 6 cm)
Seat Height	18" (45 cm)
Seat Depth	15" (38 cm)
Each Seat Cushion (L x W x Thickness)	15" x 15" x 2" (38 x 38 x 5 cm)
Weight Capacity of Each Chair	400 lbs (180 kg)
Weight Capacity of Table	180 lbs (80 kg)

Feature	Detail
Total Net Weight	33 lbs (15 kg)
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth

Image: A visual representation of the product dimensions for both the chairs and the table, including folded and unfolded measurements, along with their respective weight capacities.

WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available documentation. For any warranty claims, product support, or inquiries, please contact HAPPYGRILL customer service directly through their official channels or the retailer from whom the product was purchased.