

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Corberó](#) /

› [Corberó CCVM4604 Vitroceramic Hob User Manual - 4 Zones, 6000W](#)

Corberó CCVM4604

Corberó CCVM4604 Vitroceramic Hob User Manual

Model: CCVM4604 | 4 Zones | 6000W Power

1. INTRODUCTION AND SAFETY INFORMATION

Thank you for choosing the Corberó CCVM4604 Vitroceramic Hob. This manual provides essential information for the safe and efficient use of your appliance. Please read it thoroughly before installation and operation, and keep it for future reference.

Important Safety Instructions:

- Ensure the appliance is installed by a qualified professional.
- Do not touch hot surfaces. Use handles or knobs.
- Supervise children when the appliance is in use. This hob includes a safety lock feature to prevent accidental operation by children.
- Never use the hob for space heating.
- Do not store flammable materials on or near the hob.
- In case of a fault, disconnect the appliance from the power supply.
- The hob features automatic disconnection for enhanced safety.

2. INSTALLATION AND SETUP

Installation must be carried out by a qualified electrician or technician in accordance with local regulations and safety standards.

Product Dimensions:

Product Dimensions: 50 cm (depth) x 87.4 cm (width) x 6 cm (height)

Weight: 8.96 kg

Total Power: 6000 W

Voltage: 230 Volts


Cutout Dimensions:

For proper integration into your kitchen countertop, ensure the cutout dimensions are as follows:

Cutout Width: 56 cm

Cutout Depth: 48 cm

Cutout Height: 4.7 cm



- 6000 W de potencia total
- Dimensiones placa: 59x52x5,1 cms
- Dimensiones hueco: 56x48x4,7 cms

Corberó

Image: Corberó CCVM4604 Vitroceramic Hob showing total power (6000W), plate dimensions (59x52x5.1 cm), and cutout dimensions (56x48x4.7 cm).

3. OPERATING INSTRUCTIONS

The Corberó CCVM4604 features a user-friendly touch control panel for precise cooking adjustments.




Image: Corberó CCVM4604 Vitroceramic Hob highlighting the touch control panel and its 4 cooking zones.

Control Panel Overview:

- **Power On/Off:** Press the power symbol to turn the hob on or off.
- **Zone Selection:** Select the desired cooking zone by touching its corresponding control.
- **Power Level Adjustment:** Use the '+' and '-' buttons to adjust the power level from 1 to 9.
- **Timer Function:** The 99-minute timer allows you to set a specific cooking duration. Select the zone, then activate the timer and adjust the minutes using '+' and '-'.
- **Safety Lock:** Activate the safety lock to prevent accidental changes to settings or unintended operation, especially useful with children around.

The hob provides 9 power levels, offering flexibility for various cooking needs, from gentle simmering to rapid boiling.

4. CLEANING AND MAINTENANCE

Regular cleaning and proper maintenance will ensure the longevity and optimal performance of your Corberó Vitroceramic Hob.

Cleaning Instructions:

- Always ensure the hob is cool and disconnected from the power supply before cleaning.
- For daily cleaning, wipe the ceramic surface with a soft cloth and a mild detergent.
- For stubborn stains or burnt-on food, use a specialized ceramic hob cleaner and a scraper designed for glass-ceramic surfaces.
- Avoid abrasive cleaners, scouring pads, or harsh chemicals, as these can scratch or damage the surface.

- Wipe dry with a clean cloth to prevent water marks.

5. TROUBLESHOOTING GUIDE

If you encounter any issues with your hob, please refer to the following common troubleshooting steps before contacting customer service.

Problem	Possible Cause	Solution
Hob does not turn on.	No power supply; Safety lock activated.	Check power connection and circuit breaker; Deactivate child safety lock.
Cooking zone not heating.	Incorrect power level selected; Pan not suitable.	Increase power level; Ensure pan base is flat and covers the zone.
Display shows an error code.	Internal fault or sensor issue.	Turn off the hob, wait a few minutes, then restart. If the error persists, contact customer support.

6. TECHNICAL SPECIFICATIONS

Brand: Corberó

Model Number: CCVM4604

Color: Black

Material: Vitroceramic

Number of Heating Zones: 4

Total Power: 6000 W

Voltage: 230 Volts

Product Dimensions (L x W x H): 50 cm x 87.4 cm x 6 cm

Product Weight: 8.96 kg

Control Type: Touch Control

Power Levels: 9

Timer: Up to 99 minutes

Safety Features: Automatic Disconnection, Child Safety Lock

7. WARRANTY AND CUSTOMER SUPPORT

For warranty information, please refer to the documentation provided with your purchase or contact your retailer. For technical assistance or customer support, please visit the official Corberó website or contact their authorized service centers.

You can find more information about Corberó products and support at: [Corberó Official Store](#)

