

Remington XR1770-1TV

Remington Limitless X7 Rotary Shaver Instruction Manual

Model: XR1770-1TV

INTRODUCTION

The Remington Limitless X7 Rotary Shaver is designed to provide an efficient and comfortable shaving experience. This manual provides detailed instructions for the proper use, care, and maintenance of your shaver to ensure optimal performance and longevity.

The Limitless X7 features a 360° PivotBall for constant skin contact, individual flexing blades for adapting to facial contours, Shave Comfort Rings to reduce friction, and PowerSense Technology to maintain consistent speed. It is 100% waterproof for versatile wet or dry shaving.

360° PivotBall

effortlessly follows facial contours to capture hair



Front view of the Remington Limitless X7 Rotary Shaver.

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using this appliance. When using electrical appliances, basic safety precautions should always be observed.

- Always unplug the shaver and allow it to cool before cleaning.
- Do not use the shaver while it is charging or near water.
- Keep blades away from children and store the shaver safely.
- Always replace the head guard when the shaver is not in use.
- Clean the shaver after each use and allow it to dry completely to prevent bacterial growth.
- Always hold the shaver away from your face when turning it on or off to avoid injury from sudden movements.
- Exercise caution when using the detail trimmer attachment as it has sharp edges.

PRODUCT FEATURES

360° PivotBall

The unique 360° PivotBall design allows the shaver head to move effortlessly in any direction, maintaining constant skin contact. This feature helps the shaver follow the unique contours of your face, capturing hair even in tricky areas like the jawline and neck for a close and comfortable shave.



The 360° PivotBall effortlessly follows facial contours.

PowerSense Technology

PowerSense Technology continuously monitors and responds to pressure, analyzing hair thickness 800 times per second. This ensures the shaver maintains optimal speed and power for a consistently clean shave, even through denser hair areas.

100% Waterproof

shave dry, with shaving cream,
or in the shower



PowerSense Technology analyzes hair thickness to maintain speed.

SynX™ Hybrid Cutting System & Titanium Coated Blades

The advanced SynX™ hybrid cutting system combines the efficiency of a rotary shaver with the comfort and closeness typically associated with a foil shaver. The blades are titanium coated for enhanced durability and sustained sharpness, ensuring long-lasting cutting performance.

Detail Trimmer

great for sideburns or mustache



The SynX™ Hybrid Cutting System offers both power and comfort.



Titanium Coated Twin Track Blades are designed for durability and sharpness.

Individual Flexing Blades & Shave Comfort Rings

Individual flexing blades move independently to adapt to your unique face shape, capturing more hair in fewer passes. Shave Comfort Rings are integrated to reduce friction by up to 30%, enhancing glide and providing a comfortable shave, especially for sensitive skin.

Titanium Coated Twin Track Blades

two tracks of shaving blades are titanium coated to stay sharper, longer



Active Contour & Flex Control adapts to every angle for a close shave.

100% Waterproof Design


The shaver is fully waterproof, allowing for versatile use with foam or gel, or even in the shower. This design facilitates easy cleaning and adapts to various shaving routines.

Detail Trimmer

An integrated detail trimmer is included for precise grooming, ideal for shaping sideburns or maintaining a mustache.

Rapid Charging & Cordless Convenience

The shaver features a rapid-charge lithium battery, providing up to 60 minutes of cordless runtime on a 90-minute charge. A 5-minute quick charge offers approximately 3 minutes of power for urgent use. LED indicators display the battery status (full, actively charging, low, or needs charging).



LED Power charge panel indicates battery status and charging progress.

SETUP

Initial Charge

Before first use, fully charge your Remington Limitless X7 Shaver for 90 minutes. Connect the USB charging cable to the shaver and a compatible USB power adapter (not included). The LED indicators will show the charging status. A full charge provides up to 60 minutes of cordless operation.

Attaching/Detaching Shaver Head

The shaver head is designed for easy attachment and detachment. To remove, gently pull the head upwards from the shaver body. To attach, align the head with the body and press down until it clicks securely into place. Ensure the head is properly seated before use.

OPERATING INSTRUCTIONS

Basic Shaving

For optimal results, hold the shaver at a right angle to your skin and move it in small, circular motions. You can use the shaver dry, with shaving cream or gel, or in the shower due to its 100% waterproof design. For best performance, ensure your skin is clean and dry for dry shaving, or adequately lubricated for wet shaving.

Using the Detail Trimmer

To activate the detail trimmer, slide the trimmer switch upwards. Use the trimmer for precise shaping of sideburns, mustaches, or other facial hair. After use, slide the switch back down to retract the trimmer.

Turbo Mode

For thicker hair or areas requiring extra power, press the Turbo Mode button. This will temporarily increase the shaver's speed and cutting power. Press the button again to return to standard mode.

Video Demonstration

Watch this official product overview video for a visual guide on using the Remington Limitless X7 Rotary Shaver.

Your browser does not support the video tag.

Official product overview video for the Remington Limitless X7 Shaver, demonstrating its features and use.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene for your shaver.

Daily Cleaning

After each shave, rinse the shaver head thoroughly under warm running water. For best results, you can open the shaver head to allow water to flow through the internal components. Ensure all hair clippings are washed away. Shake off excess water and allow the shaver to air dry completely before storing.



Rinse the shaver head under warm running water after each use.

Deep Cleaning

Periodically, perform a deeper clean. Detach the shaver head from the body. Use the provided cleaning brush to remove any stubborn hair clippings from the blades and internal mechanisms. Do not disassemble the individual rotary cutters. Rinse the head again and allow it to dry completely before reattaching.



Use the cleaning brush to remove hair clippings from the shaver head.

Blade Replacement

For continued optimal shaving performance, it is recommended to replace the shaver head and blades every 12 months, or sooner if you notice a decrease in performance or increased irritation. Replacement parts can be purchased from authorized Remington retailers or the official Remington website.

TROUBLESHOOTING

If you encounter any issues with your Remington Limitless X7 Shaver, please refer to the following common problems and solutions:

- **Shaver not turning on or holding a charge:**

Ensure the shaver is fully charged. Check the charging cable and adapter for damage. Clean the charging port for any debris. If the issue persists, the battery may need servicing or replacement.

- **Reduced shaving performance or pulling:**

Clean the shaver head thoroughly to remove any accumulated hair or debris. Ensure the blades are not dull; consider replacing the shaver head if it has been in use for an extended period (e.g., over 12 months).

- **Skin irritation after shaving:**

Ensure the shaver head is clean. Try using the shaver with shaving cream or gel for a wet shave. Allow your skin to adapt to the new shaver; irritation may decrease with continued use. If irritation persists, consult a dermatologist.

- **Shaver making unusual noise:**

Clean the shaver head thoroughly. Ensure all components are correctly assembled. If the noise continues, contact customer support.

SPECIFICATIONS

Feature	Detail
Product Dimensions	9.06 x 5.55 x 3.54 inches
Weight	1.12 Pounds
Item Model Number	XR1770-1TV
UPC	074590557565
Manufacturer	Remington
Brand	Remington
Recommended Uses	Beard, Face, Mustache
Special Features	Battery Indicator, Fast Charging, Interchangeable Trimmer Heads, Rechargeable, Waterproof
Power Source	Corded Electric (for charging)
Model Name	Limitless X7 Shaver

WARRANTY AND SUPPORT

For warranty information, product registration, or to contact customer support, please refer to the warranty card included with your product or visit the official Remington website. Keep your proof of purchase for warranty claims.

You can also visit the [Remington Store on Amazon](#) for additional product information and accessories.