

[Manuals.plus](#) /

> [eufy Security](#) /

> eufy Security SmartTrack Card E30 Instruction Manual

eufy Security T87B1

eufy Security SmartTrack Card E30 Instruction Manual

Model: T87B1

1. PRODUCT OVERVIEW

The eufy Security SmartTrack Card E30 is a compact, rechargeable Bluetooth tracker designed to help you locate your personal belongings. It integrates seamlessly with Apple's Find My network, allowing you to track items globally using your iOS devices. Its slim design makes it ideal for wallets, passport holders, and laptop cases.

Key Features:

- **Apple Find My Integration:** Easily connect to the Apple Find My app for global tracking via the extensive Apple device network.
- **Rechargeable Battery:** Enjoy up to 1 year of battery life on a single charge.
- **Water-Resistant:** Designed for durability, even in rainy conditions.
- **Ultra-Loud Alarm:** An 80dB alarm helps you locate items quickly, even in noisy environments.
- **Slim Design:** At just 2.6 millimeters thick, it fits discreetly into wallets and other slim compartments.
- **Left-Behind Alerts:** Receive instant notifications on your iOS device if you leave an item behind (via Find My app).
- **Shareable Location:** Share the location of your items with friends and family through the eufy Security app.

2. WHAT'S IN THE BOX

- SmartTrack Card E30
- Quick Start Guide
- USB-C Cable
- Magnetic Charging Adapter

Note: The magnetic charging adapter is compact. Store it carefully to prevent loss.




Image: Contents of the eufy SmartTrack Card E30 package, including the card, USB-C cable, and magnetic charging adapter.

3. SETUP

3.1 Charging the SmartTrack Card

Before initial use, fully charge your SmartTrack Card E30. The battery can last up to one year on a single charge.


1. Connect the USB-C cable to the magnetic charging adapter.
2. Attach the magnetic charging adapter to the charging pins on the SmartTrack Card E30.
3. Plug the USB-C cable into a compatible USB power source (not included).

Charging Indicator:

- Blue breathing light: Device is charging.
- Solid blue light: Device is fully charged.
- Red light flashes when button is pressed: Battery is low.

Convenient USB-C Charging

SmartTrack Card is equipped with a rechargeable battery to last for up to a year on a single charge.



Note: The USB-C cable and adapter are included. The charging head is not included. To check the charging status of SmartTrack: A flashing blue light indicates the device is charging. A steady blue light means it is fully charged. Press the button, and if a red light appears, the battery is out of power.

Image: Step-by-step illustration of connecting the USB-C cable to the magnetic adapter and then to the SmartTrack Card E30 for charging.

Your browser does not support the video tag.

Video: Official eufy tutorial demonstrating how to install and charge the eufy SmartTrack Card E30.

3.2 Pairing with Apple Find My

The eufy SmartTrack Card E30 works with Apple Find My (iOS only).

1. Open the Apple Find My app on your iOS device.
2. Tap on the "Items" tab at the bottom of the screen.
3. Tap "Add Item" and then select "Other Supported Item".
4. Press and hold the button on your SmartTrack Card E30 until it emits a sound and the app detects it.
5. Follow the on-screen instructions to name your item and choose an emoji.
6. Confirm the connection and agree to the terms.



Image: The eufy SmartTrack Card E30 displayed next to an iPhone showing its location on the Apple Find My map interface.

4. OPERATING INSTRUCTIONS

4.1 Locating Your Item

To find your misplaced item:

1. Open the Apple Find My app on your iOS device.
2. Select the SmartTrack Card E30 from your "Items" list.
3. Tap "Play Sound" to make the card emit an 80dB alarm, guiding you to its location.
4. If the item is far away, use the map to navigate to its last known location.



Image: An illustration showing the SmartTrack Card E30 emitting sound waves from a wallet hidden in a couch, with a phone displaying the Find My app.

4.2 Left-Behind Alerts

Receive notifications if you accidentally leave your item behind:

- Ensure "Notify When Left Behind" is enabled for your SmartTrack Card E30 in the Apple Find My app settings.
- You will receive an instant notification on your iOS device when the card is no longer detected near you.

Super Thin to Fit in Your Wallet



Image: An iPhone screen showing a "Wallet left behind" notification, with the eufy SmartTrack Card E30 partially visible in a wallet on a table.

4.3 Finding Your Phone (eufy Security App)

If you misplace your iPhone, you can use the SmartTrack Card E30 to make it ring, even if it's on silent mode. This feature requires the eufy Security app.

- Ensure the eufy Security app is installed and the SmartTrack Card E30 is linked.
- Double-press the button on the SmartTrack Card E30. Your iPhone will ring.

Free Left-Behind Alerts Never Worry Again



TIME SENSITIVE

Now

"Wallet" left behind

This item is no longer detected near you. It was last seen near 3610 Jessie St.



Note: This function is only valid in Apple Find My and is for iOS only.

Image: A hand holding the eufy SmartTrack Card E30, with an iPhone in the background displaying an incoming call from "eufy Security" while on silent mode.

4.4 Lost Mode and QR Code

If your SmartTrack Card E30 is lost, you can enable Lost Mode in the eufy Security app. This allows anyone who finds your card to scan the QR code on its back to view your contact information and help return it.

Dual App Protection

Apple users have the simultaneous dual power of Find My and the eufy app to take advantage of eufy speed and the Apple network.

	 Works with Apple Find My	 Works with eufy App
Worldwide Tracking		—
Loud Alarm		
Left-Behind Alarm		—
Find Silent Phones	—	
Connect with Finder	—	
Share Your Items	—	

Image: An illustration showing a hand scanning the QR code on the back of the eufy SmartTrack Card E30 with a smartphone, revealing contact information for the owner.

5. MAINTENANCE

5.1 Battery Charging

Recharge the SmartTrack Card E30 when the battery low indicator (red light flash) appears. Use the provided USB-C cable and magnetic charging adapter.

5.2 Water Resistance

The SmartTrack Card E30 is water-resistant, offering protection against splashes and light rain. Avoid submerging the device in water or exposing it to high-pressure water jets.

6. TROUBLESHOOTING

- **Cannot connect to Find My app:** Ensure Bluetooth is enabled on your iOS device. Press and hold the button on the SmartTrack Card E30 to activate pairing mode. Make sure your iOS device is running the latest software version.
- **Alarm is not loud enough:** Ensure there are no obstructions blocking the speaker on the SmartTrack Card E30.
- **Battery drains quickly:** Frequent use of the "Play Sound" feature or being constantly out of range can affect battery life. Ensure the card is fully charged.
- **Magnetic charging adapter lost:** The magnetic charging adapter is essential for recharging. Keep it in a safe place, such as the original packaging box, to prevent loss.

7. SPECIFICATIONS

Feature	Detail
Model Number	T87B1
Brand	eufy Security
Dimensions	Approximately 2.6 mm thick
Material	Plastic, Silicone

Battery Life	Up to 1 year per charge
Connectivity	Bluetooth
Compatible Devices	iOS Smartphones (Apple Find My app)
Alarm Volume	80dB

8. WARRANTY AND SUPPORT

The eufy Security SmartTrack Card E30 comes with a 1-year limited warranty. For warranty claims, technical support, or further assistance, please refer to the contact information provided in your Quick Start Guide or visit the official eufy Security website.

Online resources and FAQs are available at www.eufylife.com.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0DDL6D7L8>

More documents and user manuals: <https://manuals.plus/>