

Auronic AU3272

Auronic AU3272 Compact Series Dehumidifier User Manual

Model: AU3272

INTRODUCTION

Thank you for choosing the Auronic AU3272 Compact Series Dehumidifier. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before use and keep it for future reference.

The Auronic AU3272 is designed to improve air quality by removing excess moisture, preventing mold growth, and eliminating musty odors in spaces up to 40 m². It features a 20-liter per day dehumidification capacity, a 4-liter water tank, and a laundry drying function.

IMPORTANT SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before using the appliance.
- Do not operate the dehumidifier if the power cord or plug is damaged.
- Ensure the appliance is placed on a stable, level surface.
- Do not block air inlets or outlets. Maintain at least 20 cm clearance around the unit.
- Do not use the appliance near water or in excessively wet environments (e.g., directly in a shower).
- Unplug the dehumidifier before cleaning or performing any maintenance.
- Keep out of reach of children.
- If the unit has been tilted more than 45 degrees, wait at least 24 hours before plugging it in and turning it on. This allows the refrigerant to settle.

PRODUCT OVERVIEW

The Auronic AU3272 Dehumidifier is a compact and efficient appliance designed for various indoor environments.

Compact Series

Optimaal ontvochtigen en effectief reinigen



Image: The Auronic AU3272 Dehumidifier positioned in a living room, demonstrating its compact design and suitability for home environments.

Verpakkingsinhoud



Image: Contents of the Auronic AU3272 Dehumidifier package, including the dehumidifier unit, power cord, drainage hose, and user manual.

SETUP

Unpacking and Placement

1. Carefully remove the dehumidifier from its packaging.
2. Inspect the unit for any damage. If damaged, do not operate and contact customer support.
3. Place the dehumidifier upright on a firm, level surface in the desired location. Ensure there is at least 20 cm of clear space around all sides for proper airflow.
4. If the unit was tilted during transport, allow it to stand upright for at least 24 hours before plugging it in. This is crucial for the compressor's proper function.
5. The unit is suitable for rooms up to 40 m².

Power Connection

- Ensure the power switch is in the OFF position.
- Plug the power cord securely into a grounded electrical outlet.

Water Drainage Options

Your dehumidifier offers two drainage methods:

1. Manual Drainage (Water Tank)

- The dehumidifier will collect moisture in its 4-liter water tank.
- When the tank is full, the unit will automatically shut off and an indicator light will illuminate.
- Carefully remove the water tank, empty it, and reinsert it firmly until it clicks into place.

2. Continuous Drainage (Drainage Hose)

- For continuous operation without emptying the tank, attach the included drainage hose to the continuous drainage port on the back of the unit.
- Ensure the hose is directed downwards to a suitable drain or container, allowing gravity to facilitate water flow.
- Make sure the hose is not kinked or blocked.

OPERATING INSTRUCTIONS

The control panel allows you to manage all functions of your dehumidifier.

Eenvoudig bedienen

Snel en simpel in te stellen



Image: Close-up of the Aurolic AU3272 Dehumidifier's digital control panel with touch buttons for various functions like speed, sleep/reset, lock, timer, mode, and power.

Control Panel Functions

- **STAND-BY (Power On/Off):** Press to turn the unit on or off.
- **MODE:** Cycles through the three operating modes:
 - **Auto Mode:** The unit automatically adjusts its operation based on the ambient humidity to maintain a comfortable level.
 - **Continuous Dry Mode:** The unit operates continuously to remove moisture, ideal for very damp conditions or laundry drying.
 - **Sleep Mode:** Reduces fan speed and dims display lights for quiet operation during the night.
- **TIMER:** Sets a timer for automatic shut-off. Press repeatedly to select the desired operating duration.
- **SPEED:** Adjusts the fan speed (e.g., Low, High).
- **SLEEP/RESET:** Activates Sleep Mode or resets certain functions (refer to specific error codes in troubleshooting).
- **LOCK:** Activates the child lock function to prevent accidental changes to settings. Press and hold to

activate/deactivate.

- **Humidity Adjustment Buttons (Up/Down arrows):** Used to set the desired humidity level in Auto Mode.
- **Digital Display:** Shows current humidity, timer settings, and error codes.

Laundry Drying Function

The dehumidifier can assist in drying laundry faster. Place the unit in a small, enclosed room with your wet clothes. Select the "Continuous Dry Mode" for optimal results. The 360-degree airflow helps to homogeneously dehumidify the air, speeding up drying times.



Onttrekt tot 20 liter vocht

Effectief voor ruimtes tot 40m²

Slimme vochtigheidsmeter

Was-droog functie

Stil in gebruik

Image: The Auronic AU3272 Dehumidifier operating in a bathroom, illustrating its effectiveness in high-humidity areas and its compact size.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your dehumidifier.

Cleaning the Water Tank

- Empty the water tank regularly.

- Clean the tank with mild detergent and warm water periodically to prevent mold and bacteria growth. Rinse thoroughly.
- Ensure the tank is completely dry before reinserting it.

Cleaning the Air Filter

A clean air filter is essential for efficient operation. While not explicitly detailed in the product description, most dehumidifiers have a removable, washable air filter.

- Unplug the unit before cleaning.
- Locate and remove the air filter (usually on the back or side of the unit).
- Wash the filter with warm, soapy water. Rinse thoroughly and allow it to air dry completely before reinserting.
- Clean the filter every two weeks or more frequently if the unit is used in a dusty environment.

Cleaning the Exterior

- Wipe the exterior of the unit with a soft, damp cloth.
- Do not use harsh chemicals, abrasive cleaners, or solvents, as these can damage the surface.

TROUBLESHOOTING

Before contacting customer support, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Unit does not turn on.	No power, power cord loose, water tank full or incorrectly inserted.	Check power connection. Empty and reinsert water tank correctly.
Unit is running but not collecting water.	Room humidity too low, temperature too low, air filter clogged, unit in fan-only mode.	Check ambient humidity. Ensure room temperature is above 5°C. Clean air filter. Select appropriate dehumidification mode.
Unusual noise during operation.	Unit not on a level surface, fan obstruction, internal component issue.	Ensure unit is on a flat surface. Check for obstructions around fan. If noise persists, contact support.
Humidity reading seems inaccurate initially.	Sensor needs time to stabilize.	Allow a few minutes for the sensor to accurately measure room humidity after startup.
Unit enters defrost function frequently.	Ambient temperature is low (around 20°C or below).	This is normal operation to prevent ice buildup on coils in cooler conditions. The unit will resume dehumidifying once defrosted.

If the problem persists after trying these solutions, please contact customer support.

SPECIFICATIONS

Model Number	AU3272
Dehumidification Capacity	20 Liters/day

Water Tank Volume	4 Liters
Recommended Room Size	Up to 40 m ²
Product Dimensions (D x W x H)	23.7 x 34.3 x 57 cm
Weight	13.6 kg
Wattage	378 watts
Noise Level	Approximately 42 dB (in normal operation)
Color	White
Material	Plastic
Special Features	Automatic Shut-off, Continuous Drainage Option, Laundry Drying Function, Sleep Mode, Child Lock
Included Components	Dehumidifier unit, Drainage hose, User Manual

Voor elk moment van de dag
Ook ideaal voor 's nachts

10 dB Ademen	30 dB Fluisteren	42 dB Auronic luchtontvochtiger	50 dB Luid gesprek
------------------------	----------------------------	--	------------------------------

Image: Illustration comparing the noise level of the Auronic dehumidifier (42 dB) to other common sounds, indicating its quiet operation suitable for bedrooms.

WARRANTY AND SUPPORT

Warranty Information

Specific warranty details may vary. Please refer to the warranty card included with your product or contact your retailer/seller for information regarding the warranty period and terms.

Customer Support

For any questions, technical assistance, or service requests, please contact the seller or manufacturer directly. Their contact information can typically be found on the product packaging, purchase invoice, or their official website.