

Apkezel High-Speed Electric Air Duster

Apkezel High-Speed Electric Air Duster User Manual

Model: High-Speed Electric Air Duster

Brand: Apkezel

1. INTRODUCTION

Thank you for choosing the Apkezel High-Speed Electric Air Duster. This device is designed to provide efficient and eco-friendly cleaning for a wide range of electronics and household items. Featuring a powerful brushless motor and a rechargeable battery, it offers a convenient alternative to traditional compressed air cans. Please read this manual thoroughly before use to ensure proper operation and maintenance.

2. PRODUCT OVERVIEW

The Apkezel Electric Air Duster is a compact and powerful cleaning tool. Its key features include:

- **150,000 RPM Brushless Motor:** Provides strong airflow for effective dust removal with reduced noise and extended lifespan.
- **Three Adjustable Speed Settings:** Allows for versatile cleaning tailored to different needs.
- **6000mAh Rechargeable Battery:** Offers long operating times and convenient Type-C fast charging.
- **Portable and Lightweight Design:** Easy to carry and store, comparable in size to a mobile phone.
- **Magnetic Nozzle:** Facilitates easy attachment and removal of accessories.
- **Eco-Friendly:** A reusable alternative to chemical-based compressed air cans.



Figure 2.1: Apkezel High-Speed Electric Air Duster with charging cable and cleaning brushes.

MAGNETIC DESIGN

Easy to Disassemble and Clean



Brushless Motor



60dB Low Noise



Type-C Charging



LED Lighting

Figure 2.2: Illustration of the magnetic nozzle design for easy assembly and disassembly.

PORTABLE DESIGN

Comfortable to Hold, Easy to Carry




Figure 2.3: The compact and portable design of the Apkezel Air Duster, shown next to a smartphone for scale.

3. PACKAGE CONTENTS

Please check the package for the following items:

- Apkezel High-Speed Electric Air Duster
- Magnetic Nozzle
- USB Type-C Charging Cable
- Cleaning Brushes (various types)
- User Manual

4. SETUP

4.1 Initial Charging

Before first use, fully charge the air duster. The device is equipped with a 6000mAh lithium battery and supports Type-C fast charging.

1. Connect the provided USB Type-C charging cable to the charging port on the air duster.
2. Connect the other end of the cable to a compatible USB power source (e.g., laptop, power bank, car charger, or wall adapter).
3. The charging indicator light will illuminate. A full charge typically takes approximately 3 hours.
4. Once fully charged, disconnect the charging cable.



Figure 4.1: Illustration of the 6000mAh battery and Type-C charging capability.

4.2 Attaching the Nozzle

The air duster features a magnetic nozzle for easy attachment.

1. Align the magnetic nozzle with the air outlet of the main unit.
2. The nozzle will snap into place securely due to the magnetic connection.
3. To remove, gently pull the nozzle away from the unit.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off and Speed Adjustment

The air duster has a power button and a speed adjustment function.

1. **Power On:** Press and hold the power button for a few seconds until the device turns on at the lowest speed setting.
2. **Adjust Speed:** Briefly press the power button to cycle through the three available speed settings (Low, Medium, High).
3. **Power Off:** Press and hold the power button for a few seconds until the device turns off.

3 ADJUSTABLE SPEEDS

Suitable for Different Scenarios



Figure 5.1: The three adjustable speed settings (60,000 RPM, 90,000 RPM, 150,000 RPM) for various cleaning tasks.

5.2 Cleaning Applications

The Apkezel Air Duster is suitable for a variety of cleaning tasks:

- **Electronics:** Computers, keyboards, laptops, cameras, printers, game consoles.
- **Automotive:** Car interiors, dashboards, seats.
- **Household:** Sofas, pet hair removal, small inflatables (floats, inflatable beds).
- **Outdoor:** Assisting with campfire ignition.

150000 RPM POWERFUL MOTOR

Deep Cleaning 99 % Dust




Figure 5.2: Using the air duster to effectively clean a computer keyboard.

MULTIPLE USAGE SCENARIOS

Easily Cope With All Kinds of Cleaning





Figure 5.3: Multiple usage scenarios demonstrating the versatility of the air duster for cleaning various items.

6. MAINTENANCE

6.1 Cleaning the Device

To maintain optimal performance, keep the air duster clean.

- Ensure the device is powered off before cleaning.
- Wipe the exterior of the unit with a soft, dry cloth.
- Use the provided cleaning brushes to remove any dust or debris from the air intake and outlet areas.
- Do not use liquid cleaners or immerse the device in water.

6.2 Storage

Store the air duster in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the battery is partially charged (around 50%) if storing for extended periods to prolong battery life.

7. TROUBLESHOOTING

If you encounter issues with your Apkezel Air Duster, refer to the following common solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully using the provided Type-C cable.
Weak airflow.	Low battery or incorrect speed setting.	Charge the battery or increase the speed setting. Ensure air intake/outlet is not blocked.
Nozzle detaches easily.	Nozzle not properly aligned or magnetic connection is weak.	Re-attach the nozzle, ensuring it is correctly aligned with the magnetic connection points.

If the problem persists, please contact customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	Apkezel
Motor Type	Brushless Motor
Max Speed	150,000 RPM
Blowing Force	Up to 50 m/s
Noise Level	Below 60 dB
Battery Capacity	6000 mAh Lithium Battery
Charging Port	USB Type-C
Charging Time	Approx. 3 hours
Operating Time	30-120 minutes (depending on speed)
Dimensions	Approx. 14 x 10 x 4 cm
Weight	Approx. 318 grams
Material	High-hardness, high-temperature resistant ABS
UPC	768657034228
ASIN	B0DDNK8MB6

9. SAFETY INFORMATION

Please observe the following safety precautions:

- Keep the device away from water and moisture.
- Do not operate the device near flammable liquids or gases.
- Avoid directing the airflow directly at eyes, skin, or delicate internal components of electronics for extended periods.
- Do not block the air intake or outlet during operation.
- Keep out of reach of children.
- Use only the provided charging cable or a certified Type-C cable for charging.
- Do not attempt to disassemble or repair the device yourself. Contact qualified personnel for service.

10. WARRANTY AND SUPPORT

Apkezel products are manufactured to high-quality standards. For warranty information, technical support, or any questions regarding your product, please refer to the contact information provided at the point of purchase or visit the official Apkezel website.