

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [JRD](#) /

> [JRD Warm & Cool Mist Humidifier HTJ-2286A-03 User Manual](#)

JRD HTJ-2286A-03

JRD Warm & Cool Mist Humidifier

MODEL: HTJ-2286A-03 USER MANUAL

1. IMPORTANT SAFETY INFORMATION

Please read and understand all safety instructions before using this appliance to prevent injury or damage.

- Always place the humidifier on a firm, flat, waterproof surface at least 6 inches (15 cm) away from walls and appliances.
- Before initial use, ensure to remove the small blue polystyrene float from the bottom of the water tank. Failure to do so may prevent proper operation.
- Do not add water directly into the mist nozzle. Water should only be added through the designated top-fill opening to prevent water leakage and damage to internal components.
- For optimal performance and to prevent mineral build-up (white dust), use distilled or demineralized water.
- Keep the appliance out of reach of children and pets.
- Unplug the humidifier before filling, cleaning, or moving it.
- Do not block the air intake or mist outlet.
- If you encounter any problems during use, please contact JRD customer support for assistance.

2. PRODUCT OVERVIEW

The JRD Warm & Cool Mist Humidifier (Model HTJ-2286A-03) is designed to provide optimal humidity levels for enhanced comfort and well-being. Featuring advanced ultrasonic technology, it offers both warm and cool mist options to suit various environmental needs throughout the year. Its generous 5-liter capacity ensures up to 50 hours of continuous operation on a single fill, making it ideal for large rooms, bedrooms, offices, and nurseries.

Key features include a convenient top-fill design, quiet operation (below 35dB), an integrated essential oil diffuser for aromatherapy, a 12-hour timer, and a 7-color adjustable night light. The humidifier can be controlled via a touch panel or a remote control, offering flexibility and ease of use. It also includes an

automatic shut-off safety feature when the water tank is empty.

Add Warm Mist Option

Better Sinus & Allergies Relief



JRD
Warm & Cool Mist

Other
Cool Mist Only



Upgrade HotSpring Mist

Helps Open Nasal Cavity



122°F Ultrasonic Mist

Feel Warmer after 3 Minutes



Image: The JRD Warm & Cool Mist Humidifier, showcasing its sleek black design, digital display, and control panel.

3. PACKAGE CONTENTS

Please check the package for the following items:

- JRD Warm & Cool Mist Humidifier Unit
- Remote Control
- User Manual
- Cleaning Brush (may be included)

4. PRODUCT DIAGRAM

Top-Fill Design for Easy Use

Take less than a minute to refill.



Note: Remove the sponge before **first use**.

! Do not add water directly into the mist outlet which may cause water leakage.

Image: A visual representation of the humidifier's features, including its quiet operation, timer, nightlight, and sleep mode, designed for a restful environment.

Familiarize yourself with the main components of your humidifier:

- **Mist Nozzle:** Rotates 360° to direct mist.
- **Water Tank:** 5-liter capacity with visible water level.
- **Control Panel:** Touch-sensitive buttons and digital display.
- **Base Unit:** Contains ultrasonic atomizer and heating element.
- **Essential Oil Tray:** Located at the base for aromatherapy.
- **Air Intake:** Located at the back or bottom of the unit.

5. SETUP

1. **Unpack:** Carefully remove all packaging materials and place the humidifier on a stable, flat, and waterproof surface.
2. **Remove Protective Float:** Locate and remove the small blue polystyrene float from the bottom of the water tank before first use.
3. **Fill Water Tank:** Remove the top cover. Fill the 5-liter water tank with clean, distilled, or demineralized water. Do not exceed the 'MAX' fill line.



Image: Illustrates the convenient top-fill design, allowing for easy water replenishment.

- 4. Replace Cover:** Securely place the top cover back onto the humidifier.
- 5. Connect Power:** Plug the power cord into a standard electrical outlet. The unit will beep once, and the display will light up.

6. OPERATION

The humidifier can be operated using the touch control panel on the front of the unit or the included remote control.

Cool & Warm Healthy Mist

Warm Mist

-  Up RH 10% in 13 mins
-  Relieve the Flu
-  Warm You Up in winter

Cool Mist

-  Moisturizes Skin
-  300mL/h
4X Faster Mist
-  Refresh You in Summer



Image: Demonstrates the ease of controlling the humidifier using the remote, with mist visible from the top

6.1 Basic Controls

- **Power Button:** Press to turn the humidifier On or Off.
- **Mist Mode Button:** Cycle through Low, Medium, and High mist output levels.
- **Warm/Cool Mist Button:** Toggle between warm mist (indicated by red wavy lines) and cool mist.
- **Humidity Setting Button:** Adjust the desired humidity level from 40% to 90% in 5% increments. The unit will automatically maintain this level.
- **Timer Button:** Set an auto-off timer from 1 to 12 hours.
- **Night Light Button:** Turn the 7-color night light On/Off or cycle through colors.
- **Sleep Mode Button:** Activates a quiet operation mode with dimmed display.
- **Child Lock Button:** Locks the control panel to prevent accidental changes.

6.2 Warm & Cool Mist Function

The humidifier offers both warm and cool mist options. Warm mist can help relieve congestion and provide a comforting warmth, while cool mist is ideal for general humidification and cooling during warmer periods.



Image: A graphic illustrating the distinct benefits of warm mist (e.g., increasing humidity, relieving flu symptoms) and cool mist (e.g., moisturizing skin, faster humidification).

6.3 Aromatherapy

To use the aromatherapy feature, pull out the essential oil tray located at the base of the unit. Add a few drops of your preferred essential oil onto the aroma pad. Reinsert the tray. The mist will diffuse the aroma into the air.

Humidify Your Home Easily



Remote control



Touch panel



Image: A user enjoying the aromatherapy feature of the humidifier, with a small inset showing the essential oil tray.

6.4 Night Light & Sleep Mode

The integrated 7-color night light can be set to a single color or cycle through all colors, providing a soothing ambiance. Activate Sleep Mode for ultra-quiet operation and a dimmed display, ensuring an undisturbed night's rest.



Image: The humidifier in a bedroom setting, emphasizing its quiet operation and adjustable 7-color soft

night light for a comfortable bedtime experience.

7. MAINTENANCE

Regular cleaning and proper maintenance are essential to ensure the longevity and efficient operation of your humidifier.

7.1 Daily Maintenance

- Empty and rinse the water tank daily.
- Wipe the inside of the tank with a soft cloth.

7.2 Weekly Cleaning

1. **Unplug:** Always unplug the humidifier before cleaning.
2. **Empty Water:** Remove the water tank and empty any remaining water from both the tank and the base unit.
3. **Clean Water Tank:** Fill the water tank halfway with water and add 2 tablespoons of white vinegar. Shake well and let it sit for 30 minutes. Rinse thoroughly until the vinegar smell is gone.
4. **Clean Base Unit:** Gently wipe the inside of the base unit, especially the ultrasonic atomizer, with a soft cloth dampened with white vinegar. Use the provided cleaning brush for hard-to-reach areas. Do not immerse the base unit in water.



Image: A close-up view of the humidifier's internal components being cleaned with a cloth and brush, emphasizing proper hygiene.

5. **Rinse & Dry:** Rinse all parts thoroughly with clean water and allow them to air dry completely before reassembling.

7.3 Storage

When not in use for an extended period, clean the humidifier as described above, ensure all parts are dry, and store it in a cool, dry place.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No mist or low mist output	Lack of water; clogged atomizer; mist nozzle blocked.	Refill water tank; clean the atomizer and base; ensure mist nozzle is clear.

Problem	Possible Cause	Solution
Water leakage	Water added to mist nozzle; tank not seated correctly; damaged tank.	Always fill through top opening; ensure tank is properly aligned; check for cracks.
White dust around unit	Hard water used.	Use distilled or demineralized water; clean the unit regularly.
Unit turns off unexpectedly	Water tank empty; timer activated.	Refill water tank; check timer settings.
Unusual odor	Stagnant water; dirty tank/base.	Empty and clean the water tank and base thoroughly.

9. SPECIFICATIONS

Feature	Specification
Brand	JRD
Model Name	HTJ-2286A-03
Operation Mode	Ultrasonic
Capacity	5 Liters
Max Runtime	Up to 50 hours
Product Dimensions	11"D x 12"W x 6.4"H
Item Weight	6.38 pounds (2.9 Kilograms)
Special Features	Warm & Cool Mist, Aroma Diffuser, Auto Shut Off, 12H Timer, 7 Color Night Light, Adjustable Humidity (40%-90%), 3 Mist Levels, Sleep Mode, 360° Rotating Nozzle, Remote/Touch Control
Room Type	Bedroom, Large Room, Office, Baby, Plants

10. WARRANTY AND SUPPORT

JRD products are designed for durability and performance. For warranty information, technical support, or any questions regarding your humidifier, please refer to the contact information provided in your product packaging or visit the official JRD website. Our customer service team is available to assist you within 24 hours for any issues encountered during use.

