Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- iDPRT /
- > iDPRT MT610 Pro Portable Thermal Printer User Manual

iDPRT MT610 Pro

iDPRT MT610 Pro Portable Thermal Printer User Manual

Model: MT610 Pro
Brand: iDPRT

1. Introduction

This manual provides detailed instructions for the safe and efficient operation of your iDPRT MT610 Pro Portable Thermal Printer. Please read this manual thoroughly before using the device and retain it for future reference.

The iDPRT MT610 Pro is a compact, inkless thermal printer designed for portability and convenience. It supports various paper sizes including US Letter, A4, and A5, and offers 300 DPI print resolution for documents. Connectivity options include Bluetooth for mobile devices and USB for computers.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package. If any items are missing or damaged, please contact customer support.

- MT610 Printer ×1
- USB-C Cable ×1
- Quick Start Guide ×1
- US Letter Thermal Paper ×10 sheets
- APP "HerePrint" (download required)

3. PRODUCT OVERVIEW

The iDPRT MT610 Pro printer features a compact design for easy portability. Key physical dimensions are approximately 10.2 inches (length) x 2.2 inches (width) x 1.5 inches (height), and it weighs about 1.1 pounds (498g).




Image: iDPRT MT610 Pro printer showing its compact dimensions of 10.2 inches length, 2.2 inches width, and 1.5 inches height, next to a smartphone for scale.

The printer operates without ink cartridges, utilizing thermal paper for printing. It is equipped with a 2000mAh battery, providing extended use on a single charge.



Image: Diagram illustrating the inkless thermal printing technology of the iDPRT MT610 Pro, indicating no ink or toner is required.

4. SETUP

4.1 Charging the Printer

Before initial use, fully charge the printer using the provided USB-C cable. Connect the USB-C cable to the printer and a compatible power source (e.g., computer USB port, USB wall adapter). The charging indicator light will provide status feedback.




Image: Close-up of the iDPRT MT610 Pro printer highlighting the USB-C charging port and indicating a 2000mAh battery capacity, capable of 720 hours standby or 240 sheets per full charge.

4.2 Loading Thermal Paper

The MT610 Pro supports various thermal paper sizes, including US Letter (8.5" x 11"), A4, A5, and B5. Ensure you use only thermal paper with this printer.

- 1. Open the printer's paper cover.
- 2. Insert the thermal paper with the printable side facing up. Ensure the paper is aligned correctly within the guides.
- 3. Close the paper cover securely.



Image: The iDPRT MT610 Pro printer demonstrating compatibility with US Letter, A4, A5, and B5 paper sizes, with an emphasis on using official iDPRT replacement thermal paper.

5. OPERATING INSTRUCTIONS

5.1 Mobile Printing (Bluetooth Connection)

To print from your smartphone or tablet, follow these steps:

- 1. **Download the "HerePrint" App:** Search for "HerePrint" in your device's app store (App Store for iOS, Google Play for Android) or scan the QR code provided in the Quick Start Guide. Download HerePrint App
- 2. Turn on the Printer: Press and hold the power button on the MT610 Pro until the indicator light illuminates.
- 3. **Connect via Bluetooth:** Open the "HerePrint" app. In the app, navigate to the device connection section. Turn on Bluetooth on your mobile device and select the MT610 Pro from the list of available devices to pair.
- 4. **Select and Print:** Once connected, use the app to select the document or image you wish to print. Follow the on-screen prompts to initiate printing.



Image: Visual guide showing three steps for connecting the iDPRT MT610 Pro to a phone or tablet via Bluetooth using the HerePrint app.

5.2 Computer Printing (USB Connection)

To print from your computer (Windows, macOS, Linux, ChromeOS), follow these steps:

- 1. **Connect the Printer:** Use the provided USB-C cable to connect the MT610 Pro to your computer. Ensure the printer is powered on.
- 2. **Install Drivers:** Download the appropriate printer driver for your operating system from the official iDPRT website. iDPRT Driver Download Page Install the driver following the on-screen instructions.

3.	Print Document: Open the document you wish to print (e.g., Word, Excel, PDF). Select "Print" from the
	application menu. In the print dialog box, choose "iDPRT MT610 Pro" as your printer and configure paper size
	settings as needed. Initiate printing.

Image: Visual guide showing three steps for connecting the iDPRT MT610 Pro to a computer via USB, including driver download and selecting the printer for printing.

6. MAINTENANCE

6.1 Cleaning the Printer

Regular cleaning helps maintain print quality and extends the life of your printer.

- Ensure the printer is turned off and disconnected from any power source before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or isopropyl alcohol to gently wipe the exterior of the
 printer.
- To clean the thermal print head, use a specialized thermal printer cleaning pen or a cotton swab lightly dampened with isopropyl alcohol. Gently wipe the print head surface. Allow it to dry completely before use.
- Do not use abrasive cleaners or solvents.

6.2 Battery Care

To optimize battery life:

- · Avoid fully discharging the battery frequently.
- Store the printer in a cool, dry place when not in use for extended periods.
- Charge the printer regularly, even if not used, to maintain battery health.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your iDPRT MT610 Pro printer.

7.1 Printer Not Connecting via Bluetooth

- Ensure the printer is powered on and within range of your mobile device.
- Verify Bluetooth is enabled on your mobile device.
- Restart both the printer and your mobile device.
- Ensure the "HerePrint" app is installed and updated to the latest version.
- If previously paired, try unpairing and re-pairing the device in your mobile device's Bluetooth settings.

7.2 Printer Not Recognized by Computer (USB)

- Confirm the USB-C cable is securely connected to both the printer and the computer.
- Ensure the printer is powered on.
- Verify that the correct printer drivers for your operating system are installed. If not, download them from the official iDPRT website.
- Try connecting to a different USB port on your computer.
- Restart your computer and the printer.

7.3 Poor Print Quality or Blank Pages

- Ensure you are using thermal paper and that it is loaded correctly with the printable side facing up.
- Check if the thermal paper is old or damaged, as this can affect print quality.
- Clean the thermal print head as described in the Maintenance section.
- For images, avoid printing entirely black images as this printer is optimized for documents and may not produce optimal results for high-density black areas.

7.4 Paper Jam

- Turn off the printer immediately.
- Open the paper cover and carefully remove any jammed paper. Avoid tearing the paper inside the mechanism.
- Ensure paper is loaded correctly and not wrinkled or bent before printing.

8. SPECIFICATIONS

Feature	Specification
Product Dimensions	10.2"D x 2.2"W x 1.5"H
Item Weight	1.1 pounds (498g)
Controller Type	Android, iOS
Maximum Media Size	8.5 x 11 inch (US Letter)
Supported Sheet Sizes	US Letter (8.5"x11"), A4, A5, B5
Power Consumption	10 Watts
Print Media	Thermal Paper
Max Input Sheet Capacity	10 sheets
Max Print Speed (Monochrome)	35 ppm
Compatible Devices	Laptops, PC, Smartphones, Tablets
Maximum Print Resolution	300 x 300 Dots Per Inch (300DPI)
Dual-sided printing	No
Hardware Interface	USB Type C
Ink Color	Black (Thermal)
Control Method	Арр
Printer Ink Type	Thermal
Battery	1 Lithium Polymer battery required (2000mAh)

Feature	Specification
Connectivity Technology	Bluetooth, USB
Special Feature	300 DPI HD Print, Energy Star, Lightweight, Portable
Printer Output	Monochrome

9. WARRANTY AND SUPPORT

The iDPRT MT610 Pro printer comes with a limited warranty. Please refer to the warranty card included in your package or visit the official iDPRT website for detailed warranty terms and conditions.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact iDPRT customer service through their official website or the contact information provided in your Quick Start Guide.

Official Website: www.idprt.com

© 2025 iDPRT. All rights reserved.

Related Documents - MT610 Pro



LN449 User Manual: Installation, Operation, and Maintenance Guide for iDPRT Printer

Comprehensive user manual for the iDPRT LN449 thermal label printer. Covers safety instructions, installation, usage, operation panel, maintenance, and detailed specifications. Learn how to set up and operate your LN449 printer effectively.



iDPRT SP310 Thermal Label & Receipt Printer User Guide

Comprehensive user guide for the iDPRT SP310 thermal label and receipt printer, covering setup, operation, driver installation for Windows and macOS, printing preferences, and troubleshooting.



IDPRT TE200 Quick Start Guide: Setup and Basic Operation

Get started quickly with your IDPRT TE200 thermal label printer. This guide covers packing, components, power connection, ribbon loading, and paper loading.



iDPRT SP410BT Bluetooth Thermal Label Printer User Guide

Comprehensive user guide for the iDPRT SP410BT Bluetooth Thermal Label Printer, covering package contents, setup, driver installation for Windows and macOS, label loading, printing preferences, status indicators, and troubleshooting tips.



IDPRT iF4 Label Printer Quick Start Guide

A concise and SEO-optimized guide for setting up the IDPRT iF4 label printer. Covers packing list, component identification, paper and ribbon loading, power/USB connections, warranty, and safety information.



IDPRT iQ4 Quick Start Guide - Installation and Setup

Comprehensive quick start guide for the IDPRT iQ4 printer, detailing unpacking, component identification, ribbon and paper loading procedures, power connection, warranty, and safety information.