

[Manuals.plus](#) /

› [YITAHOME](#) /

› YITAHOME Large Dressing Table User Manual

YITAHOME Schminktisch

YITAHOME Large Dressing Table User Manual

Model: Schminktisch

INTRODUCTION

Thank you for choosing the YITAHOME Large Dressing Table. This versatile vanity table is designed to enhance your beauty routine with its spacious design, integrated LED lighting, convenient power outlets, and ample storage. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new dressing table.



The YITAHOME Large Dressing Table, featuring a wide mirror with LED lighting, multiple drawers, and a matching stool.

SETUP AND ASSEMBLY

Your YITAHOME Dressing Table will arrive in two separate packages, which may not be delivered simultaneously. Please ensure you have received both boxes before beginning assembly. All components are clearly labeled, and a step-by-step instruction manual is included in the package for easy assembly. We recommend having a second person assist with assembly for optimal safety and efficiency.

OUR PACKAGE

The item comes **in two boxes** and may not arrive at the same time




Important note: The dressing table ships in two separate boxes, which may arrive at different times.

Dimensions

Refer to the diagram below for detailed product dimensions to ensure proper placement in your desired space.

- Table Dimensions: 117 cm (L) x 29.8 cm (W) x 142 cm (H)
- Stool Dimensions: 39.9 cm (L) x 28.2 cm (W) x 38.5 cm (H)



Detailed measurements of the dressing table and accompanying stool.

OPERATING INSTRUCTIONS



LED Lighting Control

The large mirror features an integrated LED light strip with three adjustable lighting modes: Warm White, Warm Yellow, and Cool White. To operate:

- **Tap the switch:** Briefly touch the designated switch on the mirror to turn the light on/off and cycle through the three color modes.
- **Long press to adjust brightness:** Press and hold the switch to seamlessly adjust the brightness level from 0% to 100%.

Release when the desired brightness is achieved.


3 COLOR LIGHTING MODES & ADJUSTABLE BRIGHTNESS



The LED mirror offers three color modes and adjustable brightness for optimal lighting.

Integrated Power Outlets and USB Ports

The dressing table is equipped with two standard AC outlets and two USB ports, providing convenient access to power for your beauty tools and electronic devices. A dedicated hairdryer holder is also included for organized storage.



This dressing table offers extensive storage with 11 spacious drawers, designed to accommodate all your makeup, fragrances, hair styling tools, and other accessories. The included stool also features hidden storage space for additional organization.



The dressing table features 11 drawers and the stool includes hidden storage for efficient organization.

MAINTENANCE

To ensure the longevity and appearance of your YITAHOME Dressing Table, follow these maintenance guidelines:

- **Cleaning Surfaces:** Wipe all surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the finish.
- **Mirror Care:** Clean the mirror with a glass cleaner and a lint-free cloth. Do not spray cleaner directly onto the LED strip or electrical components.
- **Drawer Maintenance:** Periodically check drawer slides for smooth operation. If needed, a small amount of silicone spray can be applied to the slides.
- **Electrical Components:** Ensure all plugs are securely inserted into the outlets. Do not attempt to repair or modify the electrical components yourself.


TROUBLESHOOTING

If you encounter any issues with your dressing table, please refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Missing or Damaged Parts	Shipping error or manufacturing defect.	Contact YITAHOME customer support immediately for replacement parts. Provide the part number(s) from the instruction manual.
LED Light Not Working	Power connection issue, light switch malfunction.	Ensure the power cord is securely plugged in. Check if the outlet is functional. If the issue persists, contact customer support.
Drawers Do Not Slide Smoothly	Improper assembly, debris in slides, or misaligned rails.	Verify that drawer slides are correctly installed and aligned according to the manual. Clear any obstructions. Apply a small amount of lubricant if necessary.
Electrical Outlets/USB Ports Not Functioning	No power, faulty wiring.	Check the main power connection. Ensure the power cord is fully inserted. If no power is detected, contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	YITAHOME
Model Number	Schminktisch
Color	White
Material	Engineered Wood
Table Dimensions (L x W x H)	117 cm x 29.8 cm x 142 cm (46.1" x 11.7" x 55.9")
Stool Dimensions (L x W x H)	39.9 cm x 28.2 cm x 38.5 cm (15.7" x 11.1" x 15.2")
Number of Drawers	11
LED Lighting	3 Color Modes (Warm White, Warm Yellow, Cool White), Adjustable Brightness
Power Outlets	2 AC Outlets (100-240V, 12A)
USB Ports	2 USB Ports (5V, 2A)
Power Cord Length	4.7 Feet
Assembly Required	Yes (Step-by-step instructions included)
Shipping	Ships in two cartons



Energy efficiency label for the product.

WARRANTY AND SUPPORT

YITAHOME guarantees replacement for any damaged or missing parts. If you require assistance with assembly, have questions about product functionality, or need to request replacement parts, please contact YITAHOME customer support. Refer to your purchase documentation for specific contact details or visit the official YITAHOME website for support information. We are committed to providing a delightful shopping experience and ensuring your satisfaction with our products.

© 2025 YITAHOME. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

