

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [DOGlinsen](#) /

› [DOGlinsen No Shock Dog Training Collar \(Model PD 518V-2\) Instruction Manual](#)

DOGlinsen PD 518V-2

DOGlinsen No Shock Dog Training Collar (Model PD 518V-2) Instruction Manual

Model: PD 518V-2 | Brand: DOGlinsen

INTRODUCTION

Thank you for choosing the DOGlinsen No Shock Dog Training Collar. This manual provides detailed instructions for the safe and effective use of your new training device. Designed for humane training, this collar utilizes tone and vibration to help manage your dog's behavior. Please read this manual thoroughly before operation to ensure proper setup and optimal performance.

IMPORTANT SAFETY INFORMATION

Please observe the following safety guidelines to prevent harm to your pet and yourself:

- **Not for Aggressive Dogs:** Do not use this product on aggressive dogs. If your dog is aggressive, consult a professional dog trainer.
- **Skin Irritation:** Avoid leaving the collar on the dog for more than 12 hours per day. Reposition the collar every 1-2 hours to prevent pressure sores. Check the contact area daily for signs of rash or sores. If a rash or sore is found, discontinue use until the skin has healed.
- **Proper Fit:** Ensure the collar fits snugly but not too tightly. You should be able to fit two fingers comfortably between the collar and your dog's neck.
- **Supervision:** Always supervise your dog during training sessions.
- **Children:** This is not a toy. Keep out of reach of children.
- **Water Safety:** While the receiver is waterproof, ensure the charging port is securely sealed before exposing it to water.


PACKAGE CONTENTS

The DOGlinsen No Shock Dog Training Collar package includes the following items:


- Remote Transmitter
- Receiver Collar (x2 for 2-dog system)

- Adjustable Collar Straps (x2)
- 2-in-1 USB-C Charging Cable
- Wrist Lanyard for Remote
- User Manual
- Clicker (for positive reinforcement training)

Adjustable for All Size Dogs



Quick Release



Reflective



10 lbs



110 lbs

Image: All components included in the DOGlinsen No Shock Dog Training Collar package, featuring the remote, two receivers, two collar straps, charging cable, wrist lanyard, user manual, and a clicker.

Video: An unboxing demonstration showing all items included in the DOGlinsen No Shock Dog Training Collar package, including the remote, receivers, collar straps, charging cable, and clicker.

Remote Transmitter

The remote transmitter features an LCD screen displaying settings, mode buttons for tone, vibration, and channel selection, and side buttons for intensity adjustment. It has a removable antenna for extended range.



Image: A close-up of the DOGlinsen remote transmitter, showing its LCD screen, control buttons for various functions, and the removable antenna.

Receiver Collar

The receiver unit is compact and attaches to the collar strap. It is designed without traditional prongs, focusing on humane training methods using vibration and tone. It features a power button and an indicator

light.



Image: The DOGLinsen receiver unit, highlighting its sleek design and the absence of prongs, emphasizing its no-shock functionality.

SETUP GUIDE

1. Charging the Devices

Before first use, fully charge both the remote transmitter and the receiver collar. Use the provided 2-in-1 USB-C charging cable. The indicator light on the receiver will show charging status.

Long Battery Life



Image: Illustration of the DOGlinsen remote and receiver being charged simultaneously using the included 2-in-1 USB-C charging cable, showing compatibility with various USB power sources.

2. Attaching the Collar Strap

Thread the adjustable collar strap through the loops on the receiver unit. Ensure the strap is securely fastened.

3. Fitting the Collar

Place the collar around your dog's neck. Adjust the strap so it is snug but not tight. You should be able to fit two fingers comfortably between the collar and your dog's neck. The receiver should be positioned centrally on the underside of the dog's neck.

Package Included



Image: A visual guide demonstrating the proper fit of the DOGlinsen training collar on a dog, ensuring it is snug but comfortable.

4. Pairing the Remote and Receiver

To establish communication between the remote and receiver, follow these steps:

1. Hold down the power switch button on the receiver until the indicator light starts flashing.
2. Press the Vibration button on the remote. The receiver will receive the signal and vibrate.
3. Press the Tone button on the remote. The receiver will receive the signal again. This indicates successful pairing.

Video: A step-by-step guide demonstrating how to pair the remote control with the receiver collar, showing the indicator light and button presses.

OPERATING MODES

The DOGLinsen training collar offers multiple humane training modes:

1. Tone Mode

The tone mode provides an audible signal to your dog. There are 9 different tone styles available. Use the '+' and '-' buttons on the side of the remote to select your preferred tone style (1-9).

Video: Demonstration of the 9 different tone styles available on the DOGLinsen remote control, showing how to cycle through them using the side buttons.

2. Vibration Mode

The vibration mode delivers a gentle, non-harmful vibration to get your dog's attention. The intensity of the vibration can be adjusted using the remote's side buttons.

3. Auto Bark Mode

The collar can also function as an automatic bark collar. To activate this mode, press and hold the power button on the receiver. There are 5 levels of sensitivity for the auto bark mode, which can be adjusted by pressing the power button 3 times in a row.



Image: Visual guide on how to activate the automatic bark mode by pressing and holding the power button on the receiver, with an illustration of a dog wearing the collar.




Image: Illustration showing how to adjust the 5 levels of sensitivity for the auto bark mode by pressing the power button on the receiver three times consecutively.

CONTROLLING MULTIPLE DOGS

The DOGlinSen remote transmitter supports up to 3 independent channels, allowing you to control multiple receiver collars simultaneously or separately.

Simultaneous Control (2 Dogs)

To control two receivers at the same time:

1. Put both receivers into pairing mode by holding their power buttons until the indicator lights flash.
2. Select Channel 1 on the remote.
3. Press the Vibration button. Both receivers will vibrate, indicating they are paired to Channel 1 and can be controlled simultaneously.

Separate Control (2 Dogs)

To control two receivers independently:

1. Pair the first receiver to Channel 1 as described in the "Pairing" section.
2. Put the second receiver into pairing mode.
3. Toggle the channel on the remote to Channel 2.
4. Press the Vibration button. Only the second receiver will vibrate, indicating it is paired to Channel 2.
Now you can control each receiver separately by switching channels on the remote.

Video: A demonstration showing how to control multiple dog training collars using the channel function on the remote, allowing for simultaneous or separate control of two receivers.

CHECKING BATTERY LEVEL

To check the battery level of the receiver collar:

1. Press the power button on the receiver twice in a row.
2. Listen for the number of beeps:
 - **5 Beeps:** Above 80% charge
 - **4 Beeps:** Above 60% charge
 - **3 Beeps:** Above 40% charge
 - **2 Beeps:** Above 20% charge
 - **1 Beep:** Below 20% charge (recharge soon)

Video: A demonstration of how to test the battery level of the receiver by pressing the power button twice and interpreting the number of beeps.

WATERPROOF DESIGN

The receiver collar is designed with IP67 waterproof rating, making it suitable for various outdoor conditions, including rainy weather and swimming. Ensure the charging port is properly sealed before water exposure.

Product Size




Image: An image illustrating the IP67 waterproof capability of the DOGLinsen receiver, showing it submerged in water and used in various wet environments.


ADJUSTABLE FOR ALL DOG SIZES

The collar strap is adjustable up to 27 inches, accommodating dogs from 10 lbs to 110 lbs. It features a quick-release buckle and reflective elements for safety. The soft contact points ensure comfort for your dog.

Adjustable for All Size Dogs



Quick Release



Reflective



27 inches

10 lbs



110 lbs

Image: A visual representation of the adjustable collar strap, showing its maximum length of 27 inches and suitability for dogs ranging from 10 lbs to 110 lbs, with features like quick release and reflectivity.

MAINTENANCE

- **Cleaning:** Regularly clean the receiver and collar strap with a damp cloth. Avoid harsh chemicals.
- **Storage:** Store the device in a cool, dry place when not in use.
- **Battery Care:** Do not overcharge the battery. If storing for long periods, charge the battery to about 50% every few months.

TROUBLESHOOTING

Problem	Possible Solution
Receiver not responding to remote	Check if both devices are charged. Re-pair the remote and receiver following the setup instructions. Ensure the remote is on the correct channel if controlling multiple dogs.
Collar not holding charge	Ensure the charging cable is properly connected. Check the charging port for debris. If the issue persists, contact customer support.
Dog not responding to commands	Verify the collar fit is snug. Increase the intensity level of tone or vibration gradually. Ensure consistent training methods.
Auto bark mode not working	Check if auto bark mode is activated. Adjust the sensitivity level. Ensure the collar is positioned correctly on the dog's neck.

SPECIFICATIONS

- **Model Number:** PD 518V-2
- **Brand:** DOGlinsen
- **Control Range:** Up to 3300ft (approx. 1000m)
- **Waterproof Rating:** IP67 (Receiver)
- **Battery Type:** Rechargeable Nonstandard Battery (included)
- **Charging:** 2-in-1 USB-C Cable
- **Collar Length:** Up to 27 inches (adjustable)
- **Recommended Dog Weight:** 10 lbs - 110 lbs
- **Training Modes:** Tone (9 styles), Vibration (adjustable levels), Auto Bark (5 sensitivity levels)
- **Multi-Dog Support:** Up to 3 independent channels

WARRANTY AND SUPPORT

DOGlinsen products come with a standard manufacturer's warranty. For specific warranty details, technical support, or any questions regarding your product, please refer to the contact information provided on the product packaging or visit the official DOGlinsen website. Our customer service team is ready to assist you.