

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [ECOVACS](#) /

› [ECOVACS Solid Floor Cleaner Instruction Manual for DEEBOT N30 OMNI/N30 PRO Omni](#)

ECOVACS DSC060002

ECOVACS Solid Floor Cleaner Instruction Manual

Compatible with DEEBOT N30 OMNI and DEEBOT N30 PRO Omni Robot Vacuum and Mop

1. PRODUCT OVERVIEW

The ECOVACS Solid Floor Cleaner is designed to provide effective stain and dirt removal on a wide range of hard floors. This package includes 6 pieces of solid floor cleaner, with each piece designed to last approximately one month, ensuring a lasting clean scent in your home.

Compatibility: This product is compatible with ECOVACS DEEBOT N30 OMNI and DEEBOT N30 PRO Omni robot vacuum and mop models.



Figure 1: ECOVACS Solid Floor Cleaner sticks.

2. SETUP AND INSTALLATION

Follow these steps to properly install the solid floor cleaner into your compatible DEEBOT robot vacuum.

1. Open the clean water tank compartment on your DEEBOT OMNI station.
2. Remove the clean water tank.
3. Place one ECOVACS Solid Floor Cleaner stick into the designated compartment within the clean water tank.
4. Fill the clean water tank with water up to the indicated fill line.
5. Close the lid of the clean water tank and gently swirl to mix the cleaner with the water.
6. Reinsert the clean water tank into the OMNI station.



Long before the “Smart Home” concept became fashionable ECOVACS Robotics (ECOVACS) was already at the forefront of innovation in smart home robotics, exploring new ways for robots to transform homeowners' lives.

ECOVACS' more than 27 years of work in service robotics has seen the company transformed from a visionary startup into a global corporation with a Mission of Robotics for All.

Designed to change the way people live and work, ECOVACS robotics are now being used in over 170 countries and regions around the world.

Figure 2: Inserting the solid floor cleaner into the DEEBOT OMNI station's clean water tank.

Visual Guide: Solid Detergent Floor Installation

Video 1: This video demonstrates the installation process of the solid floor cleaner into the DEEBOT OMNI station.

3. OPERATING INSTRUCTIONS

Once the solid floor cleaner is installed and the clean water tank is filled, your DEEBOT is ready to perform its mopping functions. The cleaner will automatically dissolve and mix with the water as the robot operates.

- Initiate a cleaning cycle through the ECOVACS HOME app or by pressing the start button on the OMNI station.
- The robot will dispense the cleaning solution as it mops, providing a thorough clean and leaving a fresh scent.
- The solid cleaner provides a long-lasting antibacterial effect for up to 30 days, reducing the need for frequent manual additions of liquid cleaner.



Figure 3: DEEBOT robot vacuum in operation, mopping a hard floor.

4. MAINTENANCE

Regular maintenance ensures optimal performance of your DEEBOT and the effectiveness of the solid floor cleaner.

- **Replacing the Solid Cleaner:** Replace one solid cleaner stick approximately every month, or when you notice a decrease in cleaning performance or scent.
- **Clean Water Tank:** Regularly rinse the clean water tank to prevent residue buildup.
- **Dirty Water Tank:** Empty and clean the dirty water tank after each cleaning cycle to prevent odors and bacterial growth.
- **Mop Pads:** Remove and wash the mop pads after each use. The OMNI station may have an auto-wash function for the pads.
- **Brushes and Filters:** Periodically check and clean the main brush, side brushes, and filters according to your DEEBOT's specific instruction manual.



Figure 4: Open water tanks of the DEEBOT OMNI station for maintenance.

5. TROUBLESHOOTING

If you encounter issues with your ECOVACS Solid Floor Cleaner or DEEBOT, consider the following:

- **Cleaner Not Dispensing:** Ensure the solid cleaner stick is correctly placed in the clean water tank and the tank is filled to the appropriate level. Check for any blockages in the dispensing mechanism.
- **Reduced Cleaning Performance:** Verify that the solid cleaner has not fully dissolved and needs replacement. Ensure mop pads are clean and properly attached. Clean the robot's brushes and filters.
- **Unpleasant Odor:** Thoroughly clean both the clean and dirty water tanks, as well as the mop pads, to eliminate any bacterial growth.

6. SPECIFICATIONS

| Feature | Detail |
|---------------------|----------------------------|
| Brand | ECOVACS |
| Model Name | DSC060002 |
| Included Components | 6 Pcs Solid Floor Cleaners |
| Item Weight | 5.4 ounces |
| UPC | 850058335964 |

7. WARRANTY AND SUPPORT

For warranty information, technical support, or to purchase replacement parts, please refer to the official ECOVACS website or contact their customer service directly. Keep your purchase receipt for any warranty claims.

