Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- BEZGAR /
- > BEZGAR RC Boat Accessories Package for TX2P1 Instruction Manual

BEZGAR TX2P1

BEZGAR RC Boat Accessories Package for TX2P1 Instruction Manual

Model: TX2P1 Accessories

1. Introduction

This instruction manual provides essential information for the proper use, installation, and maintenance of your BEZGAR RC Boat Accessories Package, specifically designed for the TX2P1 RC Boat. Please read this manual thoroughly before using the accessories to ensure optimal performance and longevity.

2. PACKAGE CONTENTS

Your BEZGAR RC Boat Accessories Package for TX2P1 includes the following items:

- 7.4V 1200mAH Li-ion Battery x 1
- Charging Cable x 1
- Screw Propeller x 2
- Protective Silicone Gel x 2
- Rudder x 1



Image: Contents of the BEZGAR RC Boat Accessories Package for TX2P1, including a 7.4V 600mAh Li-ion battery, two screw propellers, two protective silicone pieces, and a rudder.

3. SETUP AND INSTALLATION

These accessories are designed for the BEZGAR TX2P1 RC Boat. Refer to your TX2P1 boat's main instruction manual for specific boat disassembly/assembly steps if needed.

3.1. Battery Installation

- 1. Ensure the TX2P1 RC boat is powered off and dry.
- 2. Locate and open the battery compartment on the boat.
- 3. Carefully connect the 7.4V 1200mAH Li-ion Battery to the boat's power connector.
- 4. Place the battery securely within the compartment and close the cover, ensuring it is properly sealed to prevent water ingress.

3.2. Propeller Installation

- 1. Identify the propeller shaft at the rear of the boat.
- 2. Align a new Screw Propeller with the shaft and push it firmly into place.
- 3. Secure the propeller with any provided retaining hardware (e.g., nut, washer) as per your boat's design.

3.3. Rudder Installation

- 1. Locate the rudder mounting point at the stern of the boat.
- 2. Attach the Rudder to the designated slot or mechanism.
- 3. Ensure the rudder is securely fastened and moves freely without obstruction.

3.4. Protective Silicone Gel Installation

- 1. These silicone pieces are designed to protect vulnerable areas of the boat.
- 2. Identify the areas on your TX2P1 boat where protective silicone can be applied (e.g., bow, sides).
- 3. Adhere or attach the Protective Silicone Gel pieces firmly to these areas for added impact protection.

4. OPERATING INSTRUCTIONS

Once accessories are installed, refer to your BEZGAR TX2P1 RC Boat's main manual for detailed operating procedures. The following videos demonstrate general RC boat operation and features that your TX2P1 boat may share.

Your browser does not support the video tag.

Video: Demonstrating the BEZGAR HJ820 RC boat in action, highlighting its speed, maneuverability, and automatic flip recovery feature. This video provides a visual guide to the type of boat these accessories are designed for.

Your browser does not support the video tag.

Video: Showcasing the BEZGAR RC boat's performance, including high-speed sailing, long-distance control, and dual boat racing capabilities. This video illustrates the operational aspects of the compatible RC boat.

5. MAINTENANCE

5.1. Battery Care

- · Always use the provided Charging Cable to charge the Li-ion Battery.
- Do not overcharge or over-discharge the battery.
- Store batteries in a cool, dry place away from direct sunlight and extreme temperatures.
- Disconnect the battery from the boat when not in use.

5.2. General Cleaning

- After each use, especially in saltwater, rinse the boat and accessories with fresh water.
- Dry all components thoroughly before storage to prevent corrosion.
- Inspect propellers and rudder for any debris or damage regularly.

6. TROUBLESHOOTING

If you encounter issues, please refer to the TX2P1 RC Boat's main manual for comprehensive troubleshooting. Below are general tips related to the accessories:

- **Battery not charging:** Ensure the charging cable is properly connected to both the battery and a power source. Check for any damage to the cable or battery.
- **Reduced performance:** Check the battery charge level. Inspect propellers for damage or entanglement with debris.
- Loose accessories: Periodically check that all installed accessories (propellers, rudder, protective silicone) are securely attached.

7. SPECIFICATIONS

Feature	Detail
Package Dimensions	3.78 x 3.7 x 2.09 inches
Item Weight	3.2 ounces
ASIN	B0DDQ326VR
Batteries	1 Lithium Ion battery required (included)
Manufacturer	BEZGAR
Number of Batteries	1 Lithium Ion battery (included)
Battery Cell Composition	Lithium Ion
Battery Capacity	600 Milliamp Hours
Recommended Uses For Product	RC Boat

8. WARRANTY AND SUPPORT

BEZGAR stands by the quality of its products. While specific warranty details for this accessories package are not provided in this document, we are committed to customer satisfaction.

If you have any questions, concerns, or require assistance with your BEZGAR RC Boat Accessories Package for TX2P1, please do not hesitate to contact us. Our customer support team is ready to help.

Related Documents - TX2P1



BEZGAR HQ051 Remote Control Drone User Manual

Comprehensive user manual for the BEZGAR HQ051 Remote Control Drone, covering setup, flight controls, battery maintenance, safety precautions, and troubleshooting. Learn how to fly and operate your drone safely.



Bezgar TD203 Remote Control Car User Manual and Specifications

Official user manual and technical specifications for the Bezgar TD203 remote control car, including operation tips, battery installation, and compliance information.



BEZGAR TC141 1:14 RC Car Instruction Manual

Instruction manual for the BEZGAR TC141 1:14 RC Car, covering safety precautions, battery installation, operation guidelines, and regulatory compliance information.

Market Ma	Bezgar 1:28 Atom Max R/C Car Instruction Manual Comprehensive instruction manual for the Bezgar 1:28 Atom Max R/C car, covering setup, operation, safety, and troubleshooting. Learn how to install batteries and control your remote control car.
	BEZGAR BZR 15/BZR 16 Remote Control Car User Manual Comprehensive user manual for the BEZGAR BZR 15 and BZR 16 remote control cars. Includes setup, operation, charging, troubleshooting, and safety instructions.
	BEZGAR Road Runner RC Car User Guide and Manual Comprehensive user guide for the BEZGAR Road Runner RC car (Model TB201), covering battery installation, basic operations, safety precautions, and maintenance. Learn how to operate and care for your remote control car.