

[Manuals.plus](#) /

› [MoVols](#) /

› MoVols P2033-8S1P-PAA Vacuum Cleaner Battery User Manual for Dreame T30 R20

MoVols P2033-8S1P-PAA

MoVols P2033-8S1P-PAA Vacuum Cleaner Battery User Manual

Compatible with Dreame T30 and R20 Cordless Vacuum Cleaners

INTRODUCTION

This manual provides essential instructions for the safe and effective use of your MoVols P2033-8S1P-PAA replacement battery. This high-performance Li-Ion battery is designed to be fully compatible with Dreame T30 and R20 cordless vacuum cleaners, offering optimal performance and a longer service life. Please read this manual thoroughly before installation and use.



Image: MoVols P2033-8S1P-PAA Replacement Battery.

SETUP AND INSTALLATION

Follow these steps to safely install the replacement battery into your Dreame T30 or R20 cordless vacuum cleaner.

1. **Power Off:** Ensure your vacuum cleaner is completely powered off and disconnected from any charging source before attempting battery replacement.
2. **Locate Battery Compartment:** Identify the battery compartment on your Dreame T30 or R20 vacuum cleaner. Refer to your vacuum cleaner's original manual if unsure.
3. **Remove Old Battery:** Carefully unlatch or unscrew the old battery from its compartment. Dispose of the old battery responsibly according to local regulations.
4. **Insert New Battery:** Align the MoVols P2033-8S1P-PAA battery with the compartment and slide it into place until it clicks securely. Ensure all connections are firm.
5. **Initial Charge:** After installation, fully charge the new battery before its first use.

FOR DREAME T30 T30 NEO



- **VACUUM CLEANER BATTERY ACCESSORIES**
- **3000MAH 5000MAH**

Image: MoVols battery indicating compatibility with Dreame T30 and T30 Neo vacuum cleaners.

OPERATING INSTRUCTIONS

To ensure optimal performance and longevity of your MoVols battery, follow these operating guidelines:

- **First Use:** Fully charge the battery before its initial use to calibrate its capacity.
- **Charging:** Use only the original charger provided with your Dreame vacuum cleaner. The battery features fast charging technology with multiple security protections, including overcurrent, short circuit, overtemperature, and overvoltage protection.
- **Regular Use:** The battery is designed for consistent performance. It has no memory effect, meaning you can charge it at any time without reducing its overall capacity.
- **Discharge:** Avoid completely draining the battery frequently. It is best to recharge it before it reaches critically low levels.

Vacuum Cleaner Battery Accessories!




Image: MoVols battery shown alongside a compatible vacuum cleaner.

MAINTENANCE AND CARE

Proper maintenance will extend the life and performance of your battery.

- **Storage:** If storing the battery for an extended period, ensure it is charged to approximately 50-70% and stored in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cleaning:** Keep the battery contacts clean and free from dust or debris. Use a dry cloth to wipe them if necessary.
- **Temperature:** Avoid exposing the battery to extreme heat or cold, as this can degrade its performance and lifespan.
- **Physical Damage:** Protect the battery from drops, impacts, and punctures. Do not attempt to open or modify the battery casing.

TROUBLESHOOTING

If you encounter issues with your MoVols battery, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Battery not charging	Charger not connected properly; faulty charger; battery contacts dirty.	Ensure charger is securely connected. Try a different outlet. Clean battery contacts. Verify charger functionality.
Short runtime after full charge	Battery not fully charged; battery degradation; vacuum cleaner issue.	Ensure battery is fully charged. If battery is old, consider replacement. Check vacuum cleaner for blockages or motor issues.
Vacuum cleaner not powering on	Battery not installed correctly; battery completely discharged; battery fault.	Re-install battery, ensuring a secure connection. Charge the battery. If problem persists, contact support.

PRODUCT SPECIFICATIONS

Detailed specifications for the MoVols P2033-8S1P-PAA battery:

Feature	Detail
Model Number	P2033-8S1P-PAA
Capacity	2500mAh
Battery Type	Lithium-Ion (Li-Ion)
Voltage	29.6V
Number of Cells	8 Cells
Maximum Runtime	Up to 90 minutes (Max)
Weight	Approximately 500g (1.1 lbs)
Dimensions	138 x 81 x 45.5 mm (approx. 5.4 x 3.2 x 1.8 inches)
Compatibility	Dreame T30, Dreame R20 Cordless Vacuum Cleaners



Capacity: **2500mAh**

Battery Type: Li-ion

Cell: 8 Cells

Runtime: 90mins (Max)

Specifications

Image: Visual representation of key battery specifications.

WARRANTY INFORMATION

For specific warranty details regarding your MoVols P2033-8S1P-PAA battery, please refer to the warranty card included with your purchase or contact the seller directly. Warranty terms typically cover manufacturing defects under normal use conditions.

CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need to report an issue that cannot be resolved using the troubleshooting guide, please contact the seller or MoVols customer support. Provide your product model number (P2033-8S1P-PAA) and purchase details for faster service.

