

[manuals.plus](#) /

› [Kamon](#) /

› [Kamon K30 Wireless Earbuds User Manual](#)

Kamon K30

Kamon K30 Wireless Earbuds User Manual

Model: K30 (Item Model Number: XY-30)

1. INTRODUCTION

Thank you for choosing the Kamon K30 Wireless Earbuds. This manual provides detailed instructions for the proper use, setup, and maintenance of your new earbuds. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.



Image 1.1: Kamon K30 Wireless Earbuds in their charging case.

The Kamon K30 earbuds feature Bluetooth 5.1 technology for stable connectivity, intuitive touch controls, and a comfortable in-ear design. They are designed to deliver clear stereo sound for various audio activities.

2. PACKAGE CONTENTS

Please check the package for the following items:

- 2 x Kamon K30 Wireless Earbuds
- 1 x Wireless Charging Case
- 1 x USB-C Charging Cable
- 4 x Ear Tips (various sizes)
- 1 x User Manual

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Kamon K30 Wireless Earbuds.




Image 3.1: The Kamon K30 earbuds removed from their open charging case, showing the charging contacts.

The earbuds are designed for a secure and comfortable fit. The charging case protects the earbuds and provides additional battery life.

One-Step Pairing



Image 3.2: Internal structure diagram illustrating the components responsible for Hi-Fi stereo sound delivery.

4. SETUP

4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated to make contact with the charging pins.
2. Connect the USB-C charging cable to the charging port on the case and plug the other end into a USB power adapter (not included) or a computer's USB port.
3. The indicator light on the charging case will show charging status. Once fully charged, the light will change or turn off depending on the model.
4. Earbud charging time: Approximately 40 minutes.
5. Charging box charging time: Approximately 1 hour.




Image 4.1: The charging case and earbuds, illustrating battery life and charging indicators.

4.2 Pairing with a Device

The Kamon K30 earbuds feature one-step auto-pairing for convenience.

1. Ensure your device's Bluetooth is turned on.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your device, search for Bluetooth devices and select "Kamon K30" (or similar name like "XY-30") from the list.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

SMART Touch Control

-  **Pause / playback**
One-click left or right earphone
-  **Answer/hang up**
One-click left or right earphone
-  **Refused to answer the call**
Long press left/right earphone
-  **Volume+**
triple-click Left earphone
-  **volume-**
triple-click Right earphone
-  **previous songs**
Double-click Left earphone
-  **next songs**
Double-click Right earphone
-  **Summon voice assistant**
Long press left or right earphone for 3S



Image 4.2: A smartphone displaying the Bluetooth pairing menu, showing "Kamon K30" as an available device.

The earbuds support Bluetooth 5.1, providing a stable connection up to 33 feet (10 meters) in open outdoor environments.

5. OPERATING INSTRUCTIONS

5.1 Touch Controls

The Kamon K30 earbuds feature intuitive touch controls on each earbud. Refer to the diagram below for specific functions:



Image 5.1: A visual guide to the touch control functions on the Kamon K30 earbuds.

- **Play/Pause:** One-click on the left or right earbud.
- **Answer/Hang Up Call:** One-click on the left or right earbud.
- **Refuse Call:** Long press on the left or right earbud.
- **Volume Up:** Triple-click the Left earbud.
- **Volume Down:** Triple-click the Right earbud.
- **Previous Song:** Double-click the Left earbud.
- **Next Song:** Double-click the Right earbud.
- **Summon Voice Assistant:** Long press on the left or right earbud for 3 seconds.

Note: The touch sensors are sensitive. Apply a light touch for control. Avoid forceful tapping.

5.2 Single Earbud Mode

You can use either earbud independently:

1. Remove one earbud from the charging case.
2. Close the charging case lid.
3. The single earbud will automatically connect to your paired device.

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials. Gently clean the charging contacts on both the earbuds and the case to ensure proper charging.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage. Store the case in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Resistance:** The earbuds are waterproof (IPX rating not specified, but generally means splash/sweat resistant). Avoid submerging them in water or exposing them to heavy rain. Dry them thoroughly if they get wet.
- **Battery Care:** To preserve battery life, avoid fully discharging the earbuds and case frequently. Charge them regularly, even if not in constant use.

7. TROUBLESHOOTING

If you encounter issues with your Kamon K30 Wireless Earbuds, refer to the following common solutions:

Problem	Solution
Earbuds not pairing with device.	<ul style="list-style-type: none">◦ Ensure earbuds are charged.◦ Turn off and on your device's Bluetooth.◦ Forget "Kamon K30" from your device's Bluetooth list and re-pair.◦ Place earbuds back in the case, close the lid, wait a few seconds, then open to re-enter pairing mode.
Only one earbud is working.	<ul style="list-style-type: none">◦ Ensure both earbuds are charged.◦ Place both earbuds back into the charging case, close the lid, then open it again to allow them to reconnect to each other.◦ Check if you are in Single Earbud Mode intentionally.
Earbuds not charging.	<ul style="list-style-type: none">◦ Ensure the charging case has power.◦ Verify the earbuds are correctly seated in the case and the charging contacts are clean.◦ Try a different USB-C cable and power adapter.
Low sound quality or intermittent connection.	<ul style="list-style-type: none">◦ Ensure the earbuds are fully charged.◦ Move closer to your paired device to reduce interference.◦ Avoid obstacles between the earbuds and your device.◦ Clean any debris from the earbud speakers.

8. SPECIFICATIONS

Detailed technical specifications for the Kamon K30 Wireless Earbuds:

- **Model Name:** K30 (XY-30)
- **Brand:** Kamon
- **Connectivity:** Wireless (Bluetooth 5.1)
- **Bluetooth Profiles:** HSP, HFP, A2DP, AVRCP
- **Transmission Distance:** Up to 33 feet (10 meters) in open outdoor environments
- **Earphone Battery Capacity:** 35mAh
- **Charging Case Battery Capacity:** 350mAh
- **Listening Time:** 3-5 hours
- **Earphone Charging Time:** Approximately 40 minutes
- **Charging Box Charging Time:** Approximately 1 hour
- **Horn Material:** Graphene True Copper Ring Horn
- **Control Method:** Touch
- **Material:** ABS, Electronic Component
- **Item Weight:** 0.9 ounces (earbuds and case combined)
- **Package Dimensions:** 2.53 x 2.5 x 2 inches
- **Color:** Purple (as per this variant)
- **Special Features:** Lightweight, Microphone Included, Rechargeable Battery, Surround Sound, Sweatproof (Waterproof)



Image 8.1: Dimensional drawing of the Kamon K30 earbuds and their charging case.



9. WARRANTY AND SUPPORT


For warranty information or technical support, please refer to the contact details provided on the product packaging or the official Kamon website. Keep your purchase receipt as proof of purchase for any warranty claims.



Image 9.1: A user wearing a Kamon K30 earbud, demonstrating its in-ear fit.

Related Documents - K30

 <p>Lighting and Indication Selection Guide</p>	<p>Banner Engineering Lighting and Indication Selection Guide</p> <p>Comprehensive selection guide for Banner Engineering's industrial LED lighting and indication solutions, including programmable lights, illumination series, spot and area lights, tower lights, indicators, touch buttons, pick-to-light, and displays. Features product specifications, communication protocols (IO-Link, Modbus, EtherNet/IP), and applications.</p>
 <p>Size: 288*91mm</p>	<p>Shenzhen FuShiKe K30 Wireless Headset User Manual - Pairing, Charging, FCC Compliance</p> <p>Comprehensive user manual for the Shenzhen FuShiKe K30 wireless headset. Provides instructions on pairing, using controls, charging, proper disposal, and FCC compliance information. Includes package contents and important notifications.</p>

	<p>LC-dolida K30 Bluetooth Headband Headphones User Manual</p> <p>Comprehensive user manual for LC-dolida K30 Bluetooth Headband Headphones. Learn about features, specifications, setup, operation, and troubleshooting for these sweatproof, long-lasting wireless headphones.</p>
	<p>BoyKeep Wi-Fi Smart Camera Manual Guide</p> <p>A comprehensive manual guide for the BoyKeep Wi-Fi Smart Camera, covering app download, account login, device setup via scanning code and AP hotspot, features, FAQs, and important notes.</p>
 <p>User Manual K30 Pet Camera</p> <p>Email: support@boykeep.com Website: www.boykeep.com VI-2311</p>	<p>Boykeep K30 Pet Camera User Manual</p> <p>User manual for the Boykeep K30 Pet Camera, detailing setup, features, and troubleshooting for this indoor security camera. Learn how to connect and use your Boykeep K30.</p>
	<p>K30 Pro Optical Sensor: Quick Start Guide and Specifications</p> <p>Concise guide to setting up and installing the Banner K30 Pro Optical Sensor, a 30mm programmable multicolor RGB optical sensor and indicator. Includes wiring diagrams, specifications, and configuration details.</p>

Documents - Kamon – K30

no relevant documents