

[Manuals.plus](#) /

› [Vente-unique](#) /

› Vente-unique MAREKI Trundle Bed (2 x 90 x 190 cm) Instruction Manual

Vente-unique MAREKI

Vente-unique MAREKI Trundle Bed (2 x 90 x 190 cm) Instruction Manual

Model: MAREKI

1. INTRODUCTION

This instruction manual provides comprehensive guidance for the safe assembly, proper operation, and effective maintenance of your Vente-unique MAREKI Trundle Bed. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The MAREKI trundle bed is designed to offer a versatile sleeping solution, featuring a main bed and a retractable secondary bed, both compatible with 90 x 190 cm mattresses (not included). Its construction combines MDF, pine, and metal for durability and stability.



Image 1: The Vente-unique MAREKI Trundle Bed in its extended configuration, providing two sleeping areas.

2. PRODUCT COMPONENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact Vente-unique customer support.

- Main Bed Frame (MDF, Pine, Metal)
- Trundle Bed Frame (MDF, Pine, Metal)
- Main Bed Slatted Base (13 pine slats)
- Trundle Bed Slatted Base (8 poplar slats)
- Assembly Hardware (screws, bolts, connectors)



Image 2: The main bed frame with its slatted base, illustrating the robust construction.

3. ASSEMBLY INSTRUCTIONS

Assembly requires two people. Ensure you have adequate space and the necessary tools (e.g., screwdriver, hammer) before starting.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Main Bed Frame:** Follow the detailed diagrams provided in the separate assembly guide (usually included in the packaging) to connect the side rails, headboard, and footboard using the provided hardware. Do not overtighten screws initially.
3. **Install Main Bed Slatted Base:** Secure the 13 pine slats into the main bed frame according to the assembly guide. Ensure they are evenly spaced and firmly attached.
4. **Assemble Trundle Bed Frame:** Construct the trundle bed frame, including its wheels or sliding mechanism, following the specific instructions.
5. **Install Trundle Bed Slatted Base:** Attach the 8 poplar slats to the trundle bed frame.
6. **Final Tightening:** Once all components are assembled, carefully tighten all screws and bolts. Do not overtighten to avoid damaging the wood.
7. **Positioning:** Place the trundle bed under the main bed.

Important: Always refer to the specific assembly diagrams and instructions included with your product packaging for precise steps and hardware identification.

4. OPERATING INSTRUCTIONS

The MAREKI trundle bed offers a convenient way to provide an additional sleeping surface.

1. **Retracting the Trundle Bed:** To store the trundle bed, ensure no items are obstructing its path. Gently push the trundle bed frame fully underneath the main bed until it is securely in place.
2. **Extending the Trundle Bed:** To use the secondary sleeping area, gently pull the trundle bed frame out from under

the main bed. The trundle bed is designed to roll out smoothly. Position it as desired for use.



Image 3: The Vente-unique MAREKI Trundle Bed in its retracted position, functioning as a single bed.

5. MAINTENANCE

Proper care will extend the life and appearance of your trundle bed.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that can damage the lacquered finish.
- **Hardware Check:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary, but do not overtighten.
- **Avoid Excessive Weight:** Do not exceed the maximum weight capacity for each bed. Main bed: 120 kg. Trundle bed: 60 kg.
- **Ventilation:** Ensure adequate air circulation around and under the bed to prevent moisture buildup.

6. TROUBLESHOOTING

If you encounter issues with your MAREKI trundle bed, consider the following:

- **Squeaking Noises:** Check all connections and tighten any loose hardware. Ensure the slatted bases are correctly seated.
- **Difficulty Extending/Retracting:** Verify that the trundle bed wheels/mechanism are clean and free of obstructions. Ensure the bed is on a level surface.
- **Instability:** Re-check all assembly steps, ensuring all parts are correctly installed and tightened.

For persistent issues, please contact Vente-unique customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	Vente-unique
Model	MAREKI

Type	Trundle Bed (2 x 90 x 190 cm)
Color	White and Natural
Materials	MDF, Pine, Metal
Finish	Lacquered
Overall Dimensions (L x D x H)	200 cm x 98.5 cm x 62 cm
Sleeping Dimensions (each bed)	90 cm x 190 cm
Sleeping Height	33 cm
Main Bed Slats	13 Pine slats
Trundle Bed Slats	8 Poplar slats
Maximum Supported Load (Main Bed)	120 kg
Maximum Supported Load (Trundle Bed)	60 kg
Assembly Required	Yes (Self-assembly)
Origin	Made in Portugal (Europe)

8. WARRANTY AND SUPPORT

For information regarding warranty coverage, spare parts, or customer support, please refer to the documentation included with your purchase or visit the official Vente-unique website. You may also contact their customer service directly for assistance with any product-related inquiries.

Vente-unique Customer Service: Please refer to your purchase receipt or the Vente-unique website for contact details.

© 2024 Vente-unique. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question